RFD77808 – ams TMG4903 Sensor Starter Kit

Contents of Kit

- 1.
- RFD77311 ams TMG4903 Sensor Shield
- RFD77201 Simblee 7pin DIP Shield
- RFD22121 USB Programming Shield
- RFD22126 2xAAA Battery Shield



Figure 1 - RFD77808 Simblee ams TMG4903 Starter Kit

Features of the RFD77311 – ams TMG4903 Sensor Shield

2.

- TMG4903 Sensor
 - 3D Gesture
 - Color Sensor
 - Ambient Light Sensor
 - Proximity Sensor
 - I2C sensor (SCL GPIO 5 and SDA GPIO 6)
- Pushbutton on GPIO 2
- LED on GPIO 3

Figure 2 - RFD77311 ams TMG4903 Sensor Shield





1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

Assembling the Kit for Use

3.

Place the RFD77201 on top of the RFD22126 Battery shield. Place the ams TMG4903 sensor shield on top of the RFD77201. Please note that the shields are seated as shown in the below pictures:



Figure 3 - Kit removed from packaging



Figure 4 - Place RFD77201 Simblee 7pin DIP on top of RFD22126 2xAAA Battery Shield



Figure 5 - Place RFD77311 ams TMG4903 Sensor Shield on top of RFD77201 Simblee 7pin DIP



Figure 6 - Completed Demo Assembly



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

Insert the 2 AAA batteries into the battery shield. Then, slide the switch on the side of the battery shield to turn on the power shield and power on the Simblee device. The yellow LED on the battery shield will indicate that power is being supplied.

Figure 7 - Insert 2xAAA Batteries into holder

Figure 8 - Battery ON/OFF switch location

Figure 9 - LED power indicator



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com







Connecting to the Simblee using Simblee For Mobile

4.

Open the Simblee For Mobile app on your mobile device. If you have not downloaded the Simblee For Mobile app, please see Appendix A on how to download the Simblee For Mobile app.

On the Found Simblees screen, the sensor will show up on the screen, provided that the Simblee device is on. Click on the item. Wait for a moment while the Simblee Interface loads.

Figure 10 - iOS Simblee For Mobile Found Simblees page



Figure 11 - Android Simblee For Mobile Found Simblees page



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

 \bigcirc

 \square

CONFIDENTIAL – INTERNAL USE ONLY Document – Copyright 2017 RF Digital Corporation – Jan 31, 2017

 \leq

The Simblee will now display the proximity and color readings of the TMG4903 sensor.

Figure 12 - iOS Simblee For Mobile app interface



Simblee Connecting Everyone and Everything					
	Gesture, Color, Proximity Sensor				
	Proximity	0			
	Clear	4897 2664 1448			
	Red				
	Green				
	Blue	1081			

Figure 13 - Android Simblee For Mobile app interface



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

To disconnect from the Simblee device, click on the arrow on the top left of the screen pointing left. This will return you to the Found Simblees screen. To exit the app on Android, click on the left arrow at the bottom of the screen.

Figure 14 - iOS Simblee For Mobile back button location

•••• T-Mobile 🗟 5:02 PM < £ 3491 Gesture, Color, Proximity Sensor Proximity 0 Clear 5002 Red 2718 Green 1483 Blue 1106



Figure 15 - Android Simblee For Mobile back button location



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

Appendix A – Downloading the Simblee For Mobile App on iOS and Android Devices

Downloading the Simblee For Mobile App on iOS Devices

Open the App Store on your iPhone/iOS Device running on iOS v8.0 or later

Search for "Simblee".



Click on the "+Get" and Install to start downloading the app, then click on the "+Open" to open the app



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

CONFIDENTIAL - INTERNAL USE ONLY

Document - Copyright 2017 RF Digital Corporation - Jan 31, 2017



Upon opening the Simblee app, a prompt will ask to Allow Internet Access. Click on Yes. The application will also require that Bluetooth be enabled on your device. When entering the app, the app will display an empty browser if no Simblees are in range.

•	●●● T-Mobile ᅙ	3:36 PM	• •	* 83% 💷)
	Fou	und Simbl	ees	Sort
_				

Figure 18 - iOS Simblee For Mobile Internet Access

Figure 19 - Simblee For Mobile Default Screen



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

Downloading the Simblee For Mobile App (Android)

Open the Google Play Store on your Android device running on Android Version 6.0 or above and search for "Simblee". Click on the Simblee For Mobile item, and the Install page will appear. Click the "Install" button, and then "Open" once done installing.

Figure 20 - Android Google Play Store Search

Figure 21 - Simblee For Mobile on Android Google Play Store



Connecting Everyone and Everything

1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

CONFIDENTIAL - INTERNAL USE ONLY

Document - Copyright 2017 RF Digital Corporation - Jan 31, 2017

Note that this app needs location access, click on Allow when prompted.





Figure 23 - Android Simblee For Mobile Location Access Request



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

The application will also require that Bluetooth be enabled on your device. When entering the app, the app will display an empty browser if no Simblees are in range.



Figure 24 - Android Simblee For Mobile Default Screen

Simblee Resources

For more information on using Simblee, please see the following links:

Simblee Quick Start Guide Simblee User Guide Getting Started with Simblee for Mobile Getting Started with SimbleeCOM Simblee Datasheet



1601 Pacific Coast Hwy • Suite 290 • Hermosa Beach • CA • 90254 www.simblee.com • Tel: 949.610.0008 • contact@simblee.com

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Multiple Function Sensor Development Tools category:

Click to view products by RF Digital Wireless manufacturer:

Other Similar products are found below :

RD-KL25-AGMP01 PTC-04-DB-ACT PTC-04-DB-FL FRDM-K22F-SA9500 EV_ICM-20649 MULTI-SENSE-GEVB BRKT-STBC-SA9500 3397 STEVAL-MKIT01V1 EVAL-CN0411-ARDZ KT-TVOC-200-TB200A KT-NmHc-200-TB200A SEN0344 PIM520 PIM518 PIM519 PIM510 103030375 ZSSC4132KIT ADIS16505-3/PCBZ SEN-16794 PIM502 SEN0359 4829 EV26Q64A EVAL-AD7746RDZ EVAL-AD7746HDZ AS7022-EVALKIT RTK0ESXB10C00001BJ MAX30134EVSYS# EV-CBM-PIONEER1-1Z EVAL-ADPD188BIZ-S2 EVAL-ADCM-1 EVAL-CN0507-ARDZ SI118X-KIT ALTEHTG2SMIP EVAL-CN0533-EBZ MIKROE-4305 MAX30101WING# MIKROE-4192 MIKROE-4049 OB1203SD-U-EVK OB1203SD-BT-EVK MIKROE-4037 101990644 MIKROE-4267 MIKROE-4265 MIKROE-4330 ARG-LDKT EVAL-CN0503-ARDZ