

# **DE1.1 LiDAR TF01**

Release level: Public

Confidential level: Public

Product series: DELiDAR-TF01



## Overview

Dear users :

Congratulations! You have chosen the device DE LiDAR-TF01 manufactured by Benewake.

Please read this manual carefully before you install this device and put it into operation. Instructions and hints included in this manual provides better use of the product. Keep the instruction for reference of later work on the equipment.

Benewake (Beijing) Co. Ltd (<u>www.benewake.com</u>), is a high-tech company focusing on "Robotic eyes". IDG capital has granted Benewake A round investment. In 2016, we were awarded "Demo China EXPO" champion. We aim to turn the expensive LiDAR into core compartments for consumer use, and seek for intelligent robots to be owned by normal families.

The core R&D team members of Benewake come from Wake Forest University, Washington University, Humboldt University, Ecole Centrale Marseille, and Beijing Jiaotong University. 18% of our employee has a Doctor degree, and 42% with a Master degree.

Benewake, make the best Robotic Eyes.



## Contents

1.	Product overview 4					
2.	Wo	rking principle	4			
3.	Ele	ctrical characteristics	5			
4.	Opt	tical characteristics	5			
5.	Dat	a output and protocol	6			
5	.1	Standard data format of the serial port	6			
5	.2	Pix data format of the serial port	7			
6.	Noise Model					
7.	Line sequence					
8.	GUI					
8	.1	Standard interface	9			
8	.2	Pix interface	.0			
9.	Serial port and CAN port instructions1					
10.	. Corrosion resistance					
11.	Din	nension and specification1	3			
12.	Inst	tallation and fixation1	3			
13.	Frequently Asked Questions					



#### **1. Product overview**

Based on ToF (Time of Flight) principle, with unique characteristic of optics , electronics, and design, the product can achieve stable, accurate, high – sensitivity and high – speed distance measurement.

	Sensitivity	High			
	Detection range	Max10m (@90% Reflection ) Recommended flying height < 12m			
Features	Detection frequency	100Hz ( up to 500Hz )			
	Anti – ambient light	Work under 100k Lux ambient light			
	Shape Exquisite size , light weight ( 43 g )				
	Accuracy	Cm level @ detection range			
	UAV(drones) floating at fix height				
Applications	Terrain Following				
	Macl	hine control, security sensor			
	Distance measurement				

 Table 1 Features & applications

#### **2.** Working principle

Time of Flight (ToF) is a distance measurement method. The modulated near-infrared light emitted from sensor is reflected by the object. By calculating the time difference or phase difference between emission and reflection, the distance from the object can be deduced and so does the depth information.





Figure 1 DE1.0 Simulated light path

#### **3.** Electrical characteristics

Parameter	Symbol	Тур.	Unit
Supply voltage	DC	5 ( ±5% )	V
Power Consumption	Р	≤1	W
LED peak current	I <sub>max</sub>	200	mA
TTL	V <sub>TTL</sub>	0~3.3	V

#### TF01 Electrical characteristics

 Table 2 TF01 Electrical characteristics

( Ta=20 °C )

### 4. Optical characteristics

Parameter	Symbol	Conditions/Comments	Тур.	Unit
Operating range	L	100Klux ambient light @90% Reflection	30-1000	cm
Emitting half-angle	α	Customizable	1.5	Degree
Receiving half-angle	β	Customizable	1.5	Degree



Detection	De	Minimum detectable object size @ 5m	4 - 6	cm
Resolution	Re	Sensitivity to distance change	0.5	cm
Operating temperature	Т		-10~60	°C
Peak Wavelength	λ		850	nm

 Table 3 Optical characteristics

Test conditions: stable working for 8 hours.

#### **5.** Data output and protocol

Table below is protocol for DELiDAR TF01.

Protocol	UART
Baud rate	115200
Data bit	8
Checksum bit	1
Table 1 Campunia	tion Drotocol

 Table 4 Communication Protocol

### 5.1 Standard data format of the serial port

Data is output in hexadecrimal format, 9 bytes per frame, including one distant info,

called "Dist". Every "Dist" has a seriel number info to it , called Sequence. Frame end bit is checksum bit.

	Byte1 - 2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8	Byte9
--	-----------	-------	-------	-------	-------	-------	-------	-------



0x59 59	Dist_L	Dist_H	Strength_L	Strength_H	Sequence_L	Sequence_H	CheckSum_L			
	Data coding information									
Byte1			0x5	9, frame head	same in every	frame				
Byte2		0x59 , frame head , same in every frame								
Byte3		Dist_L distance value lower eight bit Distance is shown by HEX, eg.1000cm=03 E8 (HEX)								
Byte4	Dist_H distance value upper eight bit									
Byte5	Strength_L Lower eight bit Strength stands for signal quality, scale 0-2000 , indoor<3 reject, outdoor<10 reject									
Byte6	Strength_H Uppereight bit									
Byte7	Sequence _L Serial number lower eight bit Sequence scale vary from 00 00 to FF FF , stands for 0 to 65535 , to mark the continuity of the data									
Byte8			Sequ	ence _H Serial	number upper ei	ght bit				
Byte9	Ch	ecksum che		it , Checksum = mer eight bit , v			Checksum is the			

Table 5 Data coding information and details

### 5.2 **Pix data format of the serial port**



The data is outputted in character string and the unit is m. E.g. the output string 1.21 corresponds to the measuring distance of 1.21m.

#### 6. Noise Model

Strength	Correction Dist standard deviation/cm
> 110	< 0.7
80 - 100	0.7 - 1.1
50 - 80	1.1 - 2
20 - 50	2-5
< 20	> 5

 Table 6 500Hz TF01 noise model




Figure 2 correction dist standard deviation-strength curve



#### 7. Line sequence





Note: line sequence of the CAN bus – Red (Vcc), Black (GND), Green (CAN-H) and White (CAN-L).

#### **8.** GUI

# 8.1 Standard interface




Figure 4 Windows TF-Module Data Display Program UI

① "Start" button, press the button to record TF-01 HEX data, the data will be saved in the same directory with the GUI;

② "Display Range", click 5m or 20m to switch display scale between 5m and 20m;




③ "Data Amount for Distance", Data amount to get an average distance(DAGAD)

④ Device command input area, input HEX command in this window and press Enter to send, to change functions or setting;

(5) Scale to display the real-time measurement;

- 6 Area to display average distance-number of measurements;
- $\bigcirc$  the amount of the data rejected.

(3) Data Detail area : Dist stands for distance , unit cm. Effective Point stands for data quantity of TF-01 output. Strength stands for signal strength.



#### 8.2 **Pix interface**

Figure 5 PIX - Windows TF-Module Data Display Program UI

(9) Data display zone: Dist represents the distance measured, in unit m. The functions of other zones are identical to (1) - (6).



## **9.** Serial port and CAN port instructions

Serial port instruction:

Serial port instruction	Measuring frequency/Hz
42 57 02 00 00 00 00 E6	100
42 57 02 00 00 00 01 E6	200
42 57 02 00 00 00 02 E6	300
42 57 02 00 00 00 03 E6	400
42 57 02 00 00 00 04 E6	500

CAN port conversion cycle instruction:

CAN port instruction	Conversion cycle/ms
42 57 02 00 01 00 00 23	2
42 57 02 00 02 00 00 23	4
42 57 02 00 03 00 00 23	б
42 57 02 00 04 00 00 23	8
42 57 02 00 05 00 00 23	10

CAN port output cycle instruction:



CAN port instruction	Output cycle/ms
42 57 02 00 01 00 00 24	2
42 57 02 00 02 00 00 24	4
42 57 02 00 03 00 00 24	6
42 57 02 00 04 00 00 24	8
42 57 02 00 05 00 00 24	10

#### **10.** Corrosion resistance

Mix the pesticide with water with the radio of 1:30. Place the product inside the solution for 48 hours, and then take it out to observe the property of the product for corrosion resistance.

No.	Type of pesticide	Result	Comment
1	Hymexazol	NG	Corrosion; material turns soft
2	Phenoxyacetate acid compounds	NG	Corrosion; material turns soft
3	Trifluralin	NG	Corrosion; material turns soft
4	Cypermethrin	NG	Corrosion; material turns soft
5	Decamethrin	ОК	No change on product surface
6	Copper sulfate basic	ОК	No change on product surface
7	Glyphosate	OK	No change on product surface




8	Glufosinate-ammonium	OK	No change on product surface
9	Azoles	ОК	No change on product surface




#### **11.** Dimension and specification

Picture below is reference design, the shape and size can be highly customized.



1: Shell



3 : Wire

Figure 6 DELiDAR TF01 Mechanical Dimensions (reference design)




Figure 7 DELiDAR TF01 contour dimension ( unit : mm )

#### **12.** Installation and fixation

Please use the M2.5 pan head screw to install the product. Insert an elastic washer between the screw and the shell to avoid the shell to be damaged from over-screwing.






Figure 8 Installation and fixation instruction

#### **13.** Frequently Asked Questions

(1) What is the spread of the laser beam?

At very close distance (<0.5m), the beam diameter is about the size of the aperture of the lens. For distance larger than 0.5m, the beam diameter can be estimated using the following equation:

distance /20 = beam diameter at the this distance

The actual spread is ~52 milli-radians or ~3 degree.

(2) How do distance, target size, aspect, and reflectivity affect returned signal strength?

The device transmits a focused IR beam that reflects off a target, among which a portion of which returns to the receiver. The distance between the device and the target is determined by the difference between the moment of signal transmission to the moment of signal reception. The effective reception of a reflected signal is influenced by, but not limited to, the following factors:

• Target distance

Returned signal strength ~ 1/D2

D: distance

• Target size

Returned signal strength ~ 1/C4



C: cross section of a target

• Aspect

The orientation of the target to the sensor influences the observable cross section.

• Reflectivity

The reflective characteristics of the surface of the target influence the amount of returned signal.


Generally, it is difficult to detect a small target, especially when it is distant, poorly reflective, and its aspect is away from the normal. Nevertheless, the returned signal strength can be improved by attaching an IR reflector to the target, enlarging the size of the target, modifying its orientation, or reducing its distance from the sensor.

(3) How does the device work with different reflective surfaces?

Generally speaking, the reflective characteristics of the surface of an object can be dedvided into three categories: diffuse reflective, specular and retro-reflective.


• Diffuse reflective surface

For surfaces of materials like paper, matte walls and granite, their textured quality results in the uniform dispersion of reflected energy. Therefore the reflected energy of the dispersed laser is relaatively predictable in percentage. As a result, these materials can be read very well.





For specular surfaces, only a small amout or even none of the reflected light reaches the receiver, depending on the smoothness of the surface and the observation angle. The suggestion is to view the object from the normal.



#### **Cautions** :

- The product must be maintained by our engineers since it is customized optical instrument with high precision.
- Operating temperature : -10-60°C , storage temperature : 0-70°C
- The operating environment must be kept clean. Prevent dust or other stuff from getting into the lens.
- Keep away from high temperature and high humidity environment for storage, transportation or operation.
- Keep away from acid or strong sulfur environment.

## **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Optical Sensor Development Tools category:

Click to view products by DF Robot manufacturer:

Other Similar products are found below :

AR0330CS1C12SPKAH3-GEVB MT9V032C12STCH-GEVB MT9V034C12STCH-GEVB MT9V115EBKSTCH-GEVB AR0130CSSC00SPCAH-GEVB AR0331SRSC00XUEAH-GEVB 416015300-3 ISL29102IROZ-EVALZ MT9D131C12STCH-GEVB MT9M0211A3XTMH-GEVB MT9M034112STMH-GEVB TMD2725-DB AR1820HSSC12SHQAH3-GEVB MT9M001C12STMH-GEVB MT9M034I12STCH-GEVB MT9V013PACSTCHM-GEVB AR1335CSSC11SMKAH3-GEVB MAXCAMOV10640# MT9T112PACSTCH-GEVB MT9V022IA7ATCH-GEVB AR0331SRSC00SHCAH-GEVB MT9M031112STMH-GEVB MT9F002112-N4000H-GEVB MT9V013PACSTCHP-GEVB MT9F002112STCVH-GEVB TMD2620-DB ISL29028AIROZ-EVALZ AR1335CSSC32SMFAH3-GEVB TSL2581CS-DB TMD3700-DB NANOUSB2.2 ISL78365EVAL1Z ASX340AT3C00XPEDH3-GEVB AR0140CS2C00SUEAH3-GEVB AR0430CS2C34SMFAH3-GEVB AR0231AT7R00XUEAH3-GEVB AR0231AT7C00XUEAH3-GEVB AR0231AT7B00XUEAH3-GEVB AR0144CSSC20SUKAH3-GEVB AR0144ATSM20XUEAH3-GEVB AS0142ATSC00XUSMH3-GEVB EVAL-ADPD1080Z-PRX AR0522SRSC09SURAH3-GEVB AR0522SRSM09SURAH3-GEVB AR0521SR2M09SURAH3-GEVB AR0521SR2C09SURAH3-GEVB AR0221SR2C00SUEAH3-GEVB AS7263 DEMO KIT V3.0 AS7261 DEMO KIT V3.0 TSL2740-DB