



Finger Operated Resistive Joysticks



Resistive Joysticks Standard and Miniature

CH Products' Resistive Joystick is a low profile potentiometric controller providing unwavering multi-axis finger-positioning control. Available in two sizes, Standard & Miniature Resistive Joysticks are ideal for applications requiring a compact and reliable, low operating force controller. Featuring several ergonomically designed handles and available in single, dual or triple axis configurations, typical uses include CCTV, robotics, electric wheelchairs and medical devices.

Key Features

- Potentiometer sensing
- One, two, or three axes
- Available in two sizes
- Low profile design and shallow mounting depth
- RoHS compliant
- 7 million life cycles



Available Models

Model 100: Model 200: Model 300: Model 400: Two axis Two axis with buttons Three axis Three axis with buttons

Mechanical Specifications

Joystick travel: Breakout force: Operational force: Maximum force: Centering: Operating temperature: Life cycles: **Standard** 54° (27° from center) 0.034 Nm 0.061 Nm 0.067 Nm Spring centering -10°C to +85°C 7,000,000 Miniature 56° (28° from center) 0.029 Nm 0.041 Nm 0.062 Nm Spring centering -10°C to +85°C 7,000,000

Configuration Options

Handle Options

The Resistive Joystick can be specified with one of 17 handles to maximize functionality and operator comfort. Available with pushbutton switches as well as one, two, or three axes, the Resistive Joystick can accommodate the most specific finger operated applications.

Potentiometer Output Options

The Resistive Joystick range features high quality CH Long Life Potentiometers to deliver one, two, or three axes of precision finger operated control. Providing excellent linearity and rated for greater than seven million lifecycles, CH Long Life Potentiometers are available with either 55° or 220° of electrical travel.

Mounting Options

The Resistive Joystick may be configured with one of seven Mounting Bezels, allowing for either a Front Mount (FM) for Rear Mount (RM) installation.


Centering Options


Standard and Miniature Resistive Joysticks are available with a variety of centering options to accommodate the most specific application requirements. Spring Centering as well as several absolute positioning options are available.


Desktop Housings

CH Products' Resistive Joysticks may be incorporated into one of four Desktop Housings. Configuration options include quantity of pushbutton switches, selection of housing color, as well as USB output.

All specifications are subject to change without notice.








Н Н

HM = 2.09in (53.09mm)

Hs = 2.06in (52.32mm)







NOTES: HM = height above the housing (H) for Miniature Joysticks Hs = height above the housing (H) for Standard Joysticks The drawings are not to scale, but are proportional.

HM = 1.34in (34.04mm)


Hs = 1.32in (33.53mm)

Model 200






Model 300



HM = height above the housing (H) for Miniature Joysticks Hs = height above the housing (H) for Standard Joysticks The drawings are not to scale, but are proportional.

Three Axis Wiring Diagram



CH Long Life Potentiometer Options

CH 550°

Resistance: Taper: Power rating: Temperature range: Electrical travel: Mechanical travel: Rotational torque: Linearity: Rotational life: Electrical element: RoHS compliant

CH 55°

Resistance: Taper: Power rating: Temperature range: Electrical travel: Mechanical travel: Rotational torque: Linearity: Rotational life: Electrical element: RoHS compliant $5K\Omega \pm 20\%$ Linear $\pm 2\%$ 0.3W @ 50°C-10°C to +85°C $220° \pm 5° (110° off center)$ 260° centered0.30 Oz/in. Max $\pm 2\%$ 7 million life cycles Conductive plastic

 $5K\Omega \pm 20\%$ Linear $\pm 2\%$ 0.08W @ 50°C-10°C to +85°C $55° \pm 5° (27.5° off center)$ 260° centered0.30 Oz/in. Max $\pm 2\%$ 7 million life cycles Conductive plastic



Mounting Bezels

Several Front Mount (FM) and Rear Mount (RM) bezels are available for both Standard and Miniature Resistive Joysticks. Front Mount bezels include two sets (four screws per set) of mounting screws (1/2" and 1/4" with 2/56 threading, Phillips flathead) and optional 3/8" screws are available upon request. Rear Mount bezels include two sets of non-anodized mounting screws (1/2" and 1/4" with 2/56 threading, Phillips flathead) and optional 3/8" screws are available upon request. Rear Mount bezels include two sets of non-anodized mounting screws (1/2" and 1/4" with 2/56 threading, Phillips flathead) and optional 5/15" screws are available upon request. Please note: not all bezels are available for all configurations, please contact factory for further information.



Round Bezel (FM) Standard Cutout - 1.625"



Computer Bezel Standard Cutout - 1.213"



Split Bezel (FM) Standard Cutout - 1.500" Miniature Cutout - 1.562"



Square Bezel Snap-on (FM)

Standard Cutout - 1.437" Miniature Cutout - 1.250"



Square Bezel (RM) Standard Cutout - 1.312"

Miniature Cutout -

 \bigcirc

Round Bezel Snap-on (FM) Standard Cutout – 1.625"



Rubber Boot Kit (FM) Standard Cutout - 1.562"

Miniature Cutout - 1.562"

Centering Options

Spring Centering

The joystick returns to design center "neutral" when the handle is released.

1.187"

Friction Clutch

Friction for the "X" and "Y" axes may be independently adjusted via two socket screws, allowing for absolute positioning anywhere within the motion pattern. The Friction Clutch option is only available for Standard Resistive Joysticks.

Center Detent

The Center Detent option provides a positive tactile feedback when the handle is moved from the absolute center position. Center Detent is only available on single and dual axis Standard Resistive Joysticks when configured with the Friction Clutch centering option.

Torque Set

Torque Set provides absolute positioning with uniform friction applied to "X" and "Y" axes and is available 9 for both Standard and Miniature Resistive Joysticks.

Desktop Housings

CH Products' Resistive Joysticks may be incorporated into one of four Desktop Housings. Available in platinum gray or special order black, Desktop Housings feature the "Computer" mounting bezel as well as "X" and "Y" axis spring release tabs to allow for independent spring centering and free floating operation. Optional features include up to five normally open, single pole momentary contact pushbutton switches, external rotary trims, USB output, as well as various cables and strain relief assemblies.

Desktop Housing Features

"X" and "Y" axis spring release tabs Choice of Resistive Joystick model and handle Choice of platinum gray or special order black USB available with select housings

MJ Desktop Housing Features

Choice of zero to five pushbutton switches Available with USB output Dimensions: 7.80" x 4.75" x 1.65"



FJ Desktop Housing Features

Two rectangular pushbutton switches Optional external rotary trim tabs Available with USB output Dimensions: 7.80" x 4.75" x 1.65"

CJ Desktop Housing Features

Two pushbutton switches External rotary trim tabs Dimensions: 3.85" x 3.85" x 1.65"




SJ Desktop Housing Features

Two square pushbutton switches Available only in black Dimensions: 3.85" x 3.85" x 1.85"







Finger Operated Resistive Joysticks

Typical Applications



Made In USA

CCTV

Network/IP Camera Control Remote Control Robotic Systems Factory Automation Machine Control Medical Devices Optical Devices Targeting Systems Electric Wheelchairs Unmanned Vehicle Control Automated Conveyor Systems

CH Products 970 Park Center Drive Vista, CA 92081
 Telephone
 (760) 598-2518

 Fax
 (760) 598-2524

 Email
 oemsales@mail.chproducts.com

 Web site
 www.chproducts.com

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for CH Products manufacturer:

Other Similar products are found below :

HFX-22S12-034 HFX-33S12-034 M41L091M M21L0H1P-X M31L081A TS-1D1U02A HFX-10S12-034 TS-1D1S02A M11Q061P