

Jewel® MagSnap Wrist Straps meet or exceed the requirements of ANSI/ESD S20.20 and ANSI/ESD S1.1 including section 5.4 Breakaway Force "With the ground cord connected to the cuff in a normal manner, a force of \geq .45 kg (1 lb) but \leq 2.3 kg (5 lb) applied to the ground cord, in the normal disconnect direction, shall be required to separate the ground cord from the cuff."

Per ANSI/ESD S20.20 Paragraph 6.2.2.1. Personnel Grounding Requirements "All personnel shall be bonded or electrically connected to ground or contrived ground when handling ESD sensitive items. When personnel are seated at ESD protective workstations, they shall be connected to the common point ground via a wrist strap system."

"At first glance, the ground cord appears to be a relatively simple assembly. However, the design requirements are considerable, given the wide range of user applications and the durability requirements of constant tugging, flexing, and dragging over the edge of workstation tops and equipment chassis."

(ESD Handbook TR20.20 paragraph 5.3.2.2.2 Wrist Strap Ground Cord)

NOTE: Complete wrist strap kits include an alligator clip. Wrist strap kits include an alligator clip for occasions when a grounded banana jack is not available. However, "Wrist strap ground cords must be connected to a groundable point or an equipotential bonding point. Do not connect to a snap on a dissipative mat unless it is the groundable point for the mat. Do not clip a wirst strap to the edge of a dissipative mat." (ESD Handbook TR20.20 section 5.3.2.7)

ESD Handbook TR 20.20 paragraph 5.3.2.4.4 Test Frequency "Because wrist straps have a finite life, it is important to develop a test frequency that will guarantee integrity of the system. Typical test programs recommend that wrist straps that are used daily should be tested daily. However, if the products that are being produced are of such value that knowledge of a continuous, reliable ground is needed, and then continuous monitoring should be considered or even required"

Continuous Monitors pay for themselves improving quality, productivity, eliminating wrist strap daily testing and test result logging. Per ESD-S1.1 paragraph 6.1.3 Frequency of Functional Testing "Daily (Wrist Strap) testing may be omitted if constant monitoring is used."

DESCO

Improve wrist strap contact with Reztore™ ESD Hand Lotion.

Revolutionary magnetic interconnect technology

Creates magnetic connection between wristband and coil cord; meets ANSI/ESD S20.20 and ESD S1.1, including disengagement force test (1-5 lbs). More consistent disengagement force than standard 4 mm designs.

- Dual-wire wrist strap provides redundancy If one dual wire wrist strap condutor is severed, operator still has reliable path-to-ground with other wire
- 3.5 mm mono plug compatible with 3M and other brand Continuous Monitors
- More reliable design

MagSnap revolutionary design provides consistent retention and release performance.

Premium metal expansion wrist strap

Comfortable, designed not to pinch or pull hair

Durable metal band

Long wearing, easy to clean

· Superior contact with skin

For reliable removal of generated static charges

- · Non-flaking or scratching laminated insulator on all external surfaces
- Protects wearers from electrical hazards; provides many years of product life
- UL Listed

Note: This product is not recommended for use on equipment with operating voltage exceeding 250 VAC. **CAUTION:** The ESD Series is for electrostatic control. It will not reduce or increase your risk of receiving electric shock when using or working on electrical equipment. Follow the same precautions you would use without wrist straps, including:

- · Make certain that equipment having a grounding type plug is properly grounded.
- Make certain that you are not in contact with grounded objects other than through the ESD Series.
- Superior resistor connection strain relief

Superior reliability. Greatly exceeds ESD S1.1 Bending Life Test. Tested at over 11 million cycles vs. the 16,000 requirement

- **Covered by one or more of the following patents:** Wristband: 4,639,825
- Superior warranty See details of 1 year Limited Warranty at www.Desco.com/LimitedJewelWarranty.aspx
- Made in America

Item	Description
<u>19826</u>	Jewel [®] MagSnap Dual-Wire Metal Wristband, Large
<u>19827</u>	Jewel [®] MagSnap Dual-Wire Metal Wristband, Medium
<u>19828</u>	Jewel [®] MagSnap Dual-Wire Metal Wristband, Small
<u>19829</u>	Jewel [®] MagSnap Dual-Wire Metal Wrist Strap, Large, 6 ft Coil Cord
<u>19830</u>	Jewel [®] MagSnap Dual-Wire Metal Wrist Strap, Medium, 6 ft Coil Cord
<u>19831</u>	Jewel [®] MagSnap Dual-Wire Metal Wrist Strap, Small, 6 ft Coil Cord
<u>19832</u>	Jewel [®] MagSnap Dual-Wire Metal Wrist Strap, Large, 12 ft Coil Cord
<u>19833</u>	Jewel [®] MagSnap Dual-Wire Metal Wrist Strap, Medium, 12 ft Coil Cord
<u>19834</u>	Jewel [®] MagSnap Dual-Wire Metal Wrist Strap, Small, 12 ft Coil Cord



See Drawing 19820 for details on Jewel® MagSnap Dual-Wire Coil Cords

Jewel[®] MagSnap Dual-Wire Metal Wrist Strap

DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com PHONE (909) 627-8178	DRAWING	DATE:
DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407	NUMBER	March
PHONE (781) 821-8370	19826	2009

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Antistatic Control Products category:

Click to view products by Desco manufacturer:

Other Similar products are found below :

 13505
 13870
 14404
 20-053-0017
 2229
 2231
 3039
 37061
 39792
 42470
 XON-ASB4X30
 XON-ASB6X30
 09813
 09857

 XON-ASB8X10
 XON-ASB6X10
 19695
 09037
 68101
 68103
 73741
 13515
 13869
 13868
 13457
 13245
 13332
 13205
 13135
 91070

 8031
 8523
 13080
 13215
 157 ROLL BEIGE 1.0
 VERAX1R-300R
 17260
 66051
 12550
 19863
 09121
 73831
 13340
 13338
 04541
 19696

 16104
 SPI-20686
 66051
 12550
 19863
 09121
 73831
 13340
 13338
 04541
 19696