

# FC Lens series for Cree XLamp® 7090 XR and XR-E LEDs

- High efficiency
- 4 beams available
- Easy assembly

The FC lens offers low-profile lenses specifically designed for the XLamp® 7090XR and XR-E LEDs (1) from Cree.

A software-optimized aspheric profile enables the generation of several different beam output patterns: narrow, medium, elliptical, and wide beams.

The high collection efficiency reaches 85% of the total flux emitted by the LEDs.

Lens holders are available in black, and provide the proper alignment between the LEDs and the lenses, and set the correct distance between the lens and LED.

The lens holder can be glued to the PCB to provide a secure assembly.

Typical applications are:

- Reading lamps
- Signs
- Architectural Lighting
- Street Lights





Cree® XLamp is a trademark of Cree, Inc. For technical information about these LEDs please refer to the Cree® XLamp datasheet or visit <a href="http://www.cree.com/products/xlamp.asp">http://www.cree.com/products/xlamp.asp</a> or <a href="http://www.cree.com/products/xlamp7090\_xre.asp">http://www.cree.com/products/xlamp7090\_xre.asp</a>

#### FRAEN CORPORATION

80 Newcrossing Road Reading, MA 01867 Phone: 781.205.5300 Fax: 781.942.2426 optics@fraen.com

#### FRAEN S.r.I.

Via Stelvio, 12 20019 Settimo M. (MI) – Italy Phone: +39-02-35.456.1 Fax: +39-02-335.456.239 info@fraen.com

Website: www.fraensrl.com

For ordering information, please contact:

	ARROW
NAFTA Countries	Telephone: 1-888-9LIGHT1
	email: lightingsolutions@arrow.com
	Please contact Fraen S.r.l. for
European Countries	distributor's information
	Email: info@fraen.com

1/8



#### **General Characteristics**

Lens Material Holder Material Operating Temperature range Storage Temperature range Optical Grade PMMA PC, black color -40deg C / + 80 deg C -40deg C / + 80 deg C

Average transmittance in visible spectrum (400 - 700 nm) > 90%, as measured using 3mm thick Optical Grade PMMA.

Please note that flow lines and weld lines on the external surfaces of the lenses are acceptable if the optical performance of the lens is within the specification described in the section "OPTICAL CHARACTERISTICS"

#### **IMPORTANT NOTE – Lenses handling and cleaning:**

- <u>Handling</u>: Always use gloves to handle lenses and/or handle the lenses only by the flange. Never touch the outside surfaces of the lenses with fingers; finger oils and contamination will absorb or refract light.
- <u>Cleaning</u>: Clean lenses only if necessary. Use only soap and water to clean the surfaces and lenses. Never expose the lenses to solvents such as alcohol, as it will damage the plastic.

## Scope

\_\_\_\_\_

This datasheet provides information about the new FC series lenses:

- FC-N2-XR79-0R
- FC-M2-XR79-0R
- FC-W2-XR79-0R
- FC-E2-XR79-0R

The N2 and M2 part numbers have <u>replaced</u> the N1 and M1 part numbers:

- FC-N1-XR79-0
- FC-M1-XR79-0



### Optical Characteristics – Beam Angle (degrees, Full Angle)

Lens Part Number	Type of lens	Cool White	Warm White	Blue	Green	Red
FC-N2-XR79-0R	Narrow beam	8	8	12	12	12
FC-M2-XR79-0R	Medium beam	21	20	22	22	22
FC-W2-XR79-0R	Wide beam	29	28	28	28	28
FC-E2-XR79-0R	Elliptical beam	8 x 44	8 x 44	13x45	13x45	13x45
FC-N1-XR79-0 (5)	Narrow beam	9	-	9	9	9
FC-M1-XR79-0 (5)	Medium beam	28	-	22	22	26

<sup>(1)</sup> The typical divergence varies with LED color due to different chip size and chip position tolerance. The typical total divergence is the full angle measured where the luminous intensity is half of the peak value.

## Optical Characteristics – On-Axis Intensity (candela/lumen)

\_\_\_\_

Lens Part Number	Type of lens	Cool White	Warm White	Blue	Green	Red
		0	$\bigcirc$	•	•	
FC-N2-XR79-0R	Narrow beam	27	27	18	18	19
FC-M2-XR79-0R	Medium beam	4.1	4.1	2.9	2.9	3.3
FC-W2-XR79-0R	Wide beam	2.4	2.4	1.9	1.9	2.4
FC-E2-XR79-0R	Elliptical beam	4.8	4.8	3.5	3.5	3.5
FC-N1-XR79-0 (5)	Narrow beam	21	•	15	17	10
FC-M1-XR79-0 (5)	Medium beam	2.7	-	3.3	3.7	1.9

<sup>(2)</sup> To calculate the on-axis intensity, multiply the on-axis efficiency of the lens (cd/lm) by the total flux of the Cree XLamp 7090® XR and XR-E LED used. See "Illumination Calculations" below. For more detail on flux binning please check the Cree LED datasheet at <a href="http://www.cree.com/products/xlamp.asp">http://www.cree.com/products/xlamp.asp</a>

<sup>(3)</sup> Luminous intensity depends on the flux binning and tolerances of the LEDs. Please refer to the Cree XLamp datasheet for more details on flux binning and mechanical tolerances.

<sup>(4)</sup> Typical illuminance measured in lux per lumen (E) with typical Cree 7090 XR-E LED. To estimate the illuminance in lux, multiply the typical illuminance E by the flux in lumen of the LED used. See "Illumination Calculations" below.

<sup>(5)</sup> FC-N1-XR79-0 and FC-M1-XR79-0 have been replaced by FC-N2-XR79-0R and FC-M2-XR79-0R.



#### **Illumination Calculations**

To calculate peak <u>candela</u>: Find the central spot "on-axis intensity" value in the table above, then multiply this value by the lumens output from your LED (refer to the XLamp LED datasheet <a href="http://www.cree.com/products/pdf/XLamp7090XR-E.pdf">http://www.cree.com/products/pdf/XLamp7090XR.pdf</a> or <a href="http://www.cree.com/products/pdf/XLamp7090XR.pdf">http://www.cree.com/products/pdf/XLamp7090XR.pdf</a> for nominal lumens values). Or for a more accurate calculation, refer to the intensity binning tables <a href="http://www.cree.com/products/xlamp\_docs.asp">http://www.cree.com/products/xlamp\_docs.asp</a> .

#### Example calculation:

If the Fraen narrow beam lens FC-N2-XR79-0R is used on a cool white Cree XR-E LED at 350 mA, the typical luminous flux of the LED is 80 lumens:


The calculation is:  $(27 \text{ candela/lumen}) \times (80 \text{ lumens}) = 2160 \text{ candela peak on-axis}$ .

The <u>beam angle</u> specified in the table above is 8 degrees full beam-width measured at half-peak. This means at 4 degrees off-axis (half of 8 degrees), the intensity should be half of 2160 candela, or 1080 candelas.

1 candela at 1-meter distance produces 1 <u>Lux</u>. This means the peak intensity at 1 meter will be 2160 lux. The intensity decreases as a function of the distance squared, so at 2 meters the peak intensity will be 2160 /  $(2^2)$  = 540 lux. At 3 meters distance, the peak intensity will be 2160 /  $(3^2)$  = 240 lux.

#### **Mechanical Characteristics**

#### Figure 1. Identifying the lenses by their front views





The FC series lenses are available either assembled to a holder or without a holder. The holder provides the correct alignment (concentricity, height, and orientation) of the lens to the LED. Orientation control is important for the elliptical beam lens.

#### Figure 2. Correct vertical distance between FC lens and 7090 XR-E LED

NOTE: If the FC lens is used with <u>no</u> lens holder, the user must provide a mechanical method to set the correct distance between the lens and LED. For example, the lens flange can be located in the lamp housing to center the lens to the LED and establish 13.9 mm from the lens flange to the user's PC board. For N2, M2, W2, E2 lenses, the lens touches the LED.





Figure 3. Elliptical beam orientation





To produce a horizontal elliptical beam, the lens needs to be orientated such that the micro-lenses are positioned vertically. The elliptical beam lens assembly (with holder) will only fit the Cree LED in this orientation (with elliptical beam and rectangular LED substrate aligned). The LED orientation on the PC board should be coordinated with the beam orientation.

NOTE: The elliptical beam lens produces a beam shape that is perpendicular to the microlens pattern on the output face of the lens. The lens holder is designed to align the elliptical pattern with the rectangular shape of the Cree LED substrate. It is important to consider the orientation of the LEDs and the desired elliptical beam orientation when designing the printed circuit board layout.




Figure 4. Installation of lens assembly onto Cree LED






The new FC-N2-XR79-HRF (and M2, W2 and E2) lens assemblies will fit onto the Cree LED at only 2 orientations: 0 degrees and 180 degrees. The bottom of this new –HRF lens holder has a rectangle shape to control lens orientation (important for "E2" elliptical beam lens application). After installation, the bottom of the holder should be at the same datum/plane as the bottom of the Cree LED.



Small crush-ribs inside the round hole will center the lens assembly on the round body of the Cree LED.



The lens assembly can be secured to the PC board by using glue or silicone RTV. To avoid glue on the lens and LED, apply it along the outside diameter edge, or apply a very thin film on areas shown in green.


CAUTION: Do not use instant glue (containing cyanoacrylates). Always test the glue on a sample assembly and check the results and performance 24 hours later. Some adhesives produce fumes that will damage the surfaces of the plastic lens, lens holder, or LED.





## Figure 5. Overall dimensions of FC-\_2-XR79-HRF series lens assemblies


The new FC-\_2-XR79-HRF assemblies (shown at right) are ~ 0.4 mm larger diameter than the previous FC-\_1-XR79-H assemblies shown below.

#### **FC-N1-XR79-H**









Tolerances: +/- 0.2 mm

21.3 dia.



## **Ordering part numbers**

OR: Lens alone (no holder)
HRF: Lens with black PC holder
Caution: If using lens alone (with no holder), lens alignment and spacing must be set by the user. See Figure 2.

N: Narrow beam
M: Medium beam
W: Wide beam
E: Elliptical beam Caution: The orientation of the elliptical beam lens is controlled by the lens holder and the LED orientation (see Figure 3).

#### Published by Fraen Corporation.

All technical data contained in this document are properties of Fraen Corporation and may change without notice.

#### Published by Fraen Corporation.

All data contained in this document is the property of Fraen Corporation and may change without notice.

Rev	Date	Author	Description
05	16 October, 2007	C. Jones	Texture added to M2 and W2 lenses to improve
			homogeneity (evenness) of light output.
04	05 September, 2007	C. Jones	Replaced N1 and M1 with N2, M2, W2, and E2 family.
			Added figures 2,3, 4, and 5 and illumination calculations.
03	26 March 2007	D. DeGaetano	Added Wide and Elliptical timing of official release
02	4 December 2006	D. DeGaetano	Revised holder mechanical drawing
01	27 November 2006	D. DeGaetano	Official Datasheet
00	10 October 2006	D. DeGaetano	Preliminary Datasheet

# **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for LED Lighting Lenses category:

Click to view products by Fraen manufacturer:

Other Similar products are found below:

LL01ED-AK40L06 LL01ZZ-EX25L06-M2 180182-0000 FNP-N2-N083-0R NRW LL01ED-AL155R49 0190535300 0410111300 0510113303 0530997 2710121 C11004\_TINA2-RS C12231\_LENA-FRESNEL-LENS LL01ED-AKY24R49 LL01CR-AYG15R49 LL01CR-OT32L06-M2 LL01ZZ-AAA24L49 LL01CR-CEN38L02 LL01ZZ-AAA55L49 LL01CR-AYG24R49 LL01A00CZMB2-M2 LL01ED-AKY38R49 LL01CR-CNE2545L06-M2 LL01ZZ-AAA38L49 LL01ED-AKV36R49 LL01ED-AL124R49 LL01CR-AYG38R49 FN15973\_RONDA-REC-60-C FP-MS-11.5 F16859\_LINDA-ZT25 C14169\_LENA-CLEAR-LENS C16125\_OLGA-W C17410\_SPORT-2X2-FT6 C17414\_SPORT-2X2-S6 C17409\_SPORT-2X2-FT6W C17360\_SPORT-2X2-FT60 C17434\_ILONA-WW F16636\_LINDA-W60 10003 10003/15 10048 10049 10108 CP10960\_RGBX-SS CP12395\_LXP3-W 10415 10510 1-1000288-0 F14487\_FLORENCE-1R-MAXI-WG 12667 C14165\_STRADA-2X2-ME-WIDE2