

MAXREFDES42# IO-Link RTD Temp Sensor Quick Start Guide

(IQ² IO-Link Master Version)



Rev 0; 1/15

For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim Integrated's website at www.maximintegrated.com.

Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time.

Table of Contents

1.	Required Equipment	3
2.	Overview	5
3.	Included Files	6
4.	Procedure	8
5.	Trademarks	19
6.	Revision History	20

1. Required Equipment

- PC with Windows® 7 or Windows 8 (Verify with IQ² Development that your version of Windows is supported before purchasing their software.)
- MAXREFDES42# board
- IQ² Development iqInterface® IO-Link® master with corresponding USB and power cables (This must be purchased separately.)
- IQ² Development IO-Link iqTool® (tested with version 1.1.0.4 and comes with the iqInterface IO-Link master)
- One IO-Link cable (This must be purchased separately.)
- One A-to-B Type USB cable
- RD42_RL78_V01_XX.ZIP (Maxim-MAXREFDES42-20140824-IODD1.1.html), where XX = minor version



Figure 1. MAXREFDES42# Board Connected to an IQ² Development IO-Link Master



Figure 2. Green Display is Lit

2. Overview

- 1. Connect power and all the cables to the iqInterface IO-Link Master as shown in Figure 1.
- 2. Connect the MAXREFDES42# proximity sensor board to the other side of the IO-Link cable. Make sure the green display is lit as shown in Figure 2.
- Download the latest "all design files" RD42V01_XX.ZIP file located on the Design Resources tab at <u>www.maximintegrated.com/MAXREFDES42</u>. Alternatively, you can download the design files from <u>http://www.iq2-development.com/downloads/</u>.
- Install the IQ² Development IO-Link iqTool onto your Windows PC by referring to IQ² Development's iqInterface User Manual located at <u>http://www.iq2-development.com/downloads/</u>.
- Connect the MAXREFDES42# IO-Link RTD temperature sensor as a device in the IQ² Development IO-Link iqTool.
- 6. Read and write to the desired indexes by referring to IQ² Development's .html index definition file (Maxim-MAXREFDES42-20140824-IODD1.1.html).

3. Included Files

The **RD42_RL78_V01_XX.ZIP** contains the corresponding IO-Link Device Descriptor (IODD) files. The IODD contains information on communication properties, device parameters, identification, process, and diagnostic data. It includes an XML file, an image of the device, an icon image, and the manufacturer's logo. The IODD structure is the same for all devices of all manufacturers, and is always represented in the same way by the IODD interpreter tools. See Figures 3 to 6 for project structure and key filenames.

	a Branar (Britan) a Br
RD42_RL78_V01_00 >	
Name	Date modified
Code_Documentation	12/12/2014 5:27 PM
퉬 Design_Files	12/12/2014 5:27 PM
퉬 IODD	12/12/2014 5:27 PM

Figure 3. Directories inside RD42_RL78_VXX_XX.ZIP.

RD42_RL78_V01_00 Code_Documentation	- - - - + - + + + + + + + + + +
Name	Date modified
🔁 iqmaxrefdes42.pdf	11/24/2014 10:21 AM

Figure 4. File inside the Code_Documentation directory.

RD42_RL78_V01_00 Design_Files	- - € 2
Name	Date modified
iq2dev-iqmaxrefdes42-ddd6184ef2fb.zip iqmaxrefdes42-20141118-v132.hex readme.txt	12/2/2014 1:34 PM 11/24/2014 10:21 AM 12/1/2014 2:30 PM

Figure 5. Files inside the Design_Files directory. Source files are in the zip file.

RD42_RL78_V01_00 ► IODD	▼ 4y 5
A	
Name	Date modified
Maxim logo ppg	1/27/201/ 9.57 AM
Maxini-logo.prig	1/2//2014 0.5/ AIVI
Maxim-MAXREFDES42-20140824-IODD1.0.1.html	11/24/2014 10:23 AM
Maxim-MAXREFDES42-20140824-IODD1.0.1.xml	11/24/2014 10:23 AM
Maxim-MAXREFDES42-20140824-IODD1.1.html	11/24/2014 10:23 AM
Maxim-MAXREFDES42-20140824-IODD1.1.xml	11/24/2014 10:23 AM
💽 Maxim-MAXREFDES42-icon.png	11/24/2014 10:23 AM
💽 Maxim-MAXREFDES42-pic.png	11/24/2014 10:23 AM

Figure 6. Files inside the IODD directory. The .xml files are the IODD files and the .html files are the IQ² Development's .html index definition files.

4. Procedure

- 1. Connect the A-to-B Type USB cable from the PC to the iqInterface IO-Link Master as shown in Figure 1.
- 2. Connect an IO-Link cable to the iqInterface IO-Link Master as shown in Figure 1.
- 3. Connect 24V DC and GND to the orange terminal block on the iqInterface IO-Link Master as shown in Figure 1. Pin 1 is +24V and pin 2 is GND.
- 4. Connect the MAXREFDES42# proximity sensor board to the other side of the IO-Link cable. Make sure the green display is lit as shown in Figure 2.
- Download the latest "all design files" RD42V01_XX.ZIP file located on the DESIGN RESOURCES tab at <u>www.maximintegrated.com/MAXREFDES42</u>. Alternatively, you can download the design files from <u>http://www.ig2-development.com/downloads/</u>.
- 6. Extract the **RD42V01_XX.ZIP** file to a directory on your PC.

 Install the IQ² Development IO-Link iqTool onto your Windows PC as shown in Figure 7 by referring to IQ² Development's iqInterface User Manual located at http://www.iq2-development.com/downloads/.

 IO-Link i 	iqTool v1.1.0.4	-	-	_	-					
××	Setting	Upda	te						١Q [°] ۵	evelopment
iqMaster	iqDevice									
IO-Link						Log and Macro)			
IO-Link	State:	🔿 Inac	tive	IO-Lir	nk Config	Clear log	Save log	Macro	IO-Link device power supply	off
Go To:				Device	properties					
Diagnosi	•									
Diagnosi	3									
Error:	No Errors									
Event:										
Process	Data									
in:				hexar	Ŧ					
Out:				hexar	▼ Set					
On-reque	est Data Read	Request								
Index:	0×0000	hex	Subindex	0x00	hex -					
Data:	00:00				hexar 👻					
					Read					
On-reque	est Data Write	Request								
Index:	0x0000	hex	Subindex	0×00	hex =					
	00:00				hexar 👻					
Data:	00.00									

Figure 7. Newly installed IQ² Development IO-Link iqTool.

8. Make sure you are in the **iqMaster** tab, then press the **Setting** button. In the **IQ Connection Settings** window, select **auto** in the **Comport / USB** dropdown menu. Press **OK** to save setting as shown in Figure 8.

☆ IQ Connection Settings	
Connections Common Co	omport
O Connect by serial number	
 Comport / USB 	auto
	Port 10001
	ok cancel

Figure 8. IQ Connection Settings window.

9. Next, press the **Connect** button as shown in Figure 9.

S IO-Link iqTool v1.1.0.4	1	
Setting Update		
IO-Link	Log and Macro	
IO-Link State: O Inactive	O-Link Config Clear log Save	og Macro IO-Link device power supply off
Go To:	avice properties	
Diagnosis		
Error: No Errors		
Event:		
Process Data		
In:	exar 👻	
Out.	exar 👻 Set	
On-request Data Read Request		
Index: 0x0000 hex v Subindex 0x00	hex v	
Data: 00:00	hexar 💌	
	Read	
On-request Data Write Request		
Index: 0x0000 hex v Subindex 0x00	hex -	
Data: 00:00	hexar 🔻	
	Write	
<u></u>		

Figure 9. Press the Connect button in the iqTool.

10. If the COM port is not found automatically, open **Device Manager** in your Windows operating system as shown in Figure 10 to verify to which COM port the iqInterface hardware is connected. Then manually set that COM port in the **IQ Connection Settings** window and press the **Connect** button again. If you still cannot connect after doing this step, contact IQ² Development's technical support or refer to IQ² Development iqInterface user manual located at http://www.iq2-development.com/downloads/.



Figure 10. Device Manager built into Windows.

11. After the iqTool has connected to the correct COM port, press the **Auto** button as shown in Figure 11.

S IO-Link iqTool v1.1.0.4	
igMaster igDevice	Covelopment GmbH
IO-Link	Log and Macro
IO-Link State: O Inactive IO-Link Config Go To: Preoperate Auto Device properties	Clear log Save log Macro IO-Link device power supply on 2015.01.13 10:20:37.084 AM Log started 00:00:00.000 igInterface is connected to COM8 IO-Link device power supply IO-Link device power supply
Diagnosis	l i l
Error: No Errors Event:	
Process Data	
In: hexar + Out: hexar + Set	
On-request Data Read Request	
Index: 0x0000 hex v Subindex 0x00 hex v Data: 00:00 hexar v Read	
On-request Data Write Request	
Index: 0x0000 hex + Subindex 0x00 hex + Data: 00:00 hexar + Write	
iqFirmware: v1.1.0.5 iqBootloader: v0.0.0.3 iqStack Master: v1.1.1.6 Serial N	lumber: 20140055

Figure 11. iqTool Auto button.

12. You should now see a flashing green **Operate** circle and the **On-request Data Read Request** group should have become active (ungrayed out) as shown in Figure 12.

♦ IO-Link iqTool v1.1.0.4	
J Setting Update iqMaster iqDevice	
IO-Link	Log and Macro
IO-Link State: Operate IO-Link Config Go To: Fallback Device properties	Clear log Save log Macro IO-Link device power supply on 2015.01.13 10:37:15.152 AM Log started 00.000 00.00
Diagnosis	00:01:27.653 Set oper mode Auto request 00:01:28.106 PD Out is invalid 00:01:28.200 Operate state is achieved
Error: No Errors Event:	
Process Data	
In: 23:7D:00 hexar Out: hexar Set	
On-request Data Read Request	
Index: Dx0000 hex Subindex Dx00 hex Data: 00:00 hexar Read	
On-request Data Write Request	
Index: 0x0000 hex v Subindex 0x00 hex v Data: 00:00 hexar v Write	
iqFirmware: v1.1.0.5 iqBootloader: v0.0.0.3 iqStack Master: v1.1.1.6 Serial Nu	mber: 20140055

Figure 12. iqTool Operate state.

13. Open the Maxim-MAXREFDES42-20140824-IODD1.1.html file to view the index numbers and data formats. Go to the index 261, which is the MAX31865 RTD code register value variable as shown in Figure 13. Note: RTD code register value is shifted by 1 bit so the value read back needs to be divided by two.

C Maxim MAXREF0E542-2014(×	8 <u>- 0 x</u>	J
← → C 🗋 file:///C:/Latest%20IO-Link%20Device%20IODDs/RD42_RL78_V01_00/IODD/Maxim-MAXREFDES42-20140824-IODD1.1.html	☆ =	:
Variable "MAX31865ATP+ RTD" index=261 id=V_MAX31865RTD data type: 16-bit Ulnieger default value: 0 access rights: ro dynamic		•
octet U 1 bit offset 15-8 7-0		
Variable "MAX3865ATP+ High Fault Threshold" index=262 id=V_MAX31865HighFaultThreshold data type: 16-bit Ulnleger default value: 5535 access fights: rw excluded from data storage		
octet 0 1 bit offset 15 - 8 7 - 0 element bit 15 - 8 7 - 0		
Variable WAX51060ATF*LOW Fault Intesticid Index-2031d-V_WAA31665LOWFault Intesticid data bps:15-ball Unleger default value: 0 excluded fom data storage	ļ	
octet 0 1 bitoffset 15 - 8 7 - 0 element bit 15 - 8 7 - 0		
Variable "MAX31865ATP+ Fault Status" index=264 id=V_MAX31865FaultStatus data type: 8-bit Uinteger default value: 0 access rights: ro dynamic		
octet 0		•

Figure 13. .html index definition file – Index 261.

- 14. Read the RTD code by performing the operations in the **On-request Data Read Request** group below, as shown in Figure 14.
 - Change Index type to uint16.
 - Enter **261** in the **Index** field.
 - Change the **Data** type to **uint16**.
 - Press the Read button.

Note: RTD code register value is shifted by 1 bit so the value read back needs to be divided by two.

RTD = (Code * 400) / 2^15 = (18174 / 2) * 400/ 2^15 = 110.925 Ohms

IO-Link iqTool v1.1.0.4	
igMaster iqDevice	
IO-Link	Log and Macro
IO-Link State: Operate IO-Link Config Go To: Fallback Device properties	Clear log Save log Macro IO-Link device power supply on 2015.01.13 10:37:15.152 AM Log started 00:00:00.000 ightnerface is connected to COM8 00:01:27.653 Set oper mode Auto request 00:01:27.653 Set oper Auto Request
Diagnosis Error: No Errors Event:	00:01:28.106 PD Out is invalid 00:01:28.200 Operate state is achieved 00:14:11.522 OD read request index 261, subindex 0x00 00:14:11.600 OD read response: 18174 (2 bytes)
Process Data In: 23:7F:00 hexar -	
Out: Set	
On-request Data Read Request	
Index: 261 uint16 v Subindex 0x00 hex v Data: 18174 uint16 v Read	
On-request Data Write Request	
Index: 0x0000 hex Subindex 0x00 hex Data: 00:00 hexar Write	
iqFirmware: v1.1.0.5 iqBootloader: v0.0.0.3 iqStack Master: v1.1.1.6 Serial N	umber: 20140055

Figure 14. iqTool - On-request Data Read Request group – Index 261.

15. Next, go to index 268 in the **Maxim-MAXREFDES42-20140824-IODD1.1.html** file , which is the ambient temperature in degree C variable, as shown in Figure 15.

Maxim-MAX	REFDES42-201	4C × 📃				
← ⇒ C ⁱ	🗋 file:///0	C:/Latest%2	0IO-Link%2	0Device%	20IODDs/RD42_RL78_V01_00/IODD/Maxim-MAXREFDES42-20140824-IODD1.1.html	☆] 〓
Variable "A	mbient ter	nperature"	index=268	id=V_Tem	perature_C	•
data type: Float3 default value: -2 access rights: ro	32 46.876					
octet	0	1	2	3		
bit offset	31 - 24	23 - 16	15 - 8	7 - 0		
element bit	31 - 24	23 - 16	15 - 8	7 - 0		
data type: Float3 default value: 86 access rights: ro	32	nporatare e				
octet	0	1	2	3		
bit offset	31 - 24	23 - 16	15 - 8	7 - 0		
element bit	31 - 24	23 - 16	15 - 8	7 - 0		
data type: Float3 default value: 30 access rights: ro	32					
octet	0	1	2	3		
Dit offset	31 - 24	23 - 10	15 - 8	7-0		
Variable "A data type: Float3 default value: 1.1 access rights: ro	mbient ter	nperature s	witch-point	thysteres	is" index=271 id=V_TemperatureSPHysteresis_F	
octet	0	1	2	3		
bit offset	31 - 24	23 - 16	15 - 8	7 - 0		
element bit	31 - 24	23 - 16	15 - 8	7 - 0		
Variable "A	mbient ter	nperature s	witch-poin	hysteres	is" index=272 id=V_TemperatureSPHysteresis_C	-
😂 Start		0		§ %	💊 💊 💌 🚿	🖀 🕿 🖈 🕞 🛱 📶 🌘 4:47 PM 🖿

Figure 15. .html index definition file – Index 268.

- 16. Read the ambient temperature value in degrees C by performing the operations in the **On-request Data Read Request** group below, as shown in Figure 16.
 - Enter **268** in the **Index** field.
 - Change the **Data** type to **hex**.
 - Press the **Read** button.
 - Convert read hex value to float32.

Temp = 0x41E00E8A = 28.007099 = 28.01 degrees C

♦ IO-Link	iqTool v1.1.0.4								
ioMaster	Setting Update								
	·								
IO-LINK		Log and Macro							
IO-Link	State: Operate IO-Link Config	Clear log Save log Macro IO-Link device power supply on							
Go To:	Fallback Device properties	2015.01.13 10:37:15.152 AM Log started 00:00:00.000 iqinterface is connected to COM8 00:0112.7653 Set oper mode Auto request							
Diagnos	s	00:01:28.106 PD Out is invalid 00:01:28.200 Operate state is achieved							
Error:	No Errors	00:14:11.522 OD read request: index 261, subindex 0x00 00:14:11.600 OD read response: 18174 (2 bytes) 00:37:55.623 OD read request: index 268, subindex 0x00 00:37:55.748 OD read response: 0x41E00E8A (4 bytes)							
Event:									
Process	Data								
In:	23:7D:00 hexar 🗸								
Out:	hexar 👻 Set								
On-requ	On-request Data Read Request								
Index:	268 uint16 v Subindex 0x00 hex v								
Data:	0x41E00E8A hex								
	Read								
On-requ	On-request Data Write Request								
Index:	0x0000 hex Subindex 0x00 hex								
Data:	00:00 hexar •								
iqFirmware	: v1.1.0.5 iqBootloader: v0.0.0.3 iqStack Master: v1.1.1.6 Serial N	umber: 20140055							

Figure 16. iqTool - On-request Data Read Request group – Index 268.

5. Trademarks

IO-Link is a registered trademark of ifm electronic GmbH.

IQ² Development is a registered trademark of IQ² Development GmbH.

iqInterface is a registered trademark of IQ² Development GmbH.

iqTool is a registered trademark of IQ² Development GmbH.

Windows is a registered trademark and registered service mark of Microsoft Corp.

REVISION	REVISION	DESCRIPTION	PAGES
NUMBER	DATE		CHANGED
0	1/15	Initial release	—

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Interface Development Tools category:

Click to view products by Maxim manufacturer:

Other Similar products are found below :

ADP5585CP-EVALZ CHA2066-99F AS8650-DB MLX80104 TESTINTERFACE 416100120-3 XR18910ILEVB XR21B1421IL28-0A-EVB TW-DONGLE-USB EVAL-ADM2491EEBZ MAXREFDES23DB# MAX13235EEVKIT DFR0257 XR22404CG28EVB ZLR964122L ZLR88822L EVK-U23-01S EVK-W262U-00 DC327A PIM511 PIM536 PIM517 DEV-17512 STR-FUSB3307MPX-PPS-GEVK MAXREFDES177# EVAL-ADM2567EEBZ ZSSC3240KIT MAX9121EVKIT PIM532 ZSC31010KITV2P1 UMFT4233HPEV LVDS-18B-EVK XR20M1170G16-0A-EB XR20M1170G16-0B-EB XR20M1170G24-0B-EB XR20M1172G28-0A-EB XR20M1172G28-0B-EB SI871XSOIC8-KIT 1764 1833 1862 EVB-USB82514 ATA6628-EK ATA6631-EK EVAL-CN0313-SDPZ 2264 MCP23X17EV PS081-EVA-HR MODULE 237 SMA2RJ45EVK/NOPB FR12-0002