

Web Site: www.parallax.com Forums: forums.parallax.com Sales: sales@parallax.com Technical: support@parallax.com Office: (916) 624-8333 Fax: (916) 624-8003 Sales: (888) 512-1024 Tech Support: (888) 997-8267

ActivityBot Speaker Mount (#725-32905)

This kit provides a convenient means to mount a veho360 speaker to the ActivityBot robot's chassis, conveniently near the Activity Board's audio jack. Along with a veho360 speaker (sold separately) it's a key accessory to equip your robot to play tunes, make sound effects, or report sensor data from audio files stored on its microSD card.

ActivityBot Speaker Mount Kit Parts

Kit and veho360 speaker on an ActivityBot

Bill of Materials

Part #	Quantity	Description
720-00011	1	Universal L Bracket, aluminum
700-00024	1	Lock-nut, #4-40
700-00028	4	Screw, #4-40, pan-head, 1/4"
721-00060	1	ActivityBot veho360 speaker bracket

Additional Items Required

- Built and tested ActivityBot robot (#32500)
- veho360 speaker (#900-00018)
- Parallax Screwdriver (included in the ActivityBot kit) or #1 Phillips screwdriver
- Parallax Combination Wrench (included in the ActivityBot kit) or similar

Copyright © Parallax Inc.

Assembly Instructions

STEP 1

Insert two screws through the longer arm of the aluminum L bracket, and align speaker bracket holes with the screws, as shown at right.

Notice the U-shape goes to the right. You can put one screw in the top hole and one in the slot (as shown), or put both in the slot. The choice is yours.

STEP 2

With the screwdriver, drive the screws into the holes in the speaker bracket. It is made of Delrin, so the screws will self-tap and stay firmly in place without needing nuts.

STEP 3

Insert a screw through the outer hole in the shorter arm of the L bracket.

Drive the screw into the lock-nut, using the wrench to hold the nut securely.

STEP 4

Remove the screw from the bottom left corner of the Activity Board, the one closest to the headphone jack.

Place the L bracket on the board so the nut is hanging off, towards the back of the robot.

Thread a screw through the L bracket, through the board, and into the standoff below.

STEP 5

Gently twist the veho360 speaker to open it. Slide the middle of the speaker over the speaker bracket, with the cord facing towards the front of the robot.

Plug the speaker into the audio jack on the Activity Board.

Resources and Downloads

Check for the latest version of this document and example programs from the ActivityBot Speaker Mount product page. Go to www.parallax.com and search 725-32905.

Revision History

Version 1.0 – original release.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Mounting Fixings category:

Click to view products by Parallax manufacturer:

Other Similar products are found below :

 5912235-1 REV 5912235-2
 007541
 627
 M3783-7001
 71-074914-006
 71-146610-6H
 71-441549-198
 75-69211-3P
 75-69214-6P
 75

 69220-27S
 75-69224-5S
 7717-8DAP
 85047GULPT
 85048GBESR
 FPK-02-R10
 PMS27488-001-01
 1-18023-0
 H-118-2
 D83999/20WC8SN

 DB1
 1302030464
 DC31-14W19PN
 DC31-14W19PW
 DC32-18W32SN
 DC36-18-32SW
 DC36-18-32SX
 DC37-14-19PW
 DC37-22-21PX

 1302010957
 1302263564
 1302340393
 1404-0016-78
 14540
 149331-9811
 1561-60
 1566
 17542
 BR16A
 HS5659MB98PN

 NT20SATT01
 201C5058-01-201 REV E
 22594-8
 KBB-141
 89078GBESR
 915060
 SF4011-60101
 97-CS-50
 1671