


Thin Film Pyroelectric Linear 128+1 Element Line Sensor Array

With Integrated Read-Out Electronics

Introduction

The Pyreos line sensor array (Linear Array) utilises our unique thin-film pyroelectric PZT material to offer class leading resolution and performance across a wide infrared wavelength range at a very affordable price. The ASIC readout electronics output is a multiplexed, amplified and filtered analogue signal for each sensor element. The sensor is housed in a low profile hermetic metal package along with a temperature sensor, and is fitted with the customer's choice of filter window. An additional "+1" sensor element provides higher sensitivity on a discrete wavelength, e.g. for lubrication oil or foodstuffs. The +1 sensor is located for ATR and transmission use.





| Product Features | | | | |
|----------------------------|--|--|--|--|
| Wavelength range | 0.1 to 100 μm ¹ | | | |
| Operating temperature | Un-cooled operation | | | |
| Number of pixels | 128 sensor elements +1 sensor element | | | |
| 128 Pixel array dimensions | 60 μm x 500 μm; 100 μm pitch | | | |
| +1 sensor area | 1 mm ² (33x larger than array pixels) | | | |
| Pixel operability | 96% with no more than 2 bad in any 10 | | | |
| Dynamic range | >75 dB | | | |
| Scan speed | 10-1000 Hz | | | |

| Applications | |
|----------------------------|---|
| General IR spectroscopy | Portable, robust spectral engines |
| Lubricating oil monitoring | Quality, wear, adulteration, |
| Foodstuffs | Constitution, adulteration |
| Process monitoring | Wind turbine, petrochemical, pharmaceutical |
| Temperature measurement | Non-contact line scanning measurement |
| Imaging | Line scanning |

Filters Available

128 Element Array:

- Linear Variable Filters, ranges: 2.5 to 5.0 μm, 5.5 to 11.0 μm
- Broadband Filters: AR Si
- +1 Element: Discrete wavelength either within or extending beyond the Linear Variable Filter range.
 - 2.90um / 300nm for water content (PY2004, includes 5.5-11 μm array)
 - 5.75um / 100nm for fat "A" content (PY2075, includes 5.5-11 μm array)


Please inquire for further options.

Please note: the information contained in this document is subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. TPL640 128LT 256LT Pyreos Ltd, 14-16 The Curve, 32 Research Avenue North, Heriot Watt Research Park, Edinburgh EH14 4AP, UK. Tel: +44 131 322 0732, www.pyreos.com Copyright Pyreos Ltd 2019

¹Choice of filter windows available




Package Information



Circuit Diagram - 128 Array Readout

The amplification circuit consists of low-noise preamplifiers for each individual sensor elements, analogue switches and an output amplifier. The pre-amplifiers transform the signal charges measured at each sensor element into a conditioned voltage. The amplified signal is then passed to sample and hold, multiplexer output buffer for the read-out process. The digital inputs are CMOS compatible. A 10k NTC thermistor is integrated within the package to monitor the line sensor temperature.



Thermistor is NTC, 1%. For more details check ERTJZEG103FA Datasheet on Industrial Panasonic website.

Order Information

Contact: sales@pyreos.com Search terms: FPI Spectroscopy Etalon LVF FTIR Spectrometer-on-a-chip

Please note: the information contained in this document is subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. TPL640 128LT 256LT Pyreos Ltd, 14-16 The Curve, 32 Research Avenue North, Heriot Watt Research Park, Edinburgh EH14 4AP, UK. Tel: +44 131 322 0732, www.pyreos.com Copyright Pyreos Ltd 2019



Clock Parameters – 128 Array Readout


Similar to all pyroelectric sensors, the Pyreos thin-film pyroelectric line sensor array responds to and detects a change in infrared radiation intensity. It therefore requires a pulsed source of infrared radiation for measurement purposes.

| Parameter ¹ | Relative Value | Min. Values | Recommended Value |
|---|----------------------|-------------|-------------------|
| Chopping Frequency ² fch | | 10 Hz | 128 Hz |
| Read-out Clock CLK f _{CLK} = 2* f _{Ch} *268 | 1/t _{CLK} | 5.36 KHz | 69 KHz |
| Reset clock low-impulse duration tres | 1/2 t _{CLK} | 1.8 µs | 7.5 µs |
| Clock VVR high-impulse duration t _{VVR} | 2 t _{CLK} | 7.5 µs | 30 µs |
| Clock VDR high-impulse duration tvDR | 28 tclĸ | 200 μs | 400 µs |
| Clock VSH high-impulse duration tvsH | 1 tclk | 3.5 µs | 15 µs |

Maximum Settling Time at output tout is 1 µ second

Clock Diagram - 128 Array Readout

Pixel 1 is nearest pin 1 of the device.



Please note: the information contained in this document is subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. TPL640 128LT 256LT Pyreos Ltd, 14-16 The Curve, 32 Research Avenue North, Heriot Watt Research Park, Edinburgh EH14 4AP, UK. Tel: +44 131 322 0732, www.pyreos.com Copyright Pyreos Ltd 2019

¹ All values for VDD = 5 V, VD2 = 2.5V

 $^{^{2}}$ $t_{Ch low} = t_{Ch high}$

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Infrared Detectors category:

Click to view products by Pyreos manufacturer:

Other Similar products are found below:

HOA6517-001 HOA6540-001 HOA6542-001 HOA6571-001 HOA6572-001 HOA6489-050 HOA6531-001 HOA6532-001 HOA6546-001 HOA6570-001 HOA6573-001 HOA6536-001 HOA6548-001 HOA6544-001 G-TPCO-035 ZTP-135L ZTP-135BS ZTP-101T ZTP-115M ZTP-115-Std ZTP-135 ZTP-135SR ZTP-148SR ZTP-148SRC1 USEQFCEA500100 USEQFCEA455100 USEQFCEA391100 USEQFCEA448100 USEQFCSA448100 USEQFCSA500100 USEQFCSA435100 USEQFCSA550100 USEQFCSA455100 USEQFCSA391100 USEQFCSA391110 USEQFCSA391100 USEQFCSA391110 USEQFCSA