Energy Management
Energy Meter
Type EM21 72D



- **Certified according to MID Directive (option PF only): see “how to order” below**
- **Not-certified version available (option X): see “how to order” on the next page.**

- **Class B (kWh) according to EN50470-3**
- **Class 1 (kWh) according to EN62053-21**
- **Class 2 (kvarh) according to EN62053-23**
- **Accuracy ±0.5 RDG (current/voltage)**
- **Energy meter**
- **Instantaneous variables readout: 3 DGT**
- **Energies readout: 7 DGT**
- **System variables: W, var, PF, Hz, Phase-sequence.**
- **Single phase variables: V_{LL}, V_{LN}, A, PF**
- **Energy measurements: total kWh and kvarh**
- **TRMS measurements of distorted sine waves (voltages/currents)**
- **Self power supply**
- **Dimensions: 4-DIN modules and 72x72mm**
- **Protection degree (front): IP50**
- **Application adaptable display and programming procedure (Easyprog function)**
- **Easy connections management**
- **Detachable display**
- **Multi-use housing: for both DIN-rail and panel mounting applications**

Product Description

Three-phase energy meter with removable front LCD display unit. The same unit can be used either as a DIN-rail mounting or a panel mounting energy meter. This general purpose three-phase energy meter is suitable for both active and reactive energy metering for cost allocation but also for main electrical parameter measurement and retransmission (transducer function). Housing for DIN-rail mounting with IP50 (front) protection degree. Current measurements carried out by means of external current transformers and voltage measurements carried out either by means of direct connection or by means of potential transformers. EM21-72D is provided, as standard, with a pulsating output for active energy retransmission. In addition a 2-wire RS485 communication port is available as an option.

MID Certified according to MID Directive, Annex "B" + Annex "D" for legal metrology relevant to active electrical energy meters (see Annex MI-003 of MID). Can be used for fiscal (legal) metrology. Only the total active energy meter is certified according to MID.

How to order

EM21 72D AV5 3 X O X PF A D

- **Model**
- **Range code**
- **System**
- **Power supply**
- **Output 1**
- **Output 2**
- **Option**
- **Measurement**
- **Mounting type**

Type Selection

Range codes

AV5: 400V_{LL} AC, 5(6)A (CT connection)
AV6: 120/230V_{LL} AC 5(6)A (VT/PT and CT connections)

System

3: 3-phase, 4-wire

Power supply

X: Self power supply from 18V to 260VAC VLN, 50 Hz (connection VL1-N)

Options

PF: Certified according to MID Directive, Annex "B" + Annex "D" for legal metrology relevant to active electrical energy meters (see Annex MI-003 of MID). Can be used for fiscal (legal) metrology.

Output 1

O: Single static output (opto-mosfet)

Output 2

X: None
S: RS485 port

Mounting type

D: DIN-rail mounting
P: Panel mounting

Measurement

A: The power is always integrated -both in case of positive (imported) and negative (exported) power
B: only the positive (imported) power is integrated - no integration in case of negative (exported) power

NOTE: please check the availability of the needed code on the verification path diagram on left before order .



CARLO GAVAZZI

STANDARD

Not certified according to MID directive. Cannot be used for fiscal (legal) metrology.

How to order EM21 72D AV5 3 X O X X

- **Model**
- **Range code**
- **System**
- **Power supply**
- **Output 1**
- **Output 2**
- **Option**

Type Selection

Range codes

AV5: 400V_{LL} AC, 5(6)A or 1(6)A **(*)** (CT connection)
AV6: 120/230V_{LL} AC 5(6)A or 1(6)A **(*)** (VT/PT and CT connections)

System

3: balanced and unbalanced load: 3-phase, 4-wire; 3-phase, 3-wire; 2-phase, 3-wire; 1-phase, 2-wire

Power supply

X: Self power supply from 18V to 260VAC VLN, 45 to 65 Hz (connection VL1-N)

Options

X: none

Output 1

O: Single static output (opto-mosfet)

Output 2

X: None
S: RS485 port

(*) the range 1(6)A is available but not in compliance with the EN50470-3 standard.



NOTE: please check the availability of the needed code on the verification path diagram on left before order .

CARLO GAVAZZI

Input specifications

Rated inputs	System type: 3
Current type	Not isolated (shunt inputs). Note: the external current transformers can be connected to earth individually.
Current range (by CT)	AV5 and AV6: 5(6)A. The "1(6)A" range is available but not in compliance with the EN50470-3 standard.
Voltage (direct or by VT/PT)	AV5: 400VLL; AV6: 120/230VLL
Accuracy (Display + RS485) (@25°C ±5°C, R.H. ≤60%, 50Hz)	In: see below, Un: see below
AV5 model	In: 5A, Imax: 6A; Un: 160 to 260VLN (277 to 450VLL).
AV6 model	In: 5A, Imax: 6A; Un: 40 to 144VLN (70 to 250VLL).
Current AV5, AV6 models	From 0.002In to 0.2In: ±(0.5% RDG +3DGT). From 0.2In to Imax: ±(0.5% RDG +1DGT).
Phase-neutral voltage	In the range Un: ±(0,5% RDG +1DGT).
Phase-phase voltage	In the range Un: ±(1% RDG +1DGT).
Frequency	Range: 50Hz; resolution: ±1Hz
Active power	±(1%RDG +2DGT).
Power Factor	±[0.001+1%(1.000 - "PF RDG")].
Reactive power	±(2%RDG +2DGT).
Active energy	class B according to EN50470-1-3; class 1 according to EN62053-21.
Reactive energy	class 2 according to EN62053-23. In: 5A, Imax: 6A; 0.1 In: 0.5A. Start up current: 10mA.
Energy additional errors	
Influence quantities	According to EN62053-21, EN50470-1-3, EN62053-23
Temperature drift	≤200ppm/°C.
Sampling rate	1600 samples/s @ 50Hz, 1900 samples/s @ 60Hz
Display refresh time	1 second
Display	2 lines 1st line: 7-DGT, 2nd line: 3-DGT or 1st line: 3-DGT + 3-DGT, 2nd line: 3-DGT.
Type	LCD, h 7mm.
Instantaneous variables read-out	3-DGT.
Energies	Imported Total: 5+2, 6+1 or 7DGT
Overload status	EEE indication when the value being measured is exceeding the "Continuous inputs overload" (maximum measurement capacity)
Max. and Min. indication	Max. instantaneous variables: 999; energies: 9 999 999. Min. instantaneous variables: 0; energies 0.00.
LEDs	Red LED (Energy consumption) 0.001 kWh by pulse if CT ratio x VT ratio is <7; 0.01 kWh by pulse if CT ratio x VT ratio is ≥ 7.0 < 70.0; 0.1 kWh by pulse if CT ratio x VT ratio is ≥ 70.0 < 700.0; 1 kWh by pulse if CT ratio x VT ratio is ≥ 700.0;
Max frequency	16Hz, according to EN50470-3 Green LED (on the terminal blocks side) for power on (steady) and communication status: RX-TX (in case of RS485 option only) blinking.
Measurements	See "List of the variables that can be connected to:"
Method	TRMS measurements of distorted wave forms.
Coupling type	By means of external CT's.
Crest factor	In 5A: ≤3 (15A max. peak).
Current Overloads	
Continuous	6A, @ 50Hz.
For 500ms	120A, @ 50Hz.
Voltage Overloads	
Continuous	1.2 Un
For 500ms	2 Un
Current input impedance	
5(6)A	< 0.3VA
Voltage input impedance	
Self-power supply	Power consumption: <2VA.
Frequency	50 ± 5Hz/60 ± 5Hz.
Key-pad	Two push buttons for variable selection and programming of the instrument working parameters.

Output specifications

Pulse output	
Number of outputs	1
Type	Programmable from 0.01 to 9.99 kWh per pulses. Output connectable to the energy meters (kWh)
Pulse duration	T_{OFF} ≥120ms, according to EN62052-31. T_{ON} selectable (30 ms or 100 ms) according to EN62053-31
Output	Static: opto-mosfet.
Load	V_{ON} 2.5 VAC/DC max. 70 mA, V_{OFF} 260 VAC/DC max.
Insulation	By means of optocouplers, 4000 VRMS output to measuring inputs.
RS485	
Type	Multidrop, bidirectional (static and dynamic variables)
Connections	2-wire. Max. distance 1000m, termination directly on the instrument.
Addresses	247, selectable by means of the front keypad
Protocol	MODBUS/JBUS (RTU)
Data (bidirectional)	
Dynamic (reading only)	System and phase variables: see table “List of variables...”
Static (reading and writing)	All the configuration parameters.
Data format	1 start bit, 8 data bit, no parity,1 stop bit.
Baud-rate	9600 bits/s.
Driver input capability	1/5 unit load. Maximum 160 transceiver on the same bus.
Insulation	By means of optocouplers, 4000 VRMS output to measuring input.

Software functions

Password	Numeric code of max. 3 DGT; 2 protection levels of the programming data:
1st level	Password “0”, no protection;
2nd level	Password from 1 to 999, all data are protected
Programming lock	By means of potentiometer (back-side of the display module) it is possible to lock the access to all the configuration parameters.
System selection	
System 3-Ph.n unbalanced load	3-phase (4-wire) 3-phase (3-wire)
System 3-Ph.1 balanced load	• 3-phase (3-wire) one current and 3-phase to phase voltage measurements. Note: the phase to phase voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage. • 3-phase (4-wire) one current and 3-phase to neutral voltage measurements. Note: the phase to phase voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage. • 3-phase (2-wire) one current and 1-phase (L1) to neutral voltage measurement.
System 2-Ph	2-phase (3-wire)
System 1-Ph	1-phase (2-wire)
Transformer ratio	
VT (PT)	1.0 to 99.9 / 100 to 999 /
CT	1.0 to 99.9 / 100 to 999. The max CTxVT product for AV6 models is 2421 (X option) or 908 (PF option). The max CT ratio for MID applications (PF option) is 525.
Displaying	Up to 3 variables per page. See « Display pages », 3 different set of variables available (see « Display pages ») according to the metering function being selected.
Reset	By means of the front keypad: total energies (kWh, kvarh).
Easy connection function	Wrong phase detection and displaying. For all the display selections (except “D”) the current, power and energy measurement are independent on the current direction.

CARLO GAVAZZI

General specifications

Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C) according to EN62053-21 and EN62053-23.
Storage temperature	-30°C to +70°C (-22°F to 158°F) (R.H. < 90% non-condensing @ 40°C) according to EN62053-21 and EN62053-23.
Installation category	Cat. III (IEC60664, EN60664).
Insulation (for 1 minute)	4000 VRMS between measuring inputs and digital output.
Dielectric strength	4000 VRMS for 1 minute.
Noise rejection CMRR	100 dB, 48 to 62 Hz.
EMC	According to EN62052-11
Electrostatic discharges	15kV air discharge;
Immunity to irradiated Electromagnetic fields	Test with current: 10V/m from 80 to 2000MHz; Test without any current: 30V/m from 80 to 2000MHz;
Burst	On current and voltage measuring inputs circuit: 4kV
Immunity to conducted disturbances	10V/m from 150KHz to 80MHz
Surge	On current and voltage measuring inputs circuit: 6kV;
Radio frequency suppression	According to CISPR 22
Standard compliance	
Safety	IEC60664, IEC61010-1 EN60664, EN61010-1 EN62052-11
Metrology	EN62053-21, EN62053-23, EN50470-3
Pulse output	DIN43864, IEC62053-31
Approvals	CE, cULus listed, MID (PF option only)
Connections	Screw-type
Cable cross-section area	2.4 x 3.5 mm Min./Max. screws tightening torque: 0.4 Nm / 0.8 Nm
Housing	
Dimensions (WxHxD)	72 x 72 x 65 mm
Material	Noryl PA66, self-extinguishing: UL 94 V-0
Mounting	Panel and DIN-rail
Protection degree	
Front	IP50
Screw terminals	IP20
Weight	Approx. 400 g (packing included)

Power supply specifications

Self power supply	18 to 260VAC (48-62Hz). Across input “VL1” and “N”	**Power consumption**	≤2VA/1W

Insulation between inputs and outputs

	Measuring Inputs	Opto-Mosfet output	Communication port	Self power supply
Measuring Inputs	-	4kV	4kV	0kV
Opto-Mosfet output	4kV	-	-	4kV
Communication port	4kV	-	-	4kV
Self power supply	0kV	4kV	4kV	-

NOTE: all the models have, mandatorily, to be connected to external current transformers.

Accuracy (According to EN50470-3 and EN62053-23)

kWh, accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current



MID "Annex MI-003" compliance (PF option only)

Accuracy	0.9 Un ≤ U ≤ 1.1 Un; 0.98 fn ≤ f ≤ 1.02 fn; fn: 50Hz; cosφ: 0.5 inductive to 0.8 capacitive. Class B I st: 0.01A; I min: 0.05A; I tr: 0.25A; I n: 5A I max: 6A.
Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)

EMC compliance	E2
Mechanical compliance	M2
Protection degree	in order to achieve the protection against dust and water required by the norms harmonized to MID, the meter must be used only installed in IP51 (or better) cabinets.

Used calculation formulas

Phase variables

Instantaneous effective voltage

$$V_{1N} = \sqrt{\frac{1}{n} \cdot \sum_{1}^{n} (V_{1N})_i^2}$$

Instantaneous active power

$$W_1 = \frac{1}{n} \cdot \sum_{1}^{n} (V_{1N})_i \cdot (A_1)_i$$

Instantaneous power factor

$$\cos\varphi_1 = \frac{W_1}{VA_1}$$

Instantaneous effective current

$$A_1 = \sqrt{\frac{1}{n} \cdot \sum_{1}^{n} (A_1)_i^2}$$

Instantaneous apparent power

$$VA_1 = V_{1N} \cdot A_1$$

Instantaneous reactive power

$$\mathrm{var}_1 = \sqrt{(VA_1)^2 - (W_1)^2}$$

System variables

Equivalent three-phase voltage

$$V_\Sigma = \frac{V_1 + V_2 + V_3}{3} \cdot \sqrt{3}$$

Voltage asymmetry

Three-phase active power

$$W_\Sigma = W_1 + W_2 + W_3$$

Three-phase apparent power

$$VA_\Sigma = \sqrt{W_\Sigma^2 + \mathrm{var}_\Sigma^2}$$

Three-phase power factor (TPF)

$$\cos\varphi_\Sigma = \frac{W_\Sigma}{VA_\Sigma}$$

Energy metering

$$k\,\mathrm{var}hi = \int_{t1}^{t2} Qi(t)dt \cong \Delta t \sum_{n1}^{n2} Qnj$$

$$kWhi = \int_{t1}^{t2} Pi(t)dt \cong \Delta t \sum_{n1}^{n2} Pnj$$

Where:

i= considered phase (L1, L2 or L3)
P= active power; **Q**= reactive power;
$\mathbf{t_1}$, $\mathbf{t_2}$ =starting and ending time points of consumption recording; **n**= time unit;**Δt**= time interval between two successive power consumptions;
$\mathbf{n_1}$, $\mathbf{n_2}$ = starting and ending discrete time points of consumption recording

CARLO GAVAZZI

List of the variables that can be connected to:

- RS485 communication port
- Pulse outputs (only “energies”)

No	Variable	1-ph. sys.	2-ph. sys.	3-ph. 4-wire balanced system	3-ph. 3-wir balanced system	3-ph. 4-wire unbalanced system	3-ph. 3-wir unbalanced system	Notes
1	kWh	x	x	x	x	x	x	Total
2	kvarh	x	x	x	x	x	x	Total
3	V L-N sys (1)	o	x	x	x	x	x	sys=system (∑)
4	V L1	x	x	x	x	x	x	
5	V L2	o	x	x	x	x	x	
6	V L3	o	o	x	x	x	x	
7	V L-L sys (1)	o	x	x	x	x	x	sys=system (∑)
8	V L1-2	o	x	x	x	x	x	
9	V L2-3	o	o	x	x	x	x	
10	V L3-1	o	o	x	x	x	x	
11	A L1	x	x	x	x	x	x	
12	A L2	o	x	x	x	x	x	
13	A L3	o	o	x	x	x	x	
14	VA sys (1)	x	x	x	x	x	x	sys=system (∑)
15	VA L1 (1)	x	x	x	x	x	x	
16	VA L2 (1)	o	x	x	x	x	x	
17	VA L3 (1)	o	o	x	x	x	x	
18	var sys	x	x	x	x	x	x	sys=system (∑)
19	var L1 (1)	x	x	x	x	x	x	
20	var L2 (1)	o	x	x	x	x	x	
21	var L3 (1)	o	o	x	x	x	x	
22	W sys	x	x	x	x	x	x	sys=system (∑)
23	W L1 (1)	x	x	x	x	x	x	
24	W L2 (1)	o	x	x	x	x	x	
25	W L3 (1)	o	o	x	x	x	x	
26	PF sys	x	x	x	x	x	x	sys=system (∑)
27	PF L1	x	x	x	x	x	x	
28	PF L2	o	x	x	x	x	x	
29	PF L3	o	o	x	x	x	x	
30	Hz	x	x	x	x	x	x	
31	Phase sequence	o	o	x	x	x	x	

(x) = available
(o) = not available (zero indication on the display)
(1) = Variable available only through the serial communication port RS485

Display pages

No	1st variable (1st half-line)	2nd variable (2nd half-line)	3rd variable (2nd line)	Note	Applications			
					A	B	C	D
	Phase sequence			The phase sequence triangle appears in any page only if there is a phase reverse	x	x	x	x
1	Total kWh		W sys		x	x	x	x
2	Total kvarh		kvar sys			x	x	x
3		PF sys	Hz	Indication of C, -C, L, -L depending on the quadrant		x	x	x
4	PF L1	PF L2	PF L3	Indication of C, -C, L, -L depending on the quadrant			x	x
5	A L1	A L2	A L3				x	x
6	V L1-2	V L2-3	V L3-1				x	x
7	V L1	V L2	V L3				x	x

Additional available information on the display

Type	1st line	2nd line	note
Meter information 1	Y. 2007	r.A0	Year of production and firmware release
Meter information 2	value	LEd (kWh)	KWh per pulse of the LED
Meter information 3	SYS [3P.n]	value	System type and connection type
Meter information 4	Ct rAt.	value	Current transformer ratio
Meter information 5	Ut rAt.	value	Voltage transformer ratio
Meter information 6	PuLSE (kWh)	value	Pulse output: kWh per pulse
Meter information 7	Add	value	Serial communication address
Meter information 8	value	Sn	Secondary address (M-bus protocol)

List of selectable applications

	Description	Notes
A	Active energy meter **	Active energy measurement with some minor parameters
B	Active and reactive energy meter **	Active and reactive energy measurement with some minor parameters
C	Full set of variables **	Full set of available variables can be displayed (default selection, except PFB option)
D	Full set of variables +*	Full set of available variables can be displayed + (default in PFB option)

Notes:
+ Only in “D” application the actual direction of the current is considered.
* Not available with option PF A. ** Not available with option PF B.

One instrument with double mounting capability



... as DIN-rail mounting meter.

By means of the patented detachable display it is possible to configure the same instrument either as a panel mounting meter or...



CARLO GAVAZZI

Wiring diagrams



(6A) Self power supply, system type selection: 3P.n

3-ph, 4-wire, unbalanced load **Fig. 1**



3-CT connection

3-ph, 4-wire, unbalanced load **Fig. 2**



3-CT and 3-VT/PT connections

(6A) System type selection: 3P.n

3-ph, 3-wire, unbalanced load **Fig. 3**



3-CT connection

3-ph, 3-wire, unbalanced load **Fig. 4**



3-CT and 3-VT/PT connections

3-ph, 3-wire, unbalanced load **Fig. 5**



2-CT connections (ARON)

(6A) Self power supply, system type selection: 3P.1

3-ph, 3-wire, unbalanced load **Fig. 6**



2-CT and 3-VT/PT connections ARON

3-ph, 3/4-wire, balanced load **Fig. 7**

1-CT connection



NOTE: It is measured only the voltage between (9) and (10) which is repeated for the other phases.

3-ph, 3-wire, balanced load **Fig. 8**



1-CT and 3-VT/PT connections

NOTE: For a correct power supply of the instrument, the neutral must always be connected.

CARLO GAVAZZI

Wiring diagrams

(6A) System type selection: 2P

2-ph, 3-wire **Fig. 9**



2-CT connection

2-ph, 3-wire **Fig. 10**



2-CT and 2-VT/PT connections

(6A) System type selection: 1P

1-ph, 2-wire **Fig. 11**



1-CT connection

Static output wiring diagram

(6A) System type selection: 1P

1-ph, 2-wire **Fig. 12**



1-CT and 1-VT connections

Opto-mosfet



VDC/AC supply

RS485 port wiring diagram

RS485 port



RS485 NOTE: additional devices provided with RS485 are connected as per the picture above. The termination of the serial output is carried out only on the last instrument of the network, by means of a jumper between (B+) and (T).

Front panel description



1. **Keypad**
   To program the configuration parameters and scroll the variables on the display.
2. **Pulse output LED**
   Red LED blinking proportional to the energy being measured.
3. **Display**
   LCD-type with alphanumeric indications to display all the measured variables.
4. **Connections**
   Screw terminal blocks for instrument wiring.
5. **Green LED**
   Lit when power supply is available

Dimensions (DIN configuration)



Dimensions and panel cut out (72x72 panel mounting configuration)



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for carlo gavazzi ***manufacturer:***

Other Similar products are found below :

CTD10S16005AXXX CTD2X1005AXXX FPD01SBS200 FPD06SCC200 FPT01SBS200 MP3100 PD30CNG02NPM5RT PD30CNP06NPM5DU PH18CNT20PASA G21305521700 G21960005700 G34296470800 G34304443115 G34396470115 G34404443824 G89111010 GAD1213024 GP67630107 PPB01CM23N PPC01DM23 PS21M-US11PR-M0L PS21R-NT11N7-YK0 GT150S105A GT225S100A GT400S400A GT800S800A GT95L36A GT95L50A GT95L95A A208024060 A82-10100 RAP48A3 AD2000 RCP1100324DC RCP800224VDC REC2R48D30GKE REC3B48A30GKE RGC1A60D62KGU RGC1FS60D30GGE RJ1A23D45E RJ1P23MBT50ECV RJ1P48V30E DFC01DB48 DHA51CM24S8 RMD2H24MA30 RMD3H24LA40 DPA02CM40 DPB71CM48 DPC01DM48400HZ AQ1018