
Assembly Instructions-C17 HN - Typical Clamp











Stripping dims. inches (millimeters)

Amphenol			
Part #	а	b	С
82-804	1.00 (25.4)	.781 (19.8)	.219 (5.6)
82-856	.680 (17.3)	.34 (8.6)	.09 (2.3)
82-324	1.59 (40.4)	.875 (22.2)	.718 (18.2)


Place nut, gland, and gasket, with "V" groove toward nut, over cable and strip cable to dimensions as shown in table.


Comb out braid and fold out.

Pull braid wires forward and taper toward center conductor. Place clamp over braid and push back against cable jacket.

Fold back braid wires as shown, trim to proper length and form over clamp as shown. Solder contact to center conductor.

Insert cable and parts into connector body, make sure sharp edge of clamp seats properly in gasket. Tighten nut. Recommended Torque: 35-40 in lbs.





Stripping dims. inches (millimeters)

Amphenol			
Part #	a	b	С
16750	.799 (20.2)	.594 (15.1)	.203 (5.8)
82-816-1000	.843 (21.4)	.625 (15.9)	.218 (5.5)

Push nut, washer and gasket over cable jacket.

Cut cable even to dimensions shown in table.


Push clamp over copper braid, flush against cable jacket. Cut exposed copper braid so that approximately 3/16 remains and fan over clamp. Trim braid even with end of taper. Cut cable dielectric (dim c) from end of cable cut. Tin exposed conductor.





Solder contact pin to conductor. Do not overheat dielectric. Do not use excess solder. Wipe clean; see that dielectric is free from solder, resin and foreign material. Tighten nut to recommended torque 35-40 in lbs securely with wrench.

Assembly Instructions-C20 HN - Typical Clamp









Cut end of cable even. Push nut, washer and gasket over cable jacket.

Stripping dims. inches (millimeters)

Amphenol Part #	а	b	С
82-38	1.0 (25.4)	.781 (19.8)	.219 (5.6)

Remove vinyl jacket .798" (20.3) from end of cable. For double shield cables, remove vinyl jacket 1 3/16" (30.2) from end of cable.

Push clamp over copper braid, flush against cable jacket. Cut exposed copper braid so that approximately .219" (5.6) remains and fan over clamp. Trim braid even with end of taper. Cut cable dielectric to Dim c.

Solder contact pin to conductor. Do not overheat dielectric. Do not use excess solder. Wipe clean; see that dielectric is free from solder, resin and foreign material.

Taper dielectric with AMPHENOL 103-301 (MX-103/U) trimming tool. When tapering dielectric of cable for plug assembly, push contact stop of tool to bottom of slot. Tool will stop cutting when shoulder of contact butts against stop. Cable will be properly tapered when end of center contact is flush with end of trimmer body.

Apply small amount of Dow Corning DC-4 Silicone Compound or equivalent (per MIL-S-8660) on tapered surface of dielectric. Insert assembly into connector body. Tighten nut securely with wrench.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for amphenol manufacturer:

Other Similar products are found below:

CTV06RGQF-17-52P CTVPS00RGF-23-6P-LC JTPQ00RT-16-35P(453) GC835TY2S CF-509621-29P BF8-1218-31SV-Y70 TVP00RGW-23-6SA(LC) RNJ27CI1535P014 10-553998-139 21-033388-031 10-507142-843 GTS06G-32-7S GTC06-36-78PX-023 ACC02E28-51S-003-B30-LC TV06RL-13-35SD-LC TV06RL-13-35SD TV06RL-13-98SD-LC TV06RL-13-98SD GTC08AF32-15SX-B30-LC GTC06G32-76PZ TVP00RW-23-53AD 100-007-213-002-001 5M30-61 JT07RT-22-14PB-453 FSPP-103-00-004 360031 10-037090-161 10-541504-001 10-580902-409 TV97RW-9-9S(S15) TVPS00RGF-9-5P-LC TVPS00RGF-9-5PA-LC TVP00RGQW-21-75P-LC TV06RW-25-90AE 97-3108B16S-5PW-417 PT06J20-24SW 97-3108B16S-4PY-417 97-3108B16S-4PX-417 97-3108B16S-5PY-417 97-3108B16S-4PW-417 CS-DSDMDB37MF-025 97-3108B16S-5PZ-417 TV06RW-25-46AE TVS07RF-21-16AA TVS07RF-21-39BA 60261626SNCOND1 SE00TVW09 CF-5A9013-04N CF-6A4615-06N GTS01-22-22PX-025-116