




HAKKO FX-888

can provide the solution to all your needs.

Lead-free soldering, reducing costs, cell production, improving quality, etc.



HAKKO CORPORATION

HEAD OFFICE
 4-5, SHIOKUSA 2-CHOME, NANIWA-KU, OSAKA, 556-0024 JAPAN
 TEL:+81-6-6561-3225 FAX:+81-6-6561-8466
<http://www.hakko.com> E-mail:sales@hakko.com

OVERSEAS AFFILIATES

U.S.A.
 AMERICAN HAKKO PRODUCTS, INC.
 28520 N. AVE. WILLIAMS VALENCIA, CA 91355, U.S.A.
 TEL: (661) 294-0090 FAX: (661) 294-0096
 Toll Free (800)88-HAKKO
<http://www.hakkousa.com>

HONG KONG
 HAKKO DEVELOPMENT CO., LTD.
 ROOM 1504, EASTERN HARBOUR CENTRE,
 28 HOI CHAK STREET, QUARRY BAY, HONG KONG.
 TEL: 2811-5588 FAX: 2590-0217
<http://www.hakko.com.hk>
 E-mail:info@hakko.com.hk

SINGAPORE
 HAKKO PRODUCTS PTE., LTD.
 1, GENTING LINK #02-04, PERFECT INDUSTRIAL
 BUILDING, SINGAPORE 349518
 TEL: 6748-2277 FAX: 6744-0033
<http://www.hakko.com.sg>
 E-mail:sales@hakko.com.sg

Please access to the following address for the other Sales affiliates.
<http://www.hakko.com>

Specifications and design are subject to change without notice.
 Copyright HAKKO Corporation. All right reserved.

HAKKO FX-888

SOLDERING STATION






HAKKO FX-888

can provide the solution to all your needs.

Lead-free soldering, reducing costs, cell production, improving quality, etc.



HAKKO FX-888 SOLDERING STATION



HAKKO CORPORATION

HEAD OFFICE
4-5, SHIOKUSA 2-CHOME, NANIWA-KU, OSAKA, 556-0024 JAPAN
TEL:+81-6-6561-3225 FAX:+81-6-6561-8466
<http://www.hakko.com> E-mail:sales@hakko.com

OVERSEAS AFFILIATES

U.S.A.
AMERICAN HAKKO PRODUCTS, INC.
28520 N. AVE. WILLIAMS VALENCIA, CA 91355, U.S.A.
TEL: (661) 294-0090 FAX: (661) 294-0096
Toll Free (800)88-HAKKO
<http://www.hakkousa.com>

HONG KONG
HAKKO DEVELOPMENT CO., LTD.
ROOM 1504, EASTERN HARBOUR CENTRE,
28 HOI CHAK STREET, QUARRY BAY, HONG KONG.
TEL: 2811-5588 FAX: 2590-0217
<http://www.hakko.com.hk>
E-mail:info@hakko.com.hk

SINGAPORE
HAKKO PRODUCTS PTE., LTD.
1, GENTING LINK #02-04, PERFECT INDUSTRIAL
BUILDING, SINGAPORE 349518
TEL: 6748-2277 FAX: 6744-0033
<http://www.hakko.com.sg>
E-mail:sales@hakko.com.sg

Please access to the following address for the other Sales affiliates.
<http://www.hakko.com>

Specifications and design are subject to change without notice.
Copyright HAKKO Corporation. All right reserved.


CA00319Gblb001 Dec. 2008



Heater output increased to 65W

Output has been increased by 30% compared to that of the HAKKO 936. The conventional tip design was reviewed and the shape was improved to provide more efficient heat transfer from the heating element. As a result, the thermal recovery time to 350°C is 20 seconds faster, and the drop in tip temperature during continuous


Thermal recovery graph



Test criteria
 Measurement method: A thermocouple is mounted on the tip and the tip temperature is measured when soldering Ø1.6mm x 5mm solder to paper phenol copper board once every 3 seconds.
 Board: Paper phenol copper board.
 Temperature setting: 350°C
 Solder: Lead-free solder (Sn/Ag/Cu) Ø1.6 mm x 5mm

work is reduced (refer to the thermal recovery graph), enabling the time for performing the same work to be shortened (refer to the graph showing performance comparison) and work efficiency to be greatly increased.

HAKKO FX-888 performance comparison graph with conventional station



Test criteria
 Measurement method: Thermocouples are mounted on the tip and the soldered portion on the board, and the time until the soldered portion reaches 250°C is measured for 5 points.
 Board: Paper phenol copper board.
 Temperature setting: 350°C
 Solder: Lead-free solder (Sn/Ag/Cu) Ø0.5mm

Design completely novel

Positioning the bottom contact points as close to the base outside perimeter as possible provides a stability making it possible to use it stably even in confined spaces.



Station: Blue & yellow Iron holder: Blue & yellow

Design improved for easier use



The corners on the iron holder base were rounded to prevent them from coming in contact with hand when storing the soldering iron. Further, a protective cap installed in the iron receptacle is provided to reduce sounds when storing the iron.

Downsized to save space.



Comparison in size between FX-888 and HAKKO936.

The new FX-888 realizes space savings of approx. 50% in mounting area in comparison with conventional stations. It enables working space to be secured, which is important factor with the introduction of cell production.

Thermal calibration (CAL) screwdriver is included as a standard accessory

The calibration (CAL) screwdriver (resin) is stored in the bottom of station as a standard accessory. This enables temperature compensation to be adjusted easily and reduces the possibility of damage to the calibration volume.



Replacement tip

The thermal conduction rates of T18 series tips have been improved by reviewing the shapes which can transfer heat to the tip end efficiently. Please be sure to use T18 series tips for FX-888 station to maintain its high performance.

<p>T18-B</p>	<p>T18-C1</p>	<p>T18-CSF25</p> <p>Tinned on the soldering surface only.</p>	<p>T18-D08</p>
<p>T18-I</p>	<p>T18-CF1</p> <p>Tinned on the soldering surface only.</p>	<p>T18-C3</p>	<p>T18-D12</p>
<p>T18-K</p>	<p>T18-CF15</p> <p>Tinned on the soldering surface only.</p>	<p>T18-CF3</p> <p>Tinned on the soldering surface only.</p>	<p>T18-D16</p>
<p>T18-SB</p>	<p>T18-C2</p>	<p>T18-C4</p>	<p>T18-D24</p>
<p>T18-C05</p>	<p>T18-CF2</p> <p>Tinned on the soldering surface only.</p>	<p>T18-CF4</p> <p>Tinned on the soldering surface only.</p>	<p>T18-D32</p>

3 types of cleaning methods available in one iron holder

The following 3 cleaning methods can be performed by the cleaning tools included with the iron holder.

	<p>Cleaning sponge: Residual solder and flux adhering on the tip can be wiped off by the sponge soaked with water.</p>
	<p>Cleaning wire (option): Residual solder and flux adhering on the tip is removed by inserting the tip into a thin metallic wire. This cleaning wire leaves an appropriate amount of solder on the tip end, which prevents the tip from being oxidized. Use without water prevents the tip temperature from decreasing rapidly or tip oxidation from being promoted.</p>

	<p>Rubber cleaner: Residual solder and flux adhering on the tip can be wiped off on the silicone rubber cleaner. Use without water prevents the tip temperature from decreasing rapidly or tip oxidation from being promoted.</p>
	<p>The iron holder base is provided with a detachable waste collecting plate, which improves its maintainability. * Cleaning wire is an optional part.</p>

•Specifications

Model name	HAKKO FX-888
Main body color choices	Silver; Black; Red; Blue & yellow
Power consumption	70W
Temperature range	200 to 480°C
Temperature stability	±1°C
Temperature setting lock type	Dial screw type
Station	
Voltage	26V
Dimensions	95(w) x 118(h) x 136(d)mm
Weight (w/o cord)	Approx. 1.3kg
Iron	
Power consumption	65W(26V)
Resistance between tip and ground	< 2Ω
Tip to ground potential	< 2mV
Cord	1.2m
Total length (w/o cord)	190mm
Weight (w/o cord)	44g
Iron holder	Silver; or Blue & yellow

•Replacements/optional parts


Part number	Name/Description
FX8801-01	Soldering iron FX-8801/26V-65W
FH800-01BY	Iron holder FH-800/Blue & yellow
FH800-01SV	Iron holder FH-800/Silver
A1559	Cleaning sponge
A1561	Cleaning wire
B3474	Rubber cleaner
A1560	Heating element/26V-65W
B3469	Tip enclosure
B1785	Nut
B2022	Nipple
B3466	Calibration screwdriver

•Packing list
 FX-888 station • FX-8801 Iron • Iron holder (with rubber cleaner and sponge) * Cleaning wire is an optional part.
 Hex wrench • Calibration screwdriver • Instruction manual

Heater output increased to 65W

Output has been increased by 30% compared to that of the HAKKO 936. The conventional tip design was reviewed and the shape was improved to provide more efficient heat transfer from the heating element. As a result, the thermal recovery time to 350°C is 20 seconds faster, and the drop in tip temperature during continuous


Thermal recovery graph



Test criteria
 Measurement method: A thermocouple is mounted on the tip and the tip temperature is measured when soldering Ø1.6mm x 5mm solder to paper phenol copper board once every 3 seconds.
 Board: Paper phenol copper board.
 Temperature setting: 350°C
 Solder: Lead-free solder (Sn/Ag/Cu) Ø1.6 mm x 5mm

work is reduced (refer to the thermal recovery graph), enabling the time for performing the same work to be shortened (refer to the graph showing performance comparison) and work efficiency to be greatly increased.

HAKKO FX-888 performance comparison graph with conventional station



Test criteria
 Measurement method: Thermocouples are mounted on the tip and the soldered portion on the board, and the time until the soldered portion reaches 250°C is measured for 5 points.
 Board: Paper phenol copper board.
 Temperature setting: 350°C
 Solder: Lead-free solder (Sn/Ag/Cu) Ø0.5mm

Design completely novel

Positioning the bottom contact points as close to the base outside perimeter as possible provides a stability making it possible to use it stably even in confined spaces.



Station: Blue & yellow Iron holder: Blue & yellow

Design improved for easier use



The corners on the iron holder base were rounded to prevent them from coming in contact with hand when storing the soldering iron. Further, a protective cap installed in the iron receptacle is provided to reduce sounds when storing the iron.

Downsized to save space.



Comparison in size between FX-888 and HAKKO936.

The new FX-888 realizes space savings of approx. 50% in mounting area in comparison with conventional stations. It enables working space to be secured, which is important factor with the introduction of cell production.

Thermal calibration (CAL) screwdriver is included as a standard accessory

The calibration (CAL) screwdriver (resin) is stored in the bottom of station as a standard accessory. This enables temperature compensation to be adjusted easily and reduces the possibility of damage to the calibration volume.



Replacement tip

The thermal conduction rates of T18 series tips have been improved by reviewing the shapes which can transfer heat to the tip end efficiently. Please be sure to use T18 series tips for FX-888 station to maintain its high performance.

<p>T18-B</p>	<p>T18-C1</p>	<p>T18-CSF25</p>	<p>T18-D08</p>
<p>T18-I</p>	<p>T18-CF1</p>	<p>T18-C3</p>	<p>T18-D12</p>
<p>T18-K</p>	<p>T18-CF15</p>	<p>T18-CF3</p>	<p>T18-D16</p>
<p>T18-SB</p>	<p>T18-C2</p>	<p>T18-C4</p>	<p>T18-D24</p>
<p>T18-C05</p>	<p>T18-CF2</p>	<p>T18-CF4</p>	<p>T18-D32</p>

3 types of cleaning methods available in one iron holder

The following 3 cleaning methods can be performed by the cleaning tools included with the iron holder.

<p>Cleaning sponge: Residual solder and flux adhering on the tip can be wiped off by the sponge soaked with water.</p>	<p>Cleaning wire (option): Residual solder and flux adhering on the tip is removed by inserting the tip into a thin metallic wire. This cleaning wire leaves an appropriate amount of solder on the tip end, which prevents the tip from being oxidized. Use without water prevents the tip temperature from decreasing rapidly or tip oxidation from being promoted.</p>
---	--

<p>Rubber cleaner: Residual solder and flux adhering on the tip can be wiped off on the silicone rubber cleaner. Use without water prevents the tip temperature from decreasing rapidly or tip oxidation from being promoted.</p>	<p>The iron holder base is provided with a detachable waste collecting plate, which improves its maintainability. * Cleaning wire is an optional part.</p>
--	--

•Specifications

Model name	HAKKO FX-888
Main body color choices	Silver; Black; Red; Blue & yellow
Power consumption	70W
Temperature range	200 to 480°C
Temperature stability	±1°C
Temperature setting lock type	Dial screw type
Station Voltage	26V
Station Dimensions	95(w) x 118(h) x 136(d)mm
Station Weight (w/o cord)	Approx. 1.3kg
Iron Power consumption	65W(26V)
Iron Resistance between tip and ground	< 2Ω
Iron Tip to ground potential	< 2mV
Iron Cord	1.2m
Iron Total length (w/o cord)	190mm
Iron Weight (w/o cord)	44g
Iron Iron holder	Silver; or Blue & yellow

•Replacements/optional parts

Part number	Name/Description
FX8801-01	Soldering iron FX-8801/26V-65W
FH800-01BY	Iron holder FH-800/Blue & yellow
FH800-01SV	Iron holder FH-800/Silver
A1559	Cleaning sponge
A1561	Cleaning wire
B3474	Rubber cleaner
A1560	Heating element/26V-65W
B3469	Tip enclosure
B1785	Nut
B2022	Nipple
B3466	Calibration screwdriver


•Packing list
 FX-888 station • FX-8801 Iron • Iron holder (with rubber cleaner and sponge) * Cleaning wire is an optional part.
 Hex wrench • Calibration screwdriver • Instruction manual



HAKKO FX-888

can provide the solution to all your needs.

Lead-free soldering, reducing costs, cell production, improving quality, etc.



HAKKO CORPORATION

HEAD OFFICE
4-5, SHIOKUSA 2-CHOME, NANIWA-KU, OSAKA, 556-0024 JAPAN
TEL:+81-6-6561-3225 FAX:+81-6-6561-8466
<http://www.hakko.com> E-mail:sales@hakko.com

OVERSEAS AFFILIATES

U.S.A.
AMERICAN HAKKO PRODUCTS, INC.
28520 N. AVE. WILLIAMS VALENCIA, CA 91355, U.S.A.
TEL: (661) 294-0090 FAX: (661) 294-0096
Toll Free (800)88-HAKKO
<http://www.hakkousa.com>

HONG KONG
HAKKO DEVELOPMENT CO., LTD.
ROOM 1504, EASTERN HARBOUR CENTRE,
28 HOI CHAK STREET, QUARRY BAY, HONG KONG.
TEL: 2811-5588 FAX: 2590-0217
<http://www.hakko.com.hk>
E-mail:info@hakko.com.hk

SINGAPORE
HAKKO PRODUCTS PTE., LTD.
1, GENTING LINK #02-04, PERFECT INDUSTRIAL
BUILDING, SINGAPORE 349518
TEL: 6748-2277 FAX: 6744-0033
<http://www.hakko.com.sg>
E-mail:sales@hakko.com.sg

Please access to the following address for the other Sales affiliates.
<http://www.hakko.com>

Specifications and design are subject to change without notice.
Copyright HAKKO Corporation. All right reserved.

HAKKO FX-888 SOLDERING STATION



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [hakko manufacturer](#):

Other Similar products are found below :

[A1006](#) [FT8002-01](#) [PTG-2T1G0008](#) [HFJ11-1G06ERL](#) [HFJ12-E2450ER-L11RL](#) [TG110-RP55N5LF](#) [B3048](#) [T30-D06](#) [T12-D12](#) [FM203-15](#)
[N1-L10](#) [A1014](#) [N1-20](#) [T12-D24](#) [FM2023-04](#) [FT8003](#) [G3-1601](#) [T31-01JS02](#) [T33-BC4](#) [T33-BC5](#) [T33-D24](#) [N50B-05](#) [N50B-06](#) [950-CK](#)
[A1013](#) [A1067](#) [A1187B](#) [A1379](#) [B1309](#) [B1787](#) [C1392B](#) [A1553](#) [A1554](#) [FX300-03](#) [FT300](#) [918-T-1.6D/P](#) [C1148B/P](#) [111-SA](#) [B5045](#) [B5046](#)
[N60-09](#) [T12-1612](#) [C1148B](#) [HFJ11-1G11E-L11RL](#) [TG41-2006NRLTR](#) [T30-KU](#) [T12-BC2](#) [B3474](#) [N1-08](#) [N51-01](#)