PRODUCT DESCRIPTION

The SP 400-EB features an enhanced black LCD and 200mV d.c. measurement range with auto-zero and auto-polarity. Decimal points are user selectable. The SP 400-EB features a negative rail generator which enables the meter to measure a signal referenced to its own power supply GND. Enhanced contrast negative mode LCD with LED backlighting ensures excellent readability under all light conditions. The module is easily fitted into the panel, using the fixing clip provided. The module's low cost means it will suit high and low volume applications. The design of the panel meter's housing ensures splash proofing using the supplied seal.

FEATURES

- 9.75mm (0.38") Digit Height
- 200mV d.c. Full Scale Reading
- 5V Operation
- · Auto-zero and Auto-polarity
- Programmable Decimal Points
- Enhanced black LCD with LED Backlighting
- · Low Battery Warning
- Splash Proof

TYPICAL APPLICATIONS

- Precision Instrumentation Systems
- Power Supply Monitoring
- Test Boxes
- Panel-Mount Indication
- Low Power Voltage Measurement



ORDERING INFORMATION

	Stock Number
Blue backlighting	SP 400-EB-B
Green backlighting	SP 400-EB-G
Magenta backlighting	SP 400-EB-M
Orange backlighting	SP 400-EB-O
Purple backlighting	SP 400-EB-P
Red backlighting	SP 400-EB-R
White backlighting	SP 400-EB-W
Yellow backlighting	SP 400-EB-Y

ELECTRICAL SPECIFICATIONS

Specification		Min.	Тур.	Max.	Unit
Accuracy (overall error) *			0.1		% (± 1 count)
Linearity				±1	count
Sample rate			2.5		samples/sec
O perating temperature range		0		50	°C
Temperature stability			100		ppm/°C
Supply voltage		4.75	5	7.5**	V d.c.
Supply current at 5V d.c.	Display on		40	80***	mA
	Display disabled		350		μΑ
Input leakage current (Vin	= 0V)		1	10	pA

^{*} To ensure maximum accuracy, re-calibrate periodically.

Unless otherwise noted, specifications apply at T_A =25°C, V_{supply} =5Vd.c. (f_{dext} =48kHz) and are tested with the module configured for single ended input mode.

SAFETY

To comply with the Low Voltage Directive (LVD 93/68/EEC), input voltages to the module's pins must not exceed 60Vdc. The user must ensure that the incorporation of the panel meter into the user's equipment conforms to the relevant sections of BS EN 61010 (Safety Requirements for Electrical Equipment for Measuring, Control and Laboratory Use).

LASCAR ELECTRONICS LTD. MODULE HOUSE, WHITEPARISH, WILTSHIRE SP5 2SJ, UK TEL: +44 (1794) 884567

UK TEL: +44 (1794) 884567 FAX: +44 (1794) 884616 E-mail: sales@lascar.co.uk LASCAR ELECTRONICS INC.
4258 WEST 12th STREET,
ERIE,
PA 16505,
USA
TEL: +1 (814) 835 0621
FAX: +1 (814) 838 8141
Fmail us-sale-getronics.com


LASCAR ELECTRONICS (HK) LTD.
8th FLOOR, CHINA AEROSPACE CENTRE.
13 HO IBUN ROAD,
KWUN TONG, KOWLOON,
HONG KONG
TEL: +852 2389 6535
E- mail: saleshkgalscar.com.hk





^{**} Operation of the meter beyond the maximum supply voltage rating may cause permanent damage to the meter.


^{***} An external series resistor is required above 5V, see Applications.


^{****} This specification linearly derates to 50mA @ 50°C.











PIN FUNCTIONS

- 1. V+ Positive power supply to the meter.
- 2. GND 0V power supply to the meter.
- 3. BL- Connect to GND (pin 2).

N.B. Display may be switched offto reduce supply current via an in-line switch.

For meter supply voltages above 5V, add a series resistor Rs.

See Applications for suitable circuit diagrams.

- 4. INH Positive measuring input.
- 5. INL Negative measuring input.
- 6. DP1 Connect to V+ to display DP1 (199.9).
- 7. DP2 Connect to V+ to display DP2 (19.99).
- 8. DP3 Connect to V+ to display DP3 (1.999).
- 9. V- N.C. (Inversion of V+).

Note:

A negative supply (V-) is generated internally and mirrors the positive supply. For example: if V+ is +5V, then the internally generated V- is -5V. When measuring with the input referenced to the same supply rail as that of the panel meter, then the limitations on the input range are (V- + 1.5V) to (V+ - 1.5V).

Solder Links:

LCOM Normally Open. Connects INL to COM.


LBAT Normally Closed. Cut this link to disable the low battery warning sign.




SCALING

Two external resistors Ra and Rb may be used to alter the full scale reading (FSR) of the meter - see table. The meter will have to be re-calibrated by adjusting the calibration potentiometer on the rear of the module.


	FSR	Ra	Rb
	2V	910k	100k
Voltage	20V	1M	10k
	200V	1M	1k
	2000V*	1M	100R
	200 μΑ	OR	1k
Current	2mA	0R	100R
	20mA	0R	10R
	200mA	0R	1R






APPLICATIONS

Do not connect more than one meter to the same power supply if the meters cannot use the same signal ground. Taking any input beyond the power supply rails will damage the meter.




Measuring a single ended input voltage referenced to supply, i.e. the input voltage and the meter's power supply share the same OV rail. Ensure solder link LCOM is open.




Measuring an input voltage referenced to a floating supply, i.e. the input voltage and the meter's power supply are isolated from each other. Ensure solder link LCOM is closed.

Disabling the display to reduce supply current



Measuring a current from a circuit which is floating with respect to the DPM's supply, i.e. the current and the meter's power supply are isolated from each other.
Ensure solder link LCOM is closed.



Measuring a single ended input voltage referenced to supply, i.e. the input voltage and the meter's power supply share the same 0V rail. Ensure solder link LCOM is open.

Specifications liable to change without prior warning

SP 400-EB

Issue 3

08/2012

S.L.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for lascar manufacturer:

Other Similar products are found below:

EL-USB-1-PRO EL-USB-5 EL-USB-4 SP400-BLUE SGD21-B EL-WIFI-TP+-PROBE-G S43-RS485 EL-MOTE-WALL-BRACKET EL-MOTE-T-PLUS SGD24-M-IP EL-GFX-1 EM32-1B-LED EMV1200 DPM3AS-BL EL-GFX-DTC EL-USB-RT EL-WIFI-ALERT DTM 995B DPM125-BL PSU30205 PSU203 DPM942-FPSI EL-CC-2-001 PK10 EL-CC-2-005 PK10 S70-TP EL-SIE-1 EL-SIE-1+ EL-SIE-2+ EL-SIE-6+ SGD24-M-IP420 WIRELESS ALERT TP EL-SGD43-ATP EL-GFX-2 EM32-1B EL-USB-ACT EL-CC-2-002 PK10 EL-MOTE-TH EL-USB-CO EMT1900 EL-ENVIROPAD-TC DPM702S SGD 43-A DK+ EL-WIFI-TH EL-USB-2-LCD+ EL-WIFI-21CFR-TP+ EL-GFX-DTP+ EL-CC-2-004 PK10 EL-USB-5+ EL-USB-TP-LCD-PROBE-G EL-CC-1-003 PK10