

## Through-Beam Sensor with Visible Red LED

E3Z-TA

Visible Beam Allows Visual Confirmation of the Detection Spot, for Easy Installation and Maintenance

- Built-in amplifier
- Mutual interference protection filter included in product offering
- Long sensing distance: 10 M
- Prewired or connector models
- Light-ON/Dark-ON switch-selectable
- Noise Immunity due to IC chip design
- IP67, CE approved



CE

# **Ordering Information**

#### ■ Standard Models

Sensing method	Appearance	Connection method	Sensing distance	Part number	
				NPN output	PNP output
Through-beam		Prewired (2 m)		E3Z-T61A	E3Z-T81A
		Connector	10 m	E3Z-T66A	E3Z-T86A
			1 1 1		

### ■ Accessories (Order Separately)

#### Slit

Slit width	Sensing distance (typical)	Minimum sensing target (typical)	Quantity	Part number
0.5 mm dia.	35 mm	0.2 mm dia.	One for the emitter	E39-S65A
1 mm dia.	150 mm	0.4 mm dia.	receiver	E39-S65B
2 mm dia.	550 mm	0.7 mm dia.		E39-S65C
0.5×10 mm	700 mm	0.2 mm dia.		E39-S65D
1×10 mm	1.5 m	0.5 mm dia.		E39-S65E
2×10 mm	3.5 m	0.8 mm dia.		E39-S65F

#### **Mutual Interference Protection Filter**

Sensing distance	Dimensions	Comments	Quantity	Part number
3 m	10.8 10.8 7.4 1.4 1.2 0.2		Two filters for the emitter and two for the receiver (total of four)	E39-E11

#### ■ Brackets (All E3Z Models Use Common Brackets)

To order, you'll find the appropriate brackets for the E3Z-TA when you refer to the basic E3Z Photoelectric Sensor data sheet on Omron's web site @www.omron.com/oei, or refer to the Sensing Products Catalog.

#### ■ M8 Connectors (All E3Z Models Use Common Connectors)

To order M8 Connectors, see the basic E3Z Photoelectric Sensor data sheet on Omron's web site @www.omron.com/oei, or refer to the Sensing Products Catalog.


# **Specifications**

### ■ Ratings/Characteristics


Item	Sensing method	Through-beam		
	NPN output	E3Z-T61A/T66A		
	PNP output	E3Z-T81A/T86A		
Sensing distance		10 m		
Standard sensing targe	et	Opaque: 12-mm dia. min.		
Directional angle		Both emitter and receiver: 3° to 5°		
Light source (wave len	gth)	Red LED (700 nm)		
Power supply voltage		12 to 24 VDC ±10%		
Current consumption		Emitter: 15 mA Receiver: 20 mA		
Control output		Load power supply voltage: 26.4 VDC max. Load current: 100 mA max. (Residual voltage: 1 V max.) Open collector output (NPN or PNP depending on model) L-ON/D-ON switch-selectable		
Circuit protection		Protection from load short-circuit and reversed power supply connection		
Response time		Operation or reset: 1 ms max.		
Sensitivity adjustment		One-turn potentiometer		
Ambient illumination (receiver side)		Incandescent lamp: 3,000 lux max. Sunlight: 10,000 lux max.		
Ambient temperature		Operating: -25°C to 55°C (-13°F to 131°F) Storage: -40°C to 70°C (-40°F to 158°F) with no icing or condensation		
Ambient humidity		Operating: 35% to 85%/Storage: 35% to 95% (with no condensation)		
Insulation resistance		20 MΩ min. at 500 VDC		
Dielectric strength		1,000 VAC, 50/60 Hz for 1 min		
Vibration resistance		10 to 55 Hz, 1.5-mm double amplitude or 300 m/s <sup>2</sup> for 2 hours each in X, Y, and Z direction		
Shock resistance		500 m/s <sup>2</sup> 3 times each in X, Y, and Z directions		
Degree of protection		IP67 (IEC60529)		
Connection method		Prewired cable (standard length: 2 m) or M8 connector model		
Indicator		Operation indicator (orange) Stability indicator (green) Emitter has power indicator (orange) only.		
Weight (packed state)	Prewired cable (2 m)	Approx. 120 g (4.23 oz.)		
	Connector	Approx. 30 g (1.06 oz.)		
Material	Case	PBT (polybutylene terephthalate)		
	Lens	Methacrylate resin		
Accessories		Instruction manual		

# **Engineering Data**

# ■ Parallel Operating Range (Typical) E3Z-T□A




# ■ Receiver Output vs. Distance (Typical) E3Z-T□A




# Operation


### ■ NPN Output



### **■ PNP Output**



#### Structure of Sensor I/O Connector



Classification	Wire color	Connector pin No.	Use
DC	Brown	1	Power supply (+V)
	White	2	Pin 2 is not used.
	Blue	3	Power supply (0 V)
	Black	4	Output


## **Dimensions**


Unit: mm (inch)

#### Sensors

#### **Prewired Through-beam Models**


E3Z-T61A E3Z-T81A





# Through-beam Models with Connector E3Z-T66A

E3Z-T86A



#### ■ Accessories

#### Brackets, M8 Connectors, and Slits

For dimensions of Brackets, M8 Connectors, or Slits, see the Dimensions Section in the basic E3Z Photoelectric Sensor data sheet on Omron's web site @www.omron.com/oei, or refer to the E3Z in Omron's Sensing Products Catalog.

### **Precautions**

To ensure safe sensor operation, please follow these precautions.

#### Wiring

#### **Power Supply Voltage**

Make sure that the power supply to the Sensor is within the rated voltage range.

#### **Load Short-Circuiting**

Do not short-circuit the load, or the Sensor may be damaged.

#### **Polarity**

Correct polarity wiring is required to prevent damage to the sensor.

#### **Connection without Load**

Do not connect the power supply to the Sensor when no load is connected, or the internal elements may explode or burn.

#### **■** Operating Environment

Do not use the Sensor in locations with explosive or flammable gas.

#### Settings


#### **Power Reset Time**

When the E3Z-TA is turned ON, there is a 100 ms delay time before operation. If the load and the Sensor are connected to independent power supplies, be sure to turn ON the sensor *before* turning ON the load.

#### ■ Connections


#### M8 Metal Connector


- Turn OFF the power before disconnecting the sensor.
- Remove the connector cover before connecting or disconnecting the metal connector.
- Secure the connector cover by hand. Do not use pliers, or the connector may be damaged.
- The proper tightening torque range is between 0.3 and 0.4 N·m.



#### ■ Mounting and Adjusting Slits


- Hook the upper protruding portion of the Slit to the upper indented mounting portion of the Sensor and adjust the position of the Slit so that the Slit will be parallel to the lens side of the Sensor. (See area 1, in the illustration below.)
- Then, press the lower protruding portion of the Slit onto the indented mounting portion of the Sensor until the Slit snaps in. (See area 2, shown below.)





#### **Removal Method**

- Press the upper portion of the Slit. (See area 1, shown below.)
- Then, disconnect the lower protruding portion of the Slit from the Sensor and remove the Slit. (See area 2, shown below.)



ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

# OMRON

**OMRON ELECTRONICS LLC** 

One East Commerce Drive Schaumburg, IL 60173

1-800-55-OMRON

#### **OMRON ON-LINE**

Global - http://www.omron.com USA - http://www.omron.com/oei Canada - http://www.omron.com/oci

#### OMRON CANADA. INC.

885 Milner Avenue Scarborough, Ontario M1B 5V8

416-286-6465

Cat. No. CEDSAX4

11/01

Specifications subject to change without notice

Printed in USA

## **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Photoelectric Sensors category:

Click to view products by Omron manufacturer:

Other Similar products are found below:

E3JM-DS70R4T-US E3L2DC4 E3RA-DN12 2M E3RA-DP12 2M E3S5LE4S E3S-AD38 E3S-CR11 5M E3SCT11D5M E3SCT11M1J03M E3T-CT22S E3T-FD12R E3T-SL14R E3T-SL24 5M E3T-ST12R E3T-ST24 2M E3X-CN02 E3X-CN11 5M E3X-CN21 10M E3ZM-B66 E3ZM-CL81H 2M E3Z-T62 2M NJL5303R-TE1 PB10CNT15PO PD60CNX20BP FZS CX-491-P-J CX-491-Z XUM2BKCNL2T E3S-LS20XB4 5M E3S-LS3PW 2M E3T-FD14R E3T-SL21 5M E3T-SL21M E3T-ST11R E3T-ST12 5M E3X-DA41-S-M1J 0.3M E3X-DAB6 E3X-DAG8 E3ZM-B86