


Phase Asymmetry, Failure, Sequence, Under and Over Voltage plus Restart Delay

Td

Installation work must be carried

out by qualified personnel.



INSTALLATION AND SETTING ٠

REFORE INSTALLATION ISOLATE THE SUPPLY

- Connect the unit as required. The Connection Diagram below shows a typical installation, whereby the supply to a load is
- being monitored by the Phase monitoring relay. If a fault should occur (i.e. fuse blowing), the relay will de-energise and assuming control of the external Contactor, de-energise the Contactor as well.
- Only connect the Neutral if available and 4-wire monitoring is required.

Applying power.

- Set the "Nominal (Un)" 🕄 voltage selector to match that of the voltage being monitored Set the "Asymmetry %" 🙆 adjustment to maximum.
- Set the "Delay (t)" 🗿 and "Restart delay" 🗿 adjustments to minimum.
- Apply power and the green "Power supply" 1 LED will illuminate. The red LED 2 will illuminate and relay energise after the short delay period (Td).
- Refer to the troubleshooting table if the unit fails to operate correctly


Setting the unit (with power applied).

- Assuming all phases are perfectly balanced it should be possible to set the "Asymmetry (%)" adjustment to minimum which will ensure that it will detect the smallest of changes in the phase voltages. However, if large changes in phase voltages are likely, then the "Asymmetry (%)" setting should be increased.
- The formula used for calculating phase asymmetry is shown on the right at the bottom of the Technical Specification Set the "Delay (t)" and "Restart delay" as required. (Note that the delay "t" is only effective should any phases exceed the set trip point. However, if the supply drops below the 2nd under voltage trip level, any set time delay is automatically cancelled and the relay de-energises immediately).

Troubleshooting.

vs the status of the unit during a particular fault condition

Supply fault	Green LED 🜖	Red LED 😢	Relay	
Phase or neutral missing	LED's flas	n alternately	De-energised	
Phase or neutral restored (during restart timing)	On	Flashing (x2)	De-energised for delay (Td)	
Phases reversed (no delay)	Flashing	Off	De-energised	
Under or Over voltage condition (during timing)	On	Flashing	Energised for delay (t)	
Under or Over voltage condition (after timing)	On	Off	De-energised	
Voltage returned from Under/Over volt. (during restart timing)	On	Flashing (x2)	De-energised for delay (Td	
Phase asymmetry trip point exceeded (during timing)	On	Flashing	Energised for delay (t)	
Phase asymmetry trip point exceeded (after timing)	On	Off	De-energised	
Phase asymmetry below trip point (during restart timing)	On	Flashing (x2)	De-energised for delay (Td	
Phases < fixed under trip level [2]	On	Off	De-energised	





Broyce Control Ltd., Pool Street, Wolverhampton, West Midlands WV2 4HN. England Tel: +44 (0) 1902 773746 Fax: +44 (0) 1902 420639 Email: sales@broycecontrol.com Web: www.broycecontrol.com The Information provided in this literature is believed to be accurate (subject to change without prior notice); however, use of such information shall be entirely at the user's own risk

¹Only when 4-wire monitoring selected

Type: LPMP/2

Supply/monitoring vol	tage Un	3-wire monitorin	3-Wire	4-wire mor	itoring	4-Wire		
(L1, L2, L3, (N)):		380, 400, 415V A	c	220, 230, 2	40V AC			
Frequency range:		48 - 63Hz						
Supply variation:		243- 540V AC (L>	L)					
Overvoltage category:		III (IEC 60664)						
Rated impulse withsta	nd voltage:	4kV (1.2/50µS) IE	C 60664					
Power consumption (r	nax.):	2.5VA						
Monitoring mode:		Asymmetry, Under and Over voltage						
Trip levels:								
	Under [2]:	Fixed ± 2% see be						
	Under: Over:	Fixed – 90% of Ur Fixed – 110% of U						
	Asymmetry:	2 - 8%	m					
Measuring ranges:	Asymmetry.	Nominal (Un)	Under [2]	Under	Ove	r		
weasuring ranges.	3-wire (L>L)	380V	243V	342V	418			
	5 1110 (2-2)	400V	256V	360V	440			
		415V	265V	374V	457			
	4-wire (L>N)	220V	140V	198V	242			
		230V	147V	207V	253	v		
		240V	153V	216V	264	v		
Hysteresis:		\approx 2% of trip level	(factory set)					
Setting accuracy:		± 3%						
Repeat accuracy:		\pm 0.5% at constar	it conditions					
Immunity from micro	power cuts:	<50ms						
Response time (t _r):		≈ 50ms						
Time delay (t):		0.2 – 10s (± 5%)						
/	(- 1)	Note: actual dela	y (t) = adjustal	ble delay + resp	onse tim	е		
Restart/Power on dela Reset time:	iy (1d):	1s – 500s 50 – 100ms						
Power on indication:		Green LED						
Relay status indication	:	Red LED						
Ambient temperature	:	-20 to +60°C						
Relative humidity:		+95% max.						
Output (15, 16, 18 / 2	5 26 28)	DPDT relay						
Output (15, 16, 18 / 25, 26, 28) : Output rating:		AC1		250V 5A (1	250VA)			
		AC15						
		DC1						
Electrical life:		≥ 150,000 ops at	rated load					
Dielectric voltage:		2kV AC (rms) IEC	2kV AC (rms) IEC 60947-1					
Rated impulse withsta	nd voltage:	4kV (1.2/50µS) IE	C 60664					
Housing:		Orange flame ret	ardant UL94					
Weight:		90g						
Mounting option:		On to 35mm symmetric DIN rail to BS EN 60715 or direct surface mounting via 2 x M3.5 or 4BA screws using the black						
					ising the	ріаск		
Terminal conductor siz	70	clips provided on ≤ 2 x 2.5mm ² soli		e unit.				
			-					
Approvals:		Conforms to IEC. EMC:						
N/-+		Immunity: EN 610	00-6-2 Emissi	ons: EN 61000-	6-4			
Note: "L>L" has the same me "Asymmetry" formula		e to phase" and "L>N	I", the same as	"phase to neu	tral"			
	М	aximum deviation fr						
A	symmetry = 🗕	Vave	x1	00%				

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Broyce Control manufacturer:

Other Similar products are found below :

LART 12-230V AC/DC LXCVR 230V LBVR/A 12-24VDC LMCCR-10A LESW 12-230V AC/DC