



DX-500R Accessory and I/O Configuration Reference Guide (Website)


STANDARD ACCESSORIES




1700-0014
Power Adapter



7045-9020
Foot Switch




FTKIT
Air Hose Fitting



TSD800-6

OPTIONAL ACCESSORIES

DX-ECABLE



SPARE PARTS

Part Number	Description
2900-0015	LCD, 20 x 4 with Back Light
7049-9010	PCBA, DX-500
TSD500-30	Pressure Regulator, 0-100 psi
TSD650-21	Solenoid Valve
535	Coupler, Panel mount
TSD1121-23	Knob, Pressure Regulator
TSD1135-26	6 Pin Din Socket

I/O Configuration and End of Cycle Switch

Upon completion of a dispense cycle, an open collector circuit closes and remains closed until the next dispense cycle. This circuit can be used to signal back to a host computer, start another device in sequence, or drive any other operations that need to be tied to the completion of the dispense cycle. Upon closure, (end of dispense cycle), power from an external source is allowed to pass through the circuit to operate a 5 to 24 VDC load. Power consumption must not exceed 250 mA. The load could be a relay, solenoid, counter, LED, or any device that will operate within a 5 to 24 VDC range and a maximum of 250 mA.

