Autonics TCD210018AB

30 mm Diameter Incremental Rotary Encoders



E30 Series

PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Features

- Compact Ø 30 mm housing, Ø 4 mm solid shaft
- · Easy installation in tight or limited spaces
- · Low shaft moment of inertia
- Various resolutions: up to 3000 pulses per revolution
- · Various control output options
- Power supply: 5 VDC= \pm 5%, 12 24 VDC= \pm 5%

Safety Considerations

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ▲ symbol indicates caution due to special circumstances in which hazards may occur.

⚠ Warning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime / disaster prevention devices, etc.) ailure to follow this instruction may result in personal injury, economic loss or fire.
- 02. Do not use the unit in the place where flammable / explosive / corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.

Failure to follow this instruction may result in explosion or fire.

- 03. Install on a device panel to use.
 - Failure to follow this instruction may result in fire.
- 04. Do not connect, repair, or inspect the unit while connected to a power
 - Failure to follow this instruction may result in fire.
- 05. Check 'Connections' before wiring.

Failure to follow this instruction may result in fire.

06. Do not disassemble or modify the unit.

Failure to follow this instruction may result in fire.

⚠ Caution Failure to follow instructions may result in injury or product damage.

- 01. Use the unit within the rated specifications.
 - Failure to follow this instruction may result in fire or product damage.
- 02. Do not short the load.

Failure to follow this instruction may result in fire.

03. Do not use the unit near the place where there is the equipment which generates strong magnetic force or high frequency noise and strong **alkaline, strong acidic exists.**Failure to follow this instruction may result in product damage.

Cautions during Use

- Follow instructions in 'Cautions during Use'.
- Otherwise, It may cause unexpected accidents.
 5VDC==, 12 24 VDC== power supply should be insulated and limited voltage / current or Class 2, SELV power supply device.
- For using the unit with the equipment which generates noise (switching regulator, inverter, servo motor, etc.), ground the shield wire to the F.G. terminal.

 Ground the shield wire to the F.G. terminal.
- When supplying power with SMPS, ground the F.G. terminal and connect the noise canceling capacitor between the 0 V and F.G. terminals.
- · Wire as short as possible and keep away from high voltage lines or power lines, to prevent inductive noise.
- For Line driver unit, use the twisted pair wire which is attached seal and use the receiver for RS-422A communication.
- Check the wire type and response frequency when extending wire because of distortion of waveform or residual voltage increment etc. by line resistance or capacity between lines.
- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Altitude max. 2,000 m
- Pollution degree 2
- Installation category II

Cautions during Installation

- Install the unit correctly with the usage environment, location, and the designated specifications.
- Do not load overweight on the shaft.
- Do not put strong impact when insert a coupling into shaft. Failure to follow this instruction may result in product damage
- When fixing the product or coupling with a wrench, tighten under 0.15 N m.
 If the coupling error (parallel misalignment, angular misalignment) between the shaft increases while installation, the life cycle of the coupling and the encoder can be
- Do not apply tensile strength over 30 N to the cable.

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.



4: Ø 4 mm Resolution

2 Shaft outer diameter

Number: Refer to resolution in 'Specifications'

Output phase

3: A, B, Z 6: A, \overline{A} , B, \overline{B} , Z, \overline{Z}

V: Voltage output L: Line driver output O Power supply

5:5 VDC== ±5% 24: 12 - 24 VDC== ±5% Connection

No mark: Axial cable type C: Axial cable connector type

N: NPN open collector output

Product Components

- Product
- · Instruction manual
- Bolt \times 4
- Coupling \times 1

Sold Separately

• M17 connector cable: CID6S-□, CID9S-□

Connections

- Unused wires must be insulated.
- The metal case and shield cable of encoders must be grounded (F.G.).
- F.G. (Frame Ground) must be grounded separately.

■ Totem pole / NPN open collector / Voltage output

Pin	Color	Function	Pin	Color	Function
1	Black	OUTA	4	Brown	+V
2	White	OUT B	5	Blue	GND
3	Orange	OUT Z	6	Shield	F.G.



■ Line driver output

Pin	Color	Function	Pin	Color	Function
1	Black	OUTA	5	White	OUT B
2	Red	OUTĀ	6	Gray	OUT B
3	Brown	+V	7	Orange	OUT Z
4	Blue	GND	8	Yellow	OUT Z
			9	Shield	F.G.







Inner Circuit

• Output circuits are identical for all output phase.


■ Totem pole output




■ NPN open collector output



■ Voltage output




■ Line driver output




Output Waveform

- \bullet The rotation direction is based on facing the shaft, and it is clockwise (CW) when rotating to the right.
- Phase difference between A and B: $\frac{T}{4} \pm \frac{T}{8}$ (T = 1 cycle of A)

■ Totem pole / NPN open collector / Voltage output





■ Line driver output

Specifications


Model	E30S4-□- 3-T-□-□	E30S4-□- 3-N-□-□	E30S4-□- 3-V-□-□	E30S4-□- 6-L-5-□		
Resolution	100 / 200 / 360 / 500 / 1,000 / 1,024 / 3,000 PPR model					
Control output	Totem pole output	NPN open collector output	Voltage output	Line driver output		
Output phase	A, B, Z	A, B, Z	A, B, Z	$A, \overline{A}, B, \overline{B}, Z, \overline{Z}$		
Inflow current	\leq 30 mA	≤ 30 mA	-	≤ 20 mA		
Residual voltage	≤ 0.4 VDC==	≤ 0.4 VDC==	≤ 0.4 VDC==	≤ 0.5 VDC==		
Outflow current	\leq 10 mA	-	≤ 10 mA	≤ -20 mA		
Output voltage (5 VDC==)	≥ (power supply -2.0) VDC==	-	-	≥ 2.5 VDC==		
Output voltage (12 - 24 VDC==)	≥ (power supply -3.0) VDC==	=	=	=		
Response speed 01)	≤1 µs		$\leq 1 \mu s^{02)} \leq 2 \mu s^{03)}$	≤ 0.5 µs		
Max. response freq.	300 kHz					
Max. allowable revolution 04)	5,000 rpm					
Starting torque	≤ 0.002 N m					
Inertia moment	\leq 20 g·cm ² (2 × 10 ⁻⁶ kg·m ²)					
Allowable shaft load	Radial: ≤ 2 kgf, Thrust: ≤ 1 kgf					
Unit weight	≈ 80 g					
Approval	C€ KK EMI	C€ KEHE	C € ĽK ERIC	EAC		

- 01) Based on cable length: 2 m, I sink: 20 mA
- 02) Based on power supply: 5 VDC==, output resistance: 820 Ω
- 03) Based on power supply: 12 24 VDC = , output resistance: 4.7 kΩ
 04) Select resolution to satisfy Max. allowable revolution ≥ Max. response revolution [max.response revolution (rpm) = $\frac{\text{max.response frequency}}{\text{resolution}} \times 60 \text{ sec}$]


Model	E30S4-□- 3-T-□-□	E30S4-□- 3-N-□-□	E30S4-□- 3-V-□-□	E30S4-□- 6-L-5-□		
Power supply	5 VDC= ± 5% (rip 12-24 VDC= ± 59	5 VDC= ± 5% (ripple P-P: ≤ 5%)				
Current consumption	≤ 80 mA (no load)		≤ 50 mA (no load)		
Insulation resistance	≥ 100 MΩ (500 VDC== megger)					
Dielectric strength	Between the charging part and the case: 750 VAC \sim 50 / 60 Hz for 1 min.					
Vibration	1 mm double amplitude at frequency 10 to 55 Hz in each X, Y, Z direction for 2 hours					
Shock	≲ 50 G					
Ambient temp.	-10 to 70 °C, storage: -25 to 85 °C (no freezing or condensation)					
Ambient humi.	35 to 85%RH, storage: 35 to 90%RH (no freezing or condensation)					
Protection rating	IP50 (IEC standard)					
Connection	Axial cable type / cable connector type model					
Cable spec.	Ø 5 mm, 5-wire (Line driver output: 8-wire), shield cable cable type: 2 m, cable connector type: 250 mm					
Wire spec.	AWG24 (0.08 mm, 40-core), insulator diameter: Ø 1 mm					
Connector spec.	M17 6-pin plug type M17 9-pin plu type					

Dimensions

- Unit: mm, For the detailed drawings, follow the Autonics website.
- Following items are based on cable type. Refer to 'Specifications' for detailed specifications of cable, wire and connector.



■ Coupling



- Parallel misalignment: \leq 0.25 mm Angular misalignment: \leq 5° End-play: \leq 0.5 mm

Sold Separately: M17 Connector Cable

 \bullet For more information, refer to the M17 Connector Cable Product Manual.

	ı —				
Appearance	Power supply	Connector 1	Connector 2	Length	Model
	DC	M17 (Socket- Female) 6-pin	2 m 5 m	2 m	CID6S-2
				5 m	CID6S-5
			o-wire	10 m CID6S-10	CID6S-10
				15 m	CID6S-15

Appearance	Power supply	Connector 1	Connector 2	Length	Model
	DC	M17 (Socket- Female) 9-pin		2 m C	CID9S-2
			9-wire	5 m	CID9S-5
				10 m CID9S-10	CID9S-10

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Encoders category:

Click to view products by Autonics manufacturer:

Other Similar products are found below:

6-1393048-0 6-1393048-5 62AG22-H5-P 700-09-36 1393047-3 2-1393047-2 25LB22-G-Z T101-5C3-111-M1 385001M0439
385001M0216 V23401H1409B101 V23401T8002B802 V23401U6019B609 62B11-LPP-040C 62HS22-H0-040S 700-16-16 700-24-24
V23401D1001B102 3-1393048-1 288T220R161A2 1-1879391-5 GH65C11-N-SO 1393047-1 702-01-24 703-20-00 62V22-02-P
62D15-02-140S 61K128-075 EC21C1520402 E6F-AG5C 720 2M 62B22-SPP-030C 60016-005 31215-003 01039-2677 ACZ11BR2E20FD1-20CZ-0546 DXM510-2000S002 01002-2133 01002-9375 01002-9572 01026-476 01039-1102 01039-1981 01070-1315 01072-513
01080-056 01084-089 01094-017 01102-031 GHM912-2500-004 MKITMEF9445/004