

Congratulations on your purchase of the Connective Peripherals S1-A-7001 RS232 to CANbus adapter. Getting started is quick and easy:

General Installation

- Detailed installation instructions, port information and mechanical details are in the S1-A-7001 datasheet. This can be downloaded from: <http://www.connectiveperipherals.com>.
- To begin, connect the RS232 cable to your Host RS232 connector and the S1-A-7001. If the host RS232 is configured for DTE, like most PC-based COM ports, a straight-through 9-pin D-Sub cable can be used. External power is required and supplied through the CANbus connector as noted in the pin-out table at the end of this document.

CAN Firmware

- The S1-A-7001 comes with Connective Peripherals CANbus firmware pre-loaded from the factory. From time-to-time, Connective Peripherals will update the firmware and make it available on the web. Updated firmware can be obtained from: <http://www.connectiveperipherals.com>. Included with the firmware download will be a copy of EASYBoot, a utility that programs the firmware into the S1-A-7001.
- When updating with newly downloaded firmware, it is first necessary to place the S1-A-7001 adapter in Boot-loader mode:
 - Start a terminal program, such as HyperTerminal. Connect to the COM port and issue the “B” command:

© Connective Peripherals Pte Ltd

S1-A-7001 – Quick Start Guide

- B<CR>
- The S1-A-7001 will respond with:
 - Entering Boot Mode
Boot:>
- Close the COM port connection.
- Start EASYBoot and follow the on-screen instructions to update or verify the firmware.

The CANbus DE-9P (DS102-1) pin-out is as follows:

Pin	Function
1	No Connect
2	CAN_L = CANbus Low Side
3	GND = Signal Ground
4	No Connect
5	GND = Signal Ground
6	GND = Signal Ground
7	CAN_H = CANbus High Side
8	No Connect
9	External Power (+6VDC to +15VDC @ 150mA max, 40mA typical)

© Connective Peripherals Pte Ltd



USB2-F-1001 – Quick Start Guide

Revision History:

Version 1.0	2009-05-22	Initial release
Version 1.1	2019-03-25	Re-branding to reflect the migration of the product from EasySync to Connective Peripherals name (changed logo, copyright, internal hyperlinks)

© Connective Peripherals Pte Ltd

Clearance Number : CP#030

Document Reference Number: CP_000040

S1-A-7001_Quick_Start_Guide Version 1.1

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [RS-232 Interface IC category](#):

Click to view products by [Connective Peripherals manufacturer](#):

Other Similar products are found below :

[062191EB](#) [CH438L](#) [LT1039CN](#) [MAX3386ECPWR](#) [TRS222IDWR](#) [MAX232INE4](#) [MAX3232CPW](#) [MAX204CWE+](#) [TRS3243EIDWR](#)
[TRS3232EIDWR](#) [SN65C3232EDWR](#) [ADM208ARZ-REEL](#) [LT1780CSW#PBF](#) [LT1237CSW#PBF](#) [LT1281AISW#PBF](#) [LTC1337CSW#PBF](#)
[LT1180ACN#PBF](#) [LTC1343CGW#PBF](#) [LT1237CNW#PBF](#) [LT1039CN#PBF](#) [LT1032CSW#PBF](#) [LT1130ACSW#PBF](#) [LTC1349ISW#PBF](#)
[LT1032ISW#PBF](#) [LTM2882IY-3#PBF](#) [LT1140ACN#PBF](#) [LTC1384IG#PBF](#) [LTC1383CS#PBF](#) [LT1280AIN#PBF](#) [LT1080ISW#PBF](#)
[LTC2845IG#PBF](#) [LTC1383CN#PBF](#) [LTC2845CG#PBF](#) [LTC2846CG#PBF](#) [LTC1384CG#PBF](#) [LT1781IS#PBF](#) [LT1081IN#PBF](#)
[SN75188DE4](#) [LTC1350CNW](#) [MAX3209EEUU+T](#) [AD7306AR](#) [AD7306ARZ](#) [AD7306JNZ](#) [AD7306JRZ](#) [ADM3311EARSZ-REEL](#)
[ADM3310EACPZ-REEL7](#) [ADM3202ARUZ-REEL7](#) [ADM101EARMZ-REEL7](#) [ADM1181AAN](#) [ADM1181AANZ](#)