

# 3000 VA pure sine wave UPS, LCD display, 3 x Schuko + 3 x C13 outputs, USB, black

EG-UPS-PS3000-02

## ULTIMATE DEFENCE

- Pure sine wave output
- Provide backup power Prevents data loss
- Protects your sensitive and valuable equipment
- Perfect support for solar panel installations and other sensitive equipment that requires pure sinewave input
- Compact and reliable ideal for home and small office use



## Features

- Uninterruptable power supply with pure sine wave output
- USB interface
- Automatic AC voltage regulation (AVR)
- Intelligent overload and short-circuit protection
- Audible and visual alarms
- LCD display and LED status indication
- Internal battery with overcharge and over-discharge protection

## Packaging

Q'ty in crtn, pcs	1
Crtn volume, CUM	0.08752128
Crtn weight, kgs	30.93
Individual package size LxWxH:	592x320x462 mm
Carton size LxWxH:	592x320x462 mm
Country of origin	CN
Barcode	8716309124805
Customs code	8504408590

## Package contents

- UPS
- Power input cord

## Specifications

Type: line interactive with pure sine wave  
 Waveform: sine, 5% distortion at linear load, PF > 0.8  
 Input: AC 220V±25%, 50Hz/60Hz ±10%  
 Output: AC 220V±10%, 50Hz/60Hz ±1% (AC 220V±10% at inverter mode)  
 Switching time: up to 10 ms typically  
 Backup time: 10...30 mins (depends on the load)  
 Battery: 151 x 65 x 94 mm, sealed lead-acid 12V/9Ah, F2 terminals x 4 pcs  
 Charge time: up to 90% after 6-8 hours  
 Sockets: C14 input, 6 outputs (3x IEC C13, 3x Schuko)  
 Interface communication: USB + RJ45; optional slots: dry contacts / SNMP

## System requirements

In order to work correctly, the connected load should be at least 5% of the maximum capacity of the UPS. For example, a 700 W UPS needs at least a connected load of 35 W to work.

## Certificates



## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [UPS - Uninterruptible Power Supplies](#) category:*

*Click to view products by [Gembird](#) manufacturer:*

Other Similar products are found below :

[SMART-1400-RM](#) [UPS1500ITSIT](#) [QUINT4-UPS/24DC/24DC/20/EI](#) [QUINT4-UPS/24DC/24DC/40/EI](#) [QUINT4-UPS/24DC/24DC/10/US](#)  
[QUINT4-UPS/24DC/24DC/20/US](#) [QUINT4-UPS/24DC/24DC/40/US](#) [2789910000](#) [2786240000](#) [5AVRZP2000](#) [51942](#) [50717](#) [50719](#) [EG-](#)  
[UPS-035](#) [51945](#) [50725](#) [50721](#) [50177](#) [EG-UPS-PS3000-02](#) [51940](#) [50720](#) [UPS-RACK-1200](#) [5AVRZP5000](#) [50722](#) [5AVRZP1000](#) [50351](#)  
[51944](#) [50726](#) [EG-UPS-PS2000-02](#) [51941](#) [5AVR3000SE](#) [EG-UPS-036](#) [50724](#) [EG-UPSO-1000](#) [EG-UPS-PS1000-01](#) [SDUCFRELAYCARD](#)  
[SDUCFRELAYCARD](#) [SDUMBUSCARD](#) [50348](#) [ISRELAY](#) [6EP1931-2EC21](#) [6EP1933-2EC51](#) [SDU-24-BAT](#) [6EP1931-2DC21](#) [AK-B1-](#)  
[500E](#) [AK-B1-700BE](#) [AK-I1-200](#) [AK-I2-150](#) [AK-S1-300](#) [AK-T1-250](#)