




 ${\bf 1}$. Cut the cable end square. Slide the k-grip sleeve onto the cable. Make "Cut 1" and "Cut 2" in the Jacket.




 $2.\,$ REMOVE THE JACKET AND THE BRAID TO DIMENSION B. TO REMOVE THE BRAID FLARE BACK OR BULGE THE BRAID AND TRIM WITH SCISSORS AT "CUT 1".




3. REMOVE JACKET TO DIMENSION A..




4. TRIM DIELECTRIC TO DIMENSION "C". EXPOSED CENTER CONDUCTOR LENGTH WILL BE EQUAL TO DIMENSION "C".




4a. SLIDE SLEEVE IN PLACE UNDER BRAID.



5. SLIGHTLY FLARE THE BRAID, THEN SLIDE CONTACT INTO POSITION AND CRIMP CONTACT TO CENTER CONDUCTOR.



6. PUSH K-GRIP JR. OVER DIELECTRIC AND UNDER BRAID UNTIL DIELECTRIC BOTTOMS IN CONNECTOR. TEFLON JACKETS MAY BE SLIT AXIALLY 1/4" IN TWO PLACES TO FACILITATE ENTRY OF THE K-GRIP.



7. SLIDE K-GRIP SLEEVE AGAINST SHOULDER ON BODY AND FORM BY CRIMPING.

DASH NO	Α	В	С
-1	.624	.312	.155
-2	.624	.312	.249
-3	.687	.375	.187
-4	.668	.356	.200
-5	.687	.375	.219

NOTES:

1. STEP 4A APPLIES ONLY TO -4 CABLING INSTRUCTIONS ONLY.

ALL DIMENSIONS ARE IN INCHES

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for kings manufacturer:

Other Similar products are found below:

875-57-1 126-12-5 KA-19-156 KA-89-92-M06 KC-59-509 KD-79-19 KN-19-151 KP-8010-740-400 2431-84-11 KTH-2011 UG-27D/U KA-79-56 KA-99-57 KC-59-122 KC-59-485 KC-79-67 KC-89-87 KN-59-104 KTH-2087 KTH-2138 KTH-2168 KV-19-13 KC-59-195 KTH-2101 KTH-5000 122-32-5 KA-81-04 KP-8010-730-400 KTH-2023 KTH-2024 KTH-2105 KTH-2111 KTH-2127 KTH-2185 KTH-2325 7702-9 7703-6 7705-3 E-3511-M99 KP-8040-006-000 KP-9005-000-090 KP-9211-070-009 2431-88-6 KTH-1079 KTH-2003 KTH-2214 KTH-2255 KTH-2002 KTH-2008 KTH-2248