MG Chemicals AppGuide



Desoldering Braid

How do I remove solder from an old circuit to replace a malfunctioning component?


De-soldering is required when electronic components need to be removed from a circuit, usually because they are faulty. It may sometimes be necessary during testing or assembly, if a wrong part has been fitted or a modification has to be made.

To professionally remove solder from a circuit, you will need the following materials:

- 1. MG Chemicals Super Wick de-soldering braid
- 2. Soldering iron

PROCEDURE

Step 1 Choosing the right braid



What you need for removing solder from a circuit:



- Choose a braid width that matches the size of the solder bead to be removed.
- If there are many small beads, choosing a wider braid will also speed up the Desoldering process.

AVAILABLE BRAID PRODUCTS (BY CAT. NO)

	WIDTH AND COLOUR CODE*				
LENGTHS	0.025" White	0.05" Yellow	0.075" Green	0.1" Blue	0.125" Brown
Super Wick					
5 ft	423	424	425	426	427
25 ft	-	442	443	444	-
50 ft	451	452	453	454	-
100 ft	461	462	463	464	-
500 ft	471	472	473	474	-
No Clean Super Wick					
5 ft	-	424-NS	425-NS	426-NS	-
50 ft	-	453-NS	-	454-NS	-

*Colours are industry standard. They represent the width of a desoldering braid.

E-mail Phone

Fax

salesusa@mgchemicals.com 1-800-201-8822 Ext. 130 1-604-888-3084 Ext. 130 1-800-708-9888 1-604-888-7754



For technical specifications, MSDS, tech support and more

To customize this AppGuide for your own use please email www.mgchemicals.com info@mgchemicals.com

ISO 9001:2000 Registered Quality System. QMI Certificate #004008 Toronto, Canada.

MG Chemicals AppGuide

Step 2 Using the braid

- a. Heat up soldering iron
- b. Place Super Wick on to solder bead
- c. Place heated solder iron on to braid

Molten solder is drawn up by capillary action into the braid. Careful not to overheat, or 'drag whiskers' of solder over the board, nor let the braid solidify on the joint! Always remove braid and solder iron together in a vertical motion.



Fine Braid Super Wick

Clean, Fast, Reliable



- Oxide-free clean copper
- ▶ More strands of copper (more surface area) per square inch
- Designed to leave a residue which is environmentally safe
- Uses pure type 'R' resin flux conforming to all the requirements of MIL-F-14256F, Type 'RMA' and ANSI/J-STD-004
- Static free dissipative spools in compliance with the ESD
- Association Standard (Mil. Standard 2000 and DOD Standard 1686)
- Manufactured under SPC guidelines
- Cleaned and manufactured utilizing the latest technology in environmentally friendly chemicals and processes
- Packaged in 5, 10, 25, 100 and 500 foot lengths

No Clean Super Wick

Cleaner, Faster, More Consistent



- Oxide-free clean copper
- More strands of copper (more surface area) per square inch
- Flux residue remaining on board does not need to be cleaned
- ▶ To be used in conjunction with processes using RMA type no-clean fluxes; conforms to the requirements of ANSI/J-STD-004, Type LO
- High SIR-conforming to Bellcore specification GR-78-CORE (TR-TSY- 000078), and IPC Test Method III
- Static free dissipative spools in compliance with the ESD Association Standard (Mil. Standard 2000 and DOD Standard 1686)
- Manufactured under SPC guidelines
- Cleaned and manufactured utilizing the latest technology in environmentally friendly chemicals and processes
- Packaged in 5, 10, 25 and 100 foot lengths

E-mail salesusa@mgchemicals.com Phone 1-800-201-8822 Ext. 130 1-604-888-3084 Ext. 130 Fax 1-800-708-9888 1-604-888-7754



For technical specifications, MSDS, tech support and more

To customize this AppGuide for your own use please email www.mgchemicals.com info@mgchemicals.com

ISO 9001:2000 Registered Quality System. QMI Certificate #004008 Toronto, Canada.



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Desoldering Braid / Solder Removal category:

Click to view products by MG Chemicals manufacturer:

Other Similar products are found below :

 532505-2
 T0054487199
 T0054486999
 DP-CC
 STDC-102
 T0054465499N
 T0058741815N
 T0052921799N
 T0054465299N
 T0051320399N

 T0051351199
 4036S
 6961
 9057
 9970
 9976
 DS104
 DS115T
 DS117T
 DS204
 DS206
 DS60
 ETBB
 HE80
 MP135
 MP136
 MP137
 MP138

 MT6
 UTC234
 T0054460273
 T0053411299N
 R350[1.5M]1.5mm
 17538
 S1069
 1811-5F
 1830-10F
 1824-5F
 50-3-100
 1813-5F
 1833-10F

 1824-25F
 0320705
 0320800
 0321200
 0321300
 0321500
 10-50L
 40-4-10