




For more information,  
visit [freescale.com/  
RDKL25AGMP01](http://freescale.com/RDKL25AGMP01)

**RD-  
KL25-  
AGMP01**

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. © 2015 Freescale Semiconductor, Inc. RDKL25AGMP01QRC REV 0 920-28798 REV A

**RD-KL25-AGMP01**

**RD-  
KL25-  
AGMP01**



## Quick Reference Card

### 10-Axis Sensor Reference Design

Enabled for sensor fusion with FXAS21002C 3-axis gyroscope, FXOS8700CQ 6-axis integrated e-compass, and MPL3115A2 absolute pressure sensor for data generation in industrial applications



**Get Started**


Download tools and documentation under **Jump Start Your Design** at [freescale.com/RDKL25AGMP01](http://freescale.com/RDKL25AGMP01)



REFERENCE DESIGN

- 1 Verify package contents:
  - RD-KL25-AGMP01 board
  - battery
  - USB cable
- 2 Download and install the required PC drivers from [www.pemicro.com/opensda](http://www.pemicro.com/opensda)
- 3 Download and install the Freescale RDKL25AGMP01 demonstration application from the Downloads tab of the RD-KL25-AGMP01 web page. [freescale.com/RDKL25AGMP01](http://freescale.com/RDKL25AGMP01)
- 4 Using the provided USB cable, connect the RD-KL25-AGMP01 to the host computer.
- 5 On the host computer, start the Freescale RDKL25AGMP01 demonstration application.

For more information on this reference design and the demonstration application, go to [freescale.com/RDKL25AGMP01](http://freescale.com/RDKL25AGMP01)



Get to Know the RD-KL25-AGMP01



Learn more at [freescale.com/RDKL25AGMP01](http://freescale.com/RDKL25AGMP01)

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Multiple Function Sensor Development Tools](#) category:*

*Click to view products by [NXP](#) manufacturer:*

Other Similar products are found below :

[MAXWSNENV#](#) [STEVAL-MKIT01V1](#) [KT-O2-25%-TB200A-E](#) [KT-TVOC-200-TB200A](#) [KT-NmHc-200-TB200A](#) [SEN0344](#) [PIM520](#)  
[PIM518](#) [PIM519](#) [PIM502](#) [EVAL-AD7746HDZ](#) [AS7022-EVALKIT](#) [ALTEHTG2SMIP](#) [MAX30101WING#](#) [OB1203SD-U-EVK](#) [MIKROE-](#)  
[4265](#) [A000070](#) [EV\\_ICG-20660L](#) [GX-F12A-P](#) [GX-F15A](#) [GX-F6A-P](#) [GX-F8B](#) [GX-H12A-P](#) [GX-H15AI-P](#) [GX-H6A-P](#) [1093](#) [MIKROE-2455](#)  
[MIKROE-2458](#) [MIKROE-2507](#) [MIKROE-2508](#) [MIKROE-2516](#) [MIKROE-2529](#) [1458](#) [MIKROE-1628](#) [176](#) [189](#) [1893](#) [2106](#) [ATQT4-XPRO](#)  
[GP30-DEMO MODULE](#) [GX-F12AI-P](#) [GX-F15A-P](#) [GX-F8A-P](#) [GX-FL15B-P](#) [GX-H15A-P](#) [GX-H6AI-P](#) [GX-H8A](#) [GX-H8AI-P](#) [GX-H8A-P](#)  
[GX-F15AI-P](#)