Pushbutton Switches/Indicators A22R/M22R series

Robust and Graceful design



This document provides information mainly for selecting suitable models. Please read the document Instruction Sheet carefully for information that the user must understand and accept before purchase, including information on warranty, limitations of liability, and precautions.

OMRON Corporation Industrial Automation Company Sensing Devices Division H.Q. Industrial Sensors Division Shiokoji Horikawa, Shimogyo-ku, Kvoto, 600-8530 Japan Tel: (81)75-344-7022/Fax: (81)75-344-7107

Regional Headquarters

OMRON EUROPE B.V. Wegalaan 67-69-2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

One Commerce Drive Schaumburg, IL 60173-5302 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787 OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711 OMRON (CHINA) CO., LTD.

OMRON ELECTRONICS LLC

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

© OMRON Corporation 2009 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice. Printed in Japan

1009

OMRON Industrial Automation Global: www.ia.omron.com

Cat. No. A190-E1-01

Authorized Distributor:

realrzing

OINRON **Pushbutton Switches**

Responds with high grade illumination to various needs

2 Soft to the touch

• Gentle design for human.



3



Responds with high grade illumination to various needs

2 Soft to the touch

• Gentle design for human.



3





Switch block

A22R- 🗆

E

Lamp socket A22R-□

Operation Units

Lighted Type



Projection type A22RL-T□-□

Selector Lighted Type



2 notches A22RW-2□□





3 notches A22RW-3□□

Socket







Mounting plate A22R-3200



Socket A22R-□M





Switch block

A22R- 🗆

E

Lamp socket A22R-□

Operation Units

Lighted Type



Projection type A22RL-T□-□

Selector Lighted Type



2 notches A22RW-2□□





3 notches A22RW-3□□

Socket







Mounting plate A22R-3200



Socket A22R-□M



Pushbutton Switches

| Non-lighted/Lighted | | | | | | | |
|---------------------|--------------------------|--|------------------|----------------------------|------------------|--|--|
| Appearance | Pushbutton shape | Pushbutton color | Contact form | Part No. | Dimensions | | |
| A22R-F□-□□ | | \bigcirc | 1a | A22R-FW-10 | 28° | | |
| | | | 1a | A22R-FB-10 | | | |
| | | | 1a | A22R-FG-10 | | | |
| | | | 1a | A22R-FR-10 | | | |
| | | | 1a | A22R-FY-10 | 29.8 | | |
| 100 | Round/Flat | | 1a | A22R-FA-10 | φ29.8 - Φ29.8 | | |
| a m | | | 1b | A22R-FB-01 | 0.5 | | |
| | | | 1b | A22R-FR-01 | | | |
| | | Insert one of th M: Momentary A: Alternate | e following let | ters into the box \Box . | | | |
| A22R-T□-□□ | | \bigcirc | 1a | A22R-TW-10 | | | |
| | | | 1a | A22R-TB-10 | | | |
| | Projection | | 1a | A22R-TG-10 | Ø23.7 | | |
| | | | 1a | A22R-TR-01 | | | |
| | | | 1a | A22R-TY-10 | | | |
| | | | 1a | A22R-TA-10 | | | |
| | | | 1b | A22R-TB-01 | | | |
| | | | 1b | A22R-TR-01 | | | |
| | | Insert one of the following letters into the box . M: Momentary A: Alternate | | | | | |
| A22RL-T□-□-□□ | | \bigcirc | 1a | A22RL-TW-24A-10 | | | |
| | | | 1a | A22RL-TG-24A-10 | | | |
| | Projection AC, DC 24V | | 1a | A22RL-TR-24A-10 | φ 29.8 | | |
| | 710, 20 211 | | 1a | A22RL-TY-24A-10 | \$23.7 | | |
| | | | 1a | A22RL-TA-24A-10 | | | |
| | | \bigcirc | 1a | A22RL-TW-T2-10 | | | |
| 5.10 | | | 1a | A22RL-TG-T2-10 | | | |
| | Ducientieur | | 1a | A22RL-TR-T2-10 | | | |
| | Projection AC 220V | | 1a | A22RL-TY-T2-10 | | | |
| | | | 1a | A22RL-TA-T2-10 | | | |
| | | Insert one of th M: Momentary A: Alternate | e following lett | ters into the box \Box . | | | |

Selector Switches Non-lighted/Lighted Knob Contact Number Knob Appearance of notch position color form A22RS-2□-□ 1a 1a1b 2 notches 1a \bigcirc 1a1b 2a A22RS-3□-□ \bigcirc 2a * These Non-lighted types prov 3 notches A22RW-2 1a 2 notches 1a1b AC, DC 24V 1a \bigcirc 1a1b A22RW-3 2a 2a 3 notches AC, DC 24V 2a \Diamond 2a

A22R/M22R Series Push Button

7

Assembled Models

| t | Part No. | Dimensions |
|---|------------------|---|
| | A22RS-2M-10 | 28° |
| | A22RS-2M-11 | |
| | A22RS-2A-10 | |
| | A22RS-2A-11 | |
| | A22RS-3M-20 | |
| | A22RS-3A-20 | 29.8 |
| | | |
| | A22RW-2MG-24A-10 | φ29.8 - |
| | A22RW-2MR-24A-11 | |
| | A22RW-2AY-24A-10 | 0 ¹ 0 ¹ 2 ²⁴ 2 |
| | A22RW-2AA-24A-11 | |
| | A22RW-3MG-24A-20 | |
| | A22RW-3MR-24A-20 | |
| | A22RW-3AY-24A-20 | |
| | A22RW-3AA-24A-20 | |

Pushbutton Switches

| Non-lighted/Lighted | | | | | | | |
|---------------------|--------------------------|--|------------------|----------------------------|------------------|--|--|
| Appearance | Pushbutton shape | Pushbutton color | Contact form | Part No. | Dimensions | | |
| A22R-F□-□□ | | \bigcirc | 1a | A22R-FW-10 | 28° | | |
| | | | 1a | A22R-FB-10 | | | |
| | | | 1a | A22R-FG-10 | | | |
| | | | 1a | A22R-FR-10 | | | |
| | | | 1a | A22R-FY-10 | 29.8 | | |
| 100 | Round/Flat | | 1a | A22R-FA-10 | φ29.8 - Φ29.8 | | |
| a m | | | 1b | A22R-FB-01 | 0.5 | | |
| | | | 1b | A22R-FR-01 | | | |
| | | Insert one of th M: Momentary A: Alternate | e following let | ters into the box \Box . | | | |
| A22R-T□-□□ | | \bigcirc | 1a | A22R-TW-10 | | | |
| | | | 1a | A22R-TB-10 | | | |
| | Projection | | 1a | A22R-TG-10 | Ø23.7 | | |
| | | | 1a | A22R-TR-01 | | | |
| | | | 1a | A22R-TY-10 | | | |
| | | | 1a | A22R-TA-10 | | | |
| | | | 1b | A22R-TB-01 | | | |
| | | | 1b | A22R-TR-01 | | | |
| | | Insert one of the following letters into the box . M: Momentary A: Alternate | | | | | |
| A22RL-T□-□-□□ | | \bigcirc | 1a | A22RL-TW-24A-10 | | | |
| | | | 1a | A22RL-TG-24A-10 | | | |
| | Projection AC, DC 24V | | 1a | A22RL-TR-24A-10 | φ 29.8 | | |
| | 710, 20 211 | | 1a | A22RL-TY-24A-10 | \$23.7 | | |
| | | | 1a | A22RL-TA-24A-10 | | | |
| | | \bigcirc | 1a | A22RL-TW-T2-10 | | | |
| 5.10 | | | 1a | A22RL-TG-T2-10 | | | |
| | Ducientieur | | 1a | A22RL-TR-T2-10 | | | |
| | Projection AC 220V | | 1a | A22RL-TY-T2-10 | | | |
| | | | 1a | A22RL-TA-T2-10 | | | |
| | | Insert one of th M: Momentary A: Alternate | e following lett | ters into the box \Box . | | | |

Selector Switches Non-lighted/Lighted Knob Contact Number Knob Appearance of notch position color form A22RS-2□-□ 1a 1a1b 2 notches 1a \bigcirc 1a1b 2a A22RS-3□-□ \bigcirc 2a * These Non-lighted types prov 3 notches A22RW-2 1a 2 notches 1a1b AC, DC 24V 1a \bigcirc 1a1b A22RW-3 2a 2a 3 notches AC, DC 24V 2a \Diamond 2a

A22R/M22R Series Push Button

7

Assembled Models

| t | Part No. | Dimensions |
|---|------------------|----------------------------------|
| | A22RS-2M-10 | 28° |
| | A22RS-2M-11 | |
| | A22RS-2A-10 | |
| | A22RS-2A-11 | |
| | A22RS-3M-20 | |
| | A22RS-3A-20 | 29.8 |
| | | |
| | A22RW-2MG-24A-10 | φ29.8 - |
| | A22RW-2MR-24A-11 | |
| | A22RW-2AY-24A-10 | 0 ¹ 0 ¹ 27 |
| | A22RW-2AA-24A-11 | |
| | A22RW-3MG-24A-20 | |
| | A22RW-3MR-24A-20 | |
| | A22RW-3AY-24A-20 | |
| | A22RW-3AA-24A-20 | |

Selector Switches


| Key Selector | | | | | | | |
|--------------|--------------------|-------------------------|-----------------|--------------|------------|--|--|
| Appearance | Number of notch | Key position | Contact form | Part No. | Dimensions | | |
| A22RK-2□-□ | | ٩ | 1a | A22RK-2ML-10 | 28° | | |
| | | | 1a1b | A22RK-2ML-11 | | | |
| - | | ٩ ٥ | 1a | A22RK-2M-10 | | | |
| | 2 notches | | 1a1b | A22RK-2M-11 | | | |
| P.D. | 2 Hotorica | ~ | 1a | A22RK-2AL-10 | | | |
| | | | 1a1b | A22RK-2AL-11 | 29.8 | | |
| | | O: key release position | | | | | |
| A22RK-3□-□ | | ° | 2a | A22RK-3ML-20 | | | |
| | | °√∕° | 2a | A22RK-3M-20 | | | |
| | 0 a states | , V | 2a | A22RK-3MC-20 | | | |
| | 3 notches | \bigcirc | 2a | A22RK-3AC-20 | | | |
| | | ○: key release position | | | | | |

Indicator


• All-in-one type

| Appearance | LED rating | Indicator color | Part No. | Dimensions |
|-----------------------|------------|--------------------|-------------|------------|
| M22R-E□-□ | | \bigcirc | M22R-EW-24A | Ø29.8 |
| | | | M22R-EG-24A | |
| | AC, DC 24V | | M22R-ER-24A | |
| | | | M22R-EY-24A | |
| C "F | | | M22R-EA-24A | 0.5 |
| and the second second | AC 220V | \bigcirc | M22R-EW-T2 | ب 1 |
| | | | M22R-EG-T2 | |
| | | | M22R-ER-T2 | |
| | | | M22R-EY-T2 | |
| | | | M22R-EA-T2 | |

A22R series



M22R series





9

Selector Switches


| Key Selector | | | | | | | |
|--------------|--------------------|-------------------------|-----------------|--------------|------------|--|--|
| Appearance | Number of notch | Key position | Contact form | Part No. | Dimensions | | |
| A22RK-2□-□ | | ٩ | 1a | A22RK-2ML-10 | 28° | | |
| | | | 1a1b | A22RK-2ML-11 | | | |
| - | | ٩ ٥ | 1a | A22RK-2M-10 | | | |
| | 2 notches | | 1a1b | A22RK-2M-11 | | | |
| P.D. | 2 Hotorica | ~ | 1a | A22RK-2AL-10 | | | |
| | | | 1a1b | A22RK-2AL-11 | 29.8 | | |
| | | O: key release position | | | | | |
| A22RK-3□-□ | | ° | 2a | A22RK-3ML-20 | | | |
| | | °√∕° | 2a | A22RK-3M-20 | | | |
| | 0 a states | , V | 2a | A22RK-3MC-20 | | | |
| | 3 notches | \bigcirc | 2a | A22RK-3AC-20 | | | |
| | | ○: key release position | | | | | |

Indicator


• All-in-one type

| Appearance | LED rating | Indicator color | Part No. | Dimensions |
|-----------------------|------------|--------------------|-------------|--|
| M22R-E□-□ | | \bigcirc | M22R-EW-24A | Ø29.8 |
| | | | M22R-EG-24A | |
| | AC, DC 24V | | M22R-ER-24A | |
| | | | M22R-EY-24A | |
| C "F | | | M22R-EA-24A | 0.5 |
| and the second second | AC 220V | \bigcirc | M22R-EW-T2 | ý 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 |
| | | | M22R-EG-T2 | |
| | | | M22R-ER-T2 | |
| | | | M22R-EY-T2 | |
| | | | M22R-EA-T2 | |

A22R series



M22R series






9

| Pushbutton unit | | | | | | |
|---------------------|---------------------|--|---|------------|--|--|
| Non-lighted/Lighted | b | | | | | |
| Appearance | Pushbutton shape | Pushbutton color | Part No. | Dimensions | | |
| A22R-F□-□ | | \bigcirc | A22R-FW- | Ø29.8 | | |
| | | | A22R-FB- | | | |
| | | | A22R-FG-□ | | | |
| | Round/Flat | | A22R-FR-□ | | | |
| | Round/Flat | | A22R-FY- | | | |
| | | | A22R-FA- | | | |
| | | Insert one of the M: Momentary A: Alternate | e following letters into the box \Box . | | | |
| A22R-T□-□ | Projection | \bigcirc | A22R-TW- | | | |
| | | | A22R-TB- | | | |
| ~ | | | A22R-TG-□ | | | |
| | | | A22R-TR-□ | | | |
| | | | A22R-TY- | | | |
| | | | A22R-TA- | | | |
| | | Insert one of the following letters into the box . M: Momentary A: Alternate | | | | |
| A22RL-T□-□ | | \bigcirc | A22RL-TW- | | | |
| | | | A22RL-TG- | | | |
| 2011 | Projection | | A22RL-TR- | 0.010 | | |
| | Lighted type | | A22RL-TY- | | | |
| | | | A22RL-TA- | | | |
| | | Insert one of the M: Momentary A: Alternate | e following letters into the box \Box . | | | |

| | Selector unit | | | | | | | | |
|---|--|------------------------------|--------------------|---------------|--------------|--|--|--|--|
| | Non-lighted/Lighted | 1/21 | | | | | | | |
| | Appearance | Number of notch | Knob position | Knob color | | | | | |
| | A22RS-2□ | | \searrow | | | | | | |
| | and the second | | \bigcirc | | | | | | |
| | | 2 notches | | | | | | | |
| | A22RS-3 | | \checkmark | | | | | | |
| | Station . | | \bigcirc | | | | | | |
| 1 | | 3 notches | * These N | on-lighte | d types prov | | | | |
| | A22RW-2 | | \checkmark | | | | | | |
| | | 2 notches Lighted Type | | | | | | | |
| | All and | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | \bigcirc | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | A22RW-3 | | | | | | | | |
| | All and a second se | | \checkmark | | | | | | |
| | | 3 notches Lighted | | • | | | | | |
| | | Туре | | | | | | | |
| | | | \bigtriangledown | | | | | | |
| | | | | | | | | | |


A22R/M22R Series Push Button 11



| Pushbutton unit | | | | | | |
|---------------------|---------------------|--|---|------------|--|--|
| Non-lighted/Lighted | k | | | | | |
| Appearance | Pushbutton shape | Pushbutton color | Part No. | Dimensions | | |
| A22R-F□-□ | | \bigcirc | A22R-FW- | Ø29.8 | | |
| | | | A22R-FB- | | | |
| | | | A22R-FG-□ | | | |
| | Round/Flat | | A22R-FR-□ | | | |
| | Round/Flat | | A22R-FY- | | | |
| | | | A22R-FA- | | | |
| | | Insert one of the M: Momentary A: Alternate | e following letters into the box \Box . | | | |
| A22R-T□-□ | Projection | \bigcirc | A22R-TW- | | | |
| | | | A22R-TB- | | | |
| ~ | | | A22R-TG-□ | | | |
| | | | A22R-TR-□ | | | |
| | | | A22R-TY- | | | |
| | | | A22R-TA- | | | |
| | | Insert one of the following letters into the box . M: Momentary A: Alternate | | | | |
| A22RL-T□-□ | | \bigcirc | A22RL-TW- | | | |
| | | | A22RL-TG- | | | |
| 2011 | Projection | | A22RL-TR- | 0.010 | | |
| | Lighted type | | A22RL-TY- | | | |
| | | | A22RL-TA- | | | |
| | | Insert one of the M: Momentary A: Alternate | e following letters into the box \Box . | | | |


| | Selector unit | | | | | | | | |
|---|--|------------------------------|--------------------|---------------|--------------|--|--|--|--|
| | Non-lighted/Lighted | 1/21 | | | | | | | |
| | Appearance | Number of notch | Knob position | Knob color | | | | | |
| | A22RS-2□ | | \searrow | | | | | | |
| | and the second | | \bigcirc | | | | | | |
| | | 2 notches | | | | | | | |
| | A22RS-3 | | \checkmark | | | | | | |
| | Station . | | \bigcirc | | | | | | |
| 1 | | 3 notches | * These N | on-lighte | d types prov | | | | |
| | A22RW-2 | | \checkmark | | | | | | |
| | | 2 notches Lighted Type | | | | | | | |
| | All and | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | \bigcirc | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | A22RW-3 | | | | | | | | |
| | All and a second se | | \checkmark | | | | | | |
| | | 3 notches Lighted | | | | | | | |
| | | Туре | | | | | | | |
| | | | \bigtriangledown | | | | | | |
| | | | | | | | | | |

A22R/M22R Series Push Button 11



Selector unit

| Key Selector | | | | |
|--------------|--------------------|-------------------------|-----------|------------|
| Appearance | Number of notch | Key position | Part No. | Dimensions |
| A22RK-2 | | ٩ | A22RK-2ML | Ø29.8 |
| 1700 | | °° | A22RK-2M | |
| | 2 notches | \sim | A22RK-2AL | |
| | | O: key release positio | n | |
| A22RK-3 | | \sim | A22RK-3ML | LZ A239K |
| at the | | \sim | A22RK-3M | |
| CO. | 3 notches | \checkmark | A22RK-3MC | |
| | | \checkmark | A22RK-3AC | |
| | | O: key release position | n | |



Switch unit

| For Lighted type | | | | |
|--------------------------------------|----------|--------------|--------------|------------|
| Appearance | Туре | Contact form | Part No. | Dimensions |
| A22RL- | | 1a | A22RL-10M | |
| | | 1b | A22RL-01M | 29.8 |
| | Standard | 2a | A22RL-20M | Ø10.3 |
| 1 | | 2b | A22RL-02M | |
| 100 | | 1a1b | A22RL-11M | |
| | | 1a | A22RL-10M-T2 | |
| | | 1b | A22RL-01M-T2 | |
| | AC 220V | 2a | A22RL-20M-T2 | |
| | | 2b | A22RL-02M-T2 | |
| | | 1a1b | A22RL-11M-T2 | |

• For Non-lighted type

| 0 71 | | | | |
|------------|--------|--------------|----------|------------|
| Appearance | Туре | Contact form | Part No. | Dimensions |
| A22R-□M | | 1a | A22R-10M | 29.8 |
| | | 1b | A22R-01M | |
| | Socket | 2a | A22R-20M | |
| | | 1a1b | A22R-11M | |
| | | 2b | A22R-02M | |


Mounting plate

| Appearance | Unit | Part No. | Dimensions |
|------------|-------------------|-----------|------------|
| A22R-3200 | Mounting plate | A22R-3200 | |

A22R/M22R Series Key/Switch Section/Mounting Console

Selector unit

| Key Selector | | | | |
|--------------|--------------------|-------------------------|-----------|------------|
| Appearance | Number of notch | Key position | Part No. | Dimensions |
| A22RK-2 | | ٩ | A22RK-2ML | Ø29.8 |
| 1700 | | °° | A22RK-2M | |
| | 2 notches | \sim | A22RK-2AL | |
| | | O: key release positio | n | |
| A22RK-3 | | \sim | A22RK-3ML | LZ A239K |
| at the | | \sim | A22RK-3M | |
| CO. | 3 notches | \checkmark | A22RK-3MC | |
| | | \checkmark | A22RK-3AC | |
| | | O: key release position | n | |



Switch unit

| For Lighted type | | | | |
|--------------------------------------|----------|--------------|--------------|------------|
| Appearance | Туре | Contact form | Part No. | Dimensions |
| A22RL- | | 1a | A22RL-10M | |
| | | 1b | A22RL-01M | 29.8 |
| | Standard | 2a | A22RL-20M | Ø10.3 |
| 1 | | 2b | A22RL-02M | |
| 100 | | 1a1b | A22RL-11M | |
| | | 1a | A22RL-10M-T2 | |
| | | 1b | A22RL-01M-T2 | |
| | AC 220V | 2a | A22RL-20M-T2 | |
| | | 2b | A22RL-02M-T2 | |
| | | 1a1b | A22RL-11M-T2 | |

• For Non-lighted type

| 0 71 | | | | |
|------------|--------|--------------|----------|------------|
| Appearance | Туре | Contact form | Part No. | Dimensions |
| A22R-□M | | 1a | A22R-10M | 29.8 |
| | | 1b | A22R-01M | |
| | Socket | 2a | A22R-20M | |
| | | 1a1b | A22R-11M | |
| | | 2b | A22R-02M | |

Mounting plate

| Appearance | Unit | Part No. | Dimensions |
|------------|-------------------|-----------|------------|
| A22R-3200 | Mounting plate | A22R-3200 | |

A22R/M22R Series Key/Switch Section/Mounting Console

| Lamp unit | | | | |
|------------|-----------------------|----------------|-----------|--|
| • LED | | | | |
| Appearance | LED operating voltage | Lighting color | Part No. | Dimensions |
| A22R-□□ | | \bigcirc | A22R-6AW | |
| | [| | A22R-6AG | |
| | LED AC/DC6V | | A22R-6AR | |
| | | • | A22R-6AY | |
| | | | A22R-6AA | |
| | | \bigcirc | A22R-12AW | |
| | | | A22R-12AG | BA9S/13 |
| | LED AC/DC12V | | A22R-12AR | 5 |
| | | • | A22R-12AY | Ø9.3 |
| | | | A22R-12AA | -= |
| | | \bigcirc | A22R-24AW | |
| | | | A22R-24AG | |
| | LED AC/DC24V | | A22R-24AR | |
| | | - | A22R-24AY | |
| | | | A22R-24AA | |

Nomenclature

Completely Assembled A22R Pushbutton switches

| | | , | | | | | | | | | |
|---|---------|----------|----|---------|------------|-----|---------|------------|---|-------------------------|--------|
| | A 2 2 F | | | □ — [| | | | | | | |
| | | | 2) | 3 (| 4 56 | | 1 | | | 1 | |
| (| D Light | ing | (| 2 Pusł | nbutton Sh | ape | 3 Light | ing Color | (| Light | S |
| | Code | Lighting | | Code | Shape | | Code | Color | | Code | |
| | Blank | Non- | | F | Flat * | | R | Red | | Code | |
| | | lighted | | Т | Projection | | G | Green | | Blank | Ν |
| | L | Lighted | | | on-lighted | | Y | Yellow | | 6A | |
| | | | | type of | only | | W | White | | 12A | |
| | | | | | | | Α | Blue | | 24A | |
| | | | | | | | В | Black * | 6 | a Liabt | c |
| | | | | | | | | on-lighted | Ģ | ① Light | с Г |
| | | | | | | | type o | nly | | Code | |
| | | | | | | | | | | T2 | |
| | | | | | | | | | | Use | A |
| | | | | | | | | | | | |


Completely Assembled A22R
 Selector switches

| A 2 2 | | 3 4 | ─ □ ⑤ ───── er of Notches/Reset Met | hod | 1 ③ Ligh | ting Color | |] ⊕ Light | Source | 5 | Con | tact Form |
|-------|----------|------|---|-----|----------------------------|------------|--|-------------------------|-------------------|---|------|---------------|
| Code | Lighting | Code | Specification | | Code | Color | | Code | Operating Voltage | C | Code | Contact Form |
| s | Non- | 2M | 2 notches/Manual | | Blank | Black* | | Blank | No-lighted type | | 10 | 1a** |
| 5 | lighted | 2A | 2 notches/Automatic | | R | Red | | 6A | AC/DC6V | | 01 | 1b** |
| W | Lighted | ЗM | 3 notches/Manual | | G | Green | | 12A | AC/DC12V | | 11 | 1a1b |
| | | ЗA | 3 notches/Automatic | | Y | Yellow | | 24A | AC/DC24V | | 20 | 2a |
| | | | 3 notches/Manual – | | Α | Blue | | | | | 02 | 2b |
| | | 3MA | 3MA left side, Automatic – right side | | * Non-lighted type only | | | Light Source | | | | models with 2 |
| | | | 3 notches/Automatic - | ĺ | omy | | | Code Operating Voltag | | | notc | hes |
| | | ЗАМ | left side, Manual - | | | | | T2 | AC220V | | | |
| | | | right side | | | | | Use | AC/DC24V LED | | | |


● Completely Assembled A22RK-□-□ Key selector switches

| Rey se | elector switches | | | | | | | | |
|--------|---|---|----------|-----------------|---|--|--|--|--|
| A 2 2 | A 2 2 R K — 🗆 — 🗆 | | | | | | | | |
| | | | 7 | | | | | | |
| ป Nur | nber of Notches/Reset method | (| 2 Con | tact Form | 1 | | | | |
| Code | Number of notches, Reset method, Key release position | | Code | Contact Form | | | | | |
| 2ML | 2 notches, Manual, Left | | 10 | 1a** | | | | | |
| 2M | 2 notches, Manual, Left and Right | | 01 | 1b** | | | | | |
| 2AL | 2 notches, Automatic, Left | | 11 | 1a1b | | | | | |
| 3ML | 3 notches, Manual, Left | | 20 | 2a | | | | | |
| ЗM | 3 notches, Manual, Left and Right | | 02 | 2b | | | | | |
| 3MC | 3 notches, Manual, Center | , | ** For i | nodels | 1 | | | | |
| 3AC | 3 notches, Automatic, Center | | | 2 notches | s | | | | |
| 3MAL | 3 notches, Manual – left, Automatic - right, Left | | | | | | | | |
| 3AMR | 3 notches, Automatic – left, Manual – right, Right | | | | | | | | |
| L | | | | | | | | | |

Nomenclature



• Completely Assembled M22R-□□-□ Indicator



| Lamp unit | | | | |
|------------|-----------------------|----------------|-----------|---------------|
| • LED | | | | |
| Appearance | LED operating voltage | Lighting color | Part No. | Dimensions |
| A22R-□□ | | \bigcirc | A22R-6AW | |
| | [| | A22R-6AG | |
| | LED AC/DC6V | | A22R-6AR | |
| | | • | A22R-6AY | |
| | | | A22R-6AA | |
| | | \bigcirc | A22R-12AW | ∽ Ø9.6 |
| | | | A22R-12AG | BA9S/13 |
| | LED AC/DC12V | | A22R-12AR | 5 |
| | | • | A22R-12AY | Ø9.3 |
| | | | A22R-12AA | -= |
| | | \bigcirc | A22R-24AW | |
| | | | A22R-24AG | |
| | LED AC/DC24V | | A22R-24AR | |
| | | - | A22R-24AY | |
| | | | A22R-24AA | |

Nomenclature

Completely Assembled A22R Pushbutton switches

| | | , | | | | | | | | | |
|---|---------|----------|----|---------|------------|-----|---------|------------|---|-------------------------|--------|
| | A 2 2 F | | | □ — [| | | | | | | |
| | | | 2) | 3 (| 4 56 | | 1 | | | 1 | |
| (| D Light | ing | (| 2 Pusł | nbutton Sh | ape | 3 Light | ing Color | (| Light | S |
| | Code | Lighting | | Code | Shape | | Code | Color | | Code | |
| | Blank | Non- | | F | Flat * | | R | Red | | Code | |
| | | lighted | | Т | Projection | | G | Green | | Blank | Ν |
| | L | Lighted | | | on-lighted | | Y | Yellow | | 6A | |
| | | | | type of | only | | W | White | | 12A | |
| | | | | | | | Α | Blue | | 24A | |
| | | | | | | | В | Black * | 6 | a Liabt | c |
| | | | | | | | | on-lighted | Ģ | ① Light | с Г |
| | | | | | | | type o | nly | | Code | |
| | | | | | | | | | | T2 | |
| | | | | | | | | | | Use | A |
| | | | | | | | | | | | |


Completely Assembled A22R
 Selector switches

| A 2 2 | | 3 4 | ─ □ ⑤ ───── er of Notches/Reset Met | hod | 1 ③ Ligh | ting Color | |] ⊕ Light | Source | 5 | Con | tact Form | |
|-------|-------------------------|------------------------|---|-----|--------------------------------------|------------|--------|------------------------|-------------------|---------|----------------------|--------------|--|
| Code | Lighting | Code | Specification | | Code | Color | | Code | Operating Voltage | C | Code | Contact Form | |
| s | Non- | 2M | 2 notches/Manual | | Blank | Black* | | Blank | No-lighted type | | 10 | 1a** | |
| 5 | lighted | 2A | 2 notches/Automatic | | R | Red | | 6A | AC/DC6V | | 01 | 1b** | |
| W | Lighted | ЗM | 3 notches/Manual | | G | Green | | 12A | AC/DC12V | | 11 | 1a1b | |
| | | 3A 3 notches/Automatic | | | Y | Yellow | | 24A | AC/DC24V | | 20 | 2a | |
| | | | 3 notches/Manual – | | A Blue * Non-lighted type only | | | · · · | | | 02 | 2b | |
| | | 3MA | left side, Automatic – right side | | | | (| Light Source | | | ** For models with 2 | | |
| | | | 3 notches/Automatic - | ĺ | | | | Code Operating Voltage | | notches | | | |
| | 3AM left side, Manual – | | | | | T2 | AC220V | | | | | | |
| | | | right side | | | | | | Use AC/DC24V LED | | | | |


● Completely Assembled A22RK-□-□ Key selector switches

| Rey se | elector switches | | | | | | |
|--------|---|----------------|---------------|-----------------|--|--|--|
| A 2 2 | $RK - \Box - \Box$ | | | | | | |
| | | | 7 | | | | |
| ป Nur | nber of Notches/Reset method | ② Contact Form | | | | | |
| Code | Number of notches, Reset method, Key release position | | Code | Contact Form | | | |
| 2ML | 2 notches, Manual, Left | | 10 | 1a** | | | |
| 2M | 2 notches, Manual, Left and Right | | 01 | 1b** | | | |
| 2AL | 2 notches, Automatic, Left | | 11 | 1a1b | | | |
| 3ML | 3 notches, Manual, Left | | 20 | 2a | | | |
| ЗM | 3 notches, Manual, Left and Right | | 02 | 2b | | | |
| 3MC | 3 notches, Manual, Center | , | ** For models | | | | |
| 3AC | 2 notches | s | | | | | |
| 3MAL | 3 notches, Manual – left, Automatic - right, Left | it, | | | | | |
| 3AMR | 3 notches, Automatic – left, Manual – right, Right | | | | | | |
| L | | | | | | | |

Nomenclature



• Completely Assembled M22R-□□-□ Indicator



Nomenclature

● Individual unit (Pushbutton unit) A22R□-□□-□ Pushbutton switches

| L Lighted T Projection *For Non-lighted type only G Green W White A Blue B Black* | A 2 2 F | } □ ─ □ □ − ① ② ③ | - [] 4 | | | | | |
|--|---------|-----------------------------|-----------|----------------------|--------|----------------------|------|------------------|
| Blank Non-lighted F Flat* R Red M Momentary action L Lighted T Projection G Green A Alternate action *For Non-lighted type only Y Yellow W White A Blue B Black* | 1 Light | | ④ Swit | ch Operation | | | | |
| L Lighted T Projection *For Non-lighted type only G Green W White A Blue B Black* | Code | Lighting | Code | Pushbutton Shape | Code | Pushbutton Color | Code | Switch Operation |
| *For Non-lighted type only W White A Blue B Black* | Blank | Non-lighted | F | Flat* | R | Red | М | Momentary action |
| W White A Blue B Black* | L | Lighted | Т | Projection | G | Green | Α | Alternate action |
| A Blue B Black* | | | *For N | on-lighted type only | Y | Yellow | | • |
| B Black* | | | | | W | White | | |
| | | | | | A | Blue | | |
| *For Non-lighted type only | | | | | В | Black* | | |
| Tor Non lighted type only | | | | | *For N | on-lighted type only | y | |

● Individual unit (Selector unit) A22R□-□□ Selector switches

| A 2 2 R | $\Box = \Box$ | | | | |
|---------|---------------|-------|---|---------|-----------|
| | | | | _ | |
| 1 Light | ting | 2 Num | ber of notches, Reset Method | 3 Knob | Color |
| Code | Lighting | Code | Number of notches, Reset Method | Code | Color |
| S | Non-lighted | 2M | 2 notches, Manual | Blank | Black* |
| W | Lighted | 2A | 2 notches, Automatic | R | Red |
| | | ЗM | 3 notches, Manual | G | Green |
| | | ЗA | 3 notches, Automatic | Y | Yellow |
| | | 3MA | 3 notches, Manual – left, Automatic – right | Α | Blue |
| | | ЗАМ | 3 notches, Automatic – left, Manual - right | *Non-li | ghted typ |
| | | | | | |
| | | | | | |

● Individual unit (Key selector unit) A22RK-□ Key selector switches

| A 2 2 R | 2 2 R K — 🗆 | | | | | | | | |
|---------|---|--|--|--|--|--|--|--|--|
| | 1 | | | | | | | | |
| 1 Num | ber of notches, Reset Method, Key Release Position | | | | | | | | |
| Code | Number of notches, Reset Method, Key Release Position | | | | | | | | |
| 2ML | 2 notches, Manual, Left | | | | | | | | |
| 2M | 2 notches, Manual, Left and Right | | | | | | | | |
| 2AL | 2 notches, Automatic, Left | | | | | | | | |
| 3ML | 3 notches, Manual, Left | | | | | | | | |
| ЗM | 3 notches, Manual, Left and Right | | | | | | | | |
| 3MC | 3 notches, Manual, Center | | | | | | | | |
| 3AC | 3 notches, Automatic, Center | | | | | | | | |
| 3MAL | 3 notches, Manual – left, Automatic – right, Left | | | | | | | | |
| 3AMR | 3 notches, Automatic – left, Manual – right, Right | | | | | | | | |

Nomenclature

• Individual unit (Switch unit) A22R - M-

| A 2 2 F | א א 1 0_3 | _ | () (4) | | | | |
|---------|--------------|---|-----------|--------------|---|-------------|-------------|
| 1 Light | ing | | ② Cor | tact Form | (| l 3 Swit | ch Operatio |
| Code | Lighting | | Code | Contact Form | | Code | Switch Ope |
| Blank | Non-lighted | | 10 | 1a | | М | Momentary |
| L | Lighted | | 01 | 1b | - | | |
| | | | 11 | 1a1b | | | |
| | | | 20 | 2a | | | |
| | | | 02 | 2b | | | |
| | | | | | | | |


● Individual unit (Switch block) A22R-□

A 2 2 R

| — [(|]]]] Cont | tact Form | |
|----------|-----------------------|--------------|--|
| | Code | Contact Form | |
| | 10 | 1a | |
| | 01 | 1b | |
| | | | |

● Individual unit (LED) A22R-□ □ LED

| 1 Opera | ting Voltage | (| ② Ligh | ting color |
|---------|-------------------|---|--------|----------------|
| Code C | Operating Voltage | | Code | Lighting color |
| 6A A | AC/DC6V | | R | Red |
| 12A A | AC/DC12V | | G | Green |
| 24A A | AC/DC24V | | Y | Yellow |
| | | | W | White |
| | | | Α | Blue |



Nomenclature

● Individual unit (Pushbutton unit) A22R□-□□-□ Pushbutton switches

| L Lighted T Projection *For Non-lighted type only G Green W White A Blue B Black* | A 2 2 F | } □ ─ □ □ − ① ② ③ | - [] 4 | | | | | |
|--|---------|-----------------------------|-----------|----------------------|--------|----------------------|------|------------------|
| Blank Non-lighted F Flat* R Red M Momentary action L Lighted T Projection G Green A Alternate action *For Non-lighted type only Y Yellow W White A Blue B Black* | 1 Light | | ④ Swit | ch Operation | | | | |
| L Lighted T Projection *For Non-lighted type only G Green W White A Blue B Black* | Code | Lighting | Code | Pushbutton Shape | Code | Pushbutton Color | Code | Switch Operation |
| *For Non-lighted type only W White A Blue B Black* | Blank | Non-lighted | F | Flat* | R | Red | М | Momentary action |
| W White A Blue B Black* | L | Lighted | Т | Projection | G | Green | Α | Alternate action |
| A Blue B Black* | | | *For N | on-lighted type only | Y | Yellow | | • |
| B Black* | | | | | W | White | | |
| | | | | | A | Blue | | |
| *For Non-lighted type only | | | | | В | Black* | | |
| Tor Non lighted type only | | | | | *For N | on-lighted type only | y | |

● Individual unit (Selector unit) A22R□-□□ Selector switches

| A 2 2 R | $\Box = \Box \Box$ | | | | |
|---------|--------------------|-------|---|---------|-----------|
| | | | | _ | |
| 1 Light | ting | 2 Num | ber of notches, Reset Method | 3 Knob | Color |
| Code | Lighting | Code | Number of notches, Reset Method | Code | Color |
| S | Non-lighted | 2M | 2 notches, Manual | Blank | Black* |
| W | Lighted | 2A | 2 notches, Automatic | R | Red |
| | | ЗM | 3 notches, Manual | G | Green |
| | | ЗA | 3 notches, Automatic | Y | Yellow |
| | | 3MA | 3 notches, Manual – left, Automatic – right | Α | Blue |
| | | ЗАМ | 3 notches, Automatic – left, Manual - right | *Non-li | ghted typ |
| | | | | | |
| | | | | | |

● Individual unit (Key selector unit) A22RK-□ Key selector switches

| A 2 2 R | а 2 2 R К — 🗆 | | | | | |
|---|--|--|--|--|--|--|
| 0 | | | | | | |
| ① Number of notches, Reset Method, Key Release Position | | | | | | |
| Code | Code Number of notches, Reset Method, Key Release Position | | | | | |
| 2ML | 2 notches, Manual, Left | | | | | |
| 2M | 2 notches, Manual, Left and Right | | | | | |
| 2AL | 2AL 2 notches, Automatic, Left | | | | | |
| 3ML | 3 notches, Manual, Left | | | | | |
| ЗM | 3 notches, Manual, Left and Right | | | | | |
| 3MC | 3 notches, Manual, Center | | | | | |
| 3AC | 3 notches, Automatic, Center | | | | | |
| 3MAL 3 notches, Manual – left, Automatic – right, Left | | | | | | |
| 3AMR | 3 notches, Automatic – left, Manual – right, Right | | | | | |

Nomenclature

• Individual unit (Switch unit) A22R - M-

| A 2 2 F | א א 1 0_3 | _ | () (4) | | | | |
|---------|--------------|---|-----------|--------------|---|-------------|-------------|
| 1 Light | ing | | ② Cor | tact Form | (| l 3 Swit | ch Operatio |
| Code | Lighting | | Code | Contact Form | | Code | Switch Ope |
| Blank | Non-lighted | | 10 | 1a | | М | Momentary |
| L | Lighted | | 01 | 1b | - | | |
| | | | 11 | 1a1b | | | |
| | | | 20 | 2a | | | |
| | | | 02 | 2b | | | |
| | | | | | | | |


● Individual unit (Switch block) A22R-□

A 2 2 R

| — [(|]]]] Cont | tact Form | |
|----------|-----------------------|--------------|--|
| | Code | Contact Form | |
| | 10 | 1a | |
| | 01 | 1b | |
| | | | |


● Individual unit (LED) A22R-□ □ LED

| 1 Opera | ting Voltage | (| ② Ligh | ting color |
|---------|-------------------|---|--------|----------------|
| Code C | Operating Voltage | | Code | Lighting color |
| 6A A | AC/DC6V | | R | Red |
| 12A A | AC/DC12V | | G | Green |
| 24A A | AC/DC24V | | Y | Yellow |
| | | | W | White |
| | | | Α | Blue |



Accessories / Tools

| Acces | sories | | | | | | | |
|-----------------|----------|------------|----------------------------|------------------------------|-------|-------------|--|--|
| lte | em | Appearance | Clas | ssification | | Part No. | Remarks | |
| | | | | | White | A22Z-3321 | | |
| | Standard | | With Snap-i Plate (with | n Legend Iout text) | Red | A22Z-3322 | | |
| | size | | | | Black | A22Z-3323 | Snap-in Legend Plate is acrylic. | |
| _egend Plate | | | Without Sna | p-in Legend | Plate | A22Z-3320 | | |
| Frames | | ~ | | | White | A22Z-3331 | | |
| | Large | | With Snap-i Plate (with | n Legend Iout text) | Red | A22Z-3332 | Chan in Lorend plate is comilia | |
| | size | | | | Black | A22Z-3333 | - Snap-in Legend plate is acrylic. | |
| | | | Without Sna | Without Snap-in Legend Plate | | A22Z-3330 | | |
| Lock | Ring | | F | Round | | A22Z-3360 | The Lock Ring is used when more secure lock feature is required. | |
| Socia | a Cono | | For flat models | | | A22Z-3600F | Used to prevent dust or water from entering the Operation Unit (Pushbutton, etc.). Color: opaque Material: silicon | |
| Sealin | g Caps | | For projection models | | | A22Z-3600T | | |
| Hole | plug | | F | Round | | | Can be plugged into pre-cut panel holes for future expansion. The color is black. | |
| | | | O | ne hole | | A22Z-B101 | | |
| Contro | l Boxes | | Тм | Two holes | | | Material: Polycarbonate resin. | |
| | | | Thr | Three holes | | | | |
| Conc | ootoro | | Applicable | ø7~9 |) | A22Z-3500-1 | Plastic connector used to extend | |
| Conne | ectors | | diameter (mm) ø9~1 | | 1 | A22Z-3500-2 | a cable from the Switch Box. (See page 30) | |



| Item | Appearance | Part No. | | | |
|-------------------|------------|-----------|--|--|--|
| Lamp Extractor | | A22Z-3901 | | | |
| Tightening wrench | | A22Z-3905 | | | |

A22R/M22R Series 19

Accessories / Tools

| | | 1 | | |
|--------|---------------|---|--|--|
| | Part No. | Remarks | | |
| | A22Z-3443B | | | |
| | A22Z-3443R | | | |
| | A22Z-3443W | | | |
| ent | A22Z-3443C | | | |
| 0 | A22Z-3443R-2 | | | |
| STOP | A22Z-3443R-4 | | | |
| | A22Z-3443B-1 | Attached to the Standard | | |
| START | A22Z-3443B-3 | Plate Frame. Material: Acrylic. | | |
| ON | A22Z-3443B-5 | | | |
| OFF | A22Z-3443B-6 | | | |
| UP | A22Z-3443B-7 | | | |
| DOWN | A22Z-3443B-8 | | | |
| WER ON | A22Z-3443B-9 | | | |
| FF-ON | A22Z-3443B-10 | | | |
| | A22Z-3453B | | | |
| | A22Z-3453R | Attached to the Large-size Legend Plate Frame. | | |
| | A22Z-3453W | Material: Acrylic. | | |
| ent | A22Z-3453C | | | |
| | A22Z-3460 | | | |
| | A22Z-3460-1 | After printing on a film, | | |
| | A22Z-3460-2 | affix to the indicator Plate of the Lighted Pushbotton Switch. | | |
| | A22Z-3460-3 | (The back is coated with adhesive.) | | |
| | A22Z-3460-4 | | | |
| | | | | |


Remarks

Rubber tool used to easily replace Lamps.

Tool used to tighten nuts from the back of the panel.

Accessories / Tools

| Acces | sories | | | | | | | |
|-----------------|----------|------------|----------------------------|------------------------------|-------|-------------|--|--|
| lte | em | Appearance | Clas | ssification | | Part No. | Remarks | |
| | | | | | White | A22Z-3321 | | |
| | Standard | | With Snap-i Plate (with | n Legend Iout text) | Red | A22Z-3322 | | |
| | size | | | | Black | A22Z-3323 | Snap-in Legend Plate is acrylic. | |
| _egend Plate | | | Without Sna | p-in Legend | Plate | A22Z-3320 | | |
| Frames | | ~ | | | White | A22Z-3331 | | |
| | Large | | With Snap-i Plate (with | n Legend Iout text) | Red | A22Z-3332 | Chan in Lorend plate is comilia | |
| | size | | | | Black | A22Z-3333 | - Snap-in Legend plate is acrylic. | |
| | | | Without Sna | Without Snap-in Legend Plate | | A22Z-3330 | | |
| Lock | Ring | | F | Round | | A22Z-3360 | The Lock Ring is used when more secure lock feature is required. | |
| Socia | a Cono | | For flat models | | | A22Z-3600F | Used to prevent dust or water from entering the Operation Unit (Pushbutton, etc.). Color: opaque Material: silicon | |
| Sealin | g Caps | | For projection models | | | A22Z-3600T | | |
| Hole | plug | | F | Round | | | Can be plugged into pre-cut panel holes for future expansion. The color is black. | |
| | | | O | ne hole | | A22Z-B101 | | |
| Contro | l Boxes | | Тм | Two holes | | | Material: Polycarbonate resin. | |
| | | | Thr | Three holes | | | | |
| Cont | ootoro | | Applicable | ø7~9 |) | A22Z-3500-1 | Plastic connector used to extend | |
| Conne | ectors | | diameter (mm) ø9~1 | | 1 | A22Z-3500-2 | a cable from the Switch Box. (See page 30) | |



| Item | Appearance | Part No. | | | |
|-------------------|------------|-----------|--|--|--|
| Lamp Extractor | | A22Z-3901 | | | |
| Tightening wrench | | A22Z-3905 | | | |

A22R/M22R Series 19

Accessories / Tools

| | | 1 | | |
|--------|---------------|---|--|--|
| | Part No. | Remarks | | |
| | A22Z-3443B | | | |
| | A22Z-3443R | | | |
| | A22Z-3443W | | | |
| ent | A22Z-3443C | | | |
| 0 | A22Z-3443R-2 | | | |
| STOP | A22Z-3443R-4 | | | |
| | A22Z-3443B-1 | Attached to the Standard | | |
| START | A22Z-3443B-3 | Plate Frame. Material: Acrylic. | | |
| ON | A22Z-3443B-5 | | | |
| OFF | A22Z-3443B-6 | | | |
| UP | A22Z-3443B-7 | | | |
| DOWN | A22Z-3443B-8 | | | |
| WER ON | A22Z-3443B-9 | | | |
| FF-ON | A22Z-3443B-10 | | | |
| | A22Z-3453B | | | |
| | A22Z-3453R | Attached to the Large-size Legend Plate Frame. | | |
| | A22Z-3453W | Material: Acrylic. | | |
| ent | A22Z-3453C | | | |
| | A22Z-3460 | | | |
| | A22Z-3460-1 | After printing on a film, | | |
| | A22Z-3460-2 | affix to the indicator Plate of the Lighted Pushbotton Switch. | | |
| | A22Z-3460-3 | (The back is coated with adhesive.) | | |
| | A22Z-3460-4 | | | |
| | | | | |

Remarks

Rubber tool used to easily replace Lamps.

Tool used to tighten nuts from the back of the panel.

Specifications

Approved standards

| Switch unit | |
|--|---|
| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 6A 240VAC/10A 120VAC |
| EN | EN60947-5-1 (low voltage directive) 3A 240VAC (AC-15) |
| ccc | GB/14048.5-2001 3A 240VAC/1.5A 24VDC |
| Lamp unit | |
| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 24VAC/DC MAX |
| Voltage-reduction unit | |
| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 220VAC |
| ccc | GB/14048.5-2001 220VAC |
| Indicator | |
| | |

| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 12A: 12VAC/DC 24A: 24VAC/DC T2 : 220VAC |
|---------|--|
| ccc | GB/14048.5-2001 T2 : 220VAC |

Ratings

| Rated current | Rated voltage | Inducti | ve load |
|---------------|---------------|-------------------|--------------|
| (A) | (V) | Rated current (A) | Power facfor |
| 10 | 240 | 3 | 0.4 |

Rated current values are determined according to the testing conditions. The above ratings were obtained by conducting tests under the following conditions:

Ambient temperature: 20+/- 2°C Ambient humidity: 65+/-5%RH

Operating frequency: 30 operations/minute

• LED (For pushbutton unit)

| Operating voltage | Current consumption |
|-------------------|---------------------|
| AC/DC 6V±5% | 20mA |
| AC/DC 12V±5% | 20mA |
| AC/DC 24V±5% | 20mA |

• LED (For indicator unit)

| Operating voltage | Current consumption |
|-------------------|---------------------|
| AC/DC 12V±5% | 20mA |
| AC/DC 24V±5% | 20mA |

• Voltage reduction unit (For pushbutton and indicator units)

| Operating voltage | Current consumption |
|----------------------|---------------------|
| AC 200V(190 to 230V) | 20mA |

Characteristics

| Environment | | |
|-----------------------|--|--|
| Ambient temperature*1 | Non-lighted type: -20 to +60°C Lighted type: -20 to +50°C | |
| Ambient humidity | -35 to 85%RH | |
| Storage temperature*1 | -40 to +70°C | |
| Protective code*2 | IP65 | |
| Vibration resistance | 10 to 55Hz, Double amplitude 1.5 | |
| Shock resistance | Non-lighted type: 1,000m/s ² Lighted type: 600m/s ² | |
| | | |

*1: With no icing or condensation

*2: Protection against dust or water from the front of a mounting panel side

Operation

| | Operation | | Slow action | |
|------------------------|----------------|----------------------------------|--|--|
| Operating frequency | Mechanical | Momentary operation: 60 operatio | | |
| | Electrical | Knob-type and Key-type selector: | | |
| | Mechanical dur | ability | Momentary switch :3,000,000 ope Alternate, Key/Knob Selector swit | |

• Electrical Characteristics (Switch block)

| Insulation resistance | 100M Ω Minimum (At 500VDC) |
|-----------------------------------|--|
| Dielectric strength | Between terminals of same polarit Between terminals of different pola |
| Rating | AC-15, A600, Ue=240V, le=3A |
| Rated insulation voltage | Ui=600V, Pollution degree: 3 |
| Conditional short-circuit current | 10A, IEC60209-1 |
| Electrical durability | 500,000 operations Minimum (at A |

A22R/M22R Series

21

Characteristics

5mm

ons/minute max.

: 30 operations/minute max.

perations itches: 300,000 operations

rity: AC2,500V 50/60Hz for 1 minute blarity: AC2,500V 50/60Hz for 1 minute

AC 240V, 3A, cosø=0.4)

Specifications

Approved standards

| Switch unit | |
|--|---|
| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 6A 240VAC/10A 120VAC |
| EN | EN60947-5-1 (low voltage directive) 3A 240VAC (AC-15) |
| ccc | GB/14048.5-2001 3A 240VAC/1.5A 24VDC |
| Lamp unit | |
| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 24VAC/DC MAX |
| Voltage-reduction unit | |
| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 220VAC |
| ccc | GB/14048.5-2001 220VAC |
| Indicator | |
| | |

| UL, cUL | UL 508/CSA C22.2 No.14 File No. E76675 12A: 12VAC/DC 24A: 24VAC/DC T2 : 220VAC |
|---------|--|
| ccc | GB/14048.5-2001 T2 : 220VAC |

Ratings

| Rated current | Rated voltage | Inducti | ve load |
|---------------|---------------|-------------------|--------------|
| (A) | (V) | Rated current (A) | Power facfor |
| 10 | 240 | 3 | 0.4 |

Rated current values are determined according to the testing conditions. The above ratings were obtained by conducting tests under the following conditions:

Ambient temperature: 20+/- 2°C Ambient humidity: 65+/-5%RH

Operating frequency: 30 operations/minute

• LED (For pushbutton unit)

| Operating voltage | Current consumption |
|-------------------|---------------------|
| AC/DC 6V±5% | 20mA |
| AC/DC 12V±5% | 20mA |
| AC/DC 24V±5% | 20mA |

• LED (For indicator unit)

| Operating voltage | Current consumption |
|-------------------|---------------------|
| AC/DC 12V±5% | 20mA |
| AC/DC 24V±5% | 20mA |

• Voltage reduction unit (For pushbutton and indicator units)

| Operating voltage | Current consumption |
|----------------------|---------------------|
| AC 200V(190 to 230V) | 20mA |

Characteristics

| Environment | | |
|-----------------------|--|--|
| Ambient temperature*1 | Non-lighted type: -20 to +60°C Lighted type: -20 to +50°C | |
| Ambient humidity | -35 to 85%RH | |
| Storage temperature*1 | -40 to +70°C | |
| Protective code*2 | IP65 | |
| Vibration resistance | 10 to 55Hz, Double amplitude 1.5 | |
| Shock resistance | Non-lighted type: 1,000m/s ² Lighted type: 600m/s ² | |
| | | |

*1: With no icing or condensation

*2: Protection against dust or water from the front of a mounting panel side

Operation

| | Operation | | Slow action | |
|---|------------------------|------------|---|--|
| | Operating frequency | Mechanical | Momentary operation: 60 operatio | |
| | | Electrical | Knob-type and Key-type selector: | |
| 2 | Mechanical dur | ability | Momentary switch :3,000,000 ope Alternate, Key/Knob Selector swi | |

• Electrical Characteristics (Switch block)

| Insulation resistance | 100M Ω Minimum (At 500VDC) | |
|-----------------------------------|--|--|
| Dielectric strength | Between terminals of same polarit Between terminals of different pola | |
| Rating | AC-15, A600, Ue=240V, le=3A | |
| Rated insulation voltage | Ui=600V, Pollution degree: 3 | |
| Conditional short-circuit current | 10A, IEC60209-1 | |
| Electrical durability | 500,000 operations Minimum (at A | |

A22R/M22R Series

21

Characteristics

5mm

ons/minute max.

: 30 operations/minute max.

perations itches: 300,000 operations

rity: AC2,500V 50/60Hz for 1 minute blarity: AC2,500V 50/60Hz for 1 minute

AC 240V, 3A, cosø=0.4)

Characteristics

Operating characteristics

• Pushbutton switch (1a1b)

| Total Travel Force (TTF) | 29.4N Maximum |
|--------------------------|---------------|
| Total Travel (TT) | 5.5mm Maximum |

• Knob-type selector switch (1a1b)

| Total Travel Force (TTF) | Manual reset: 0.34N·m Maximum * Auto-reset 2-notch: 0.25N·m * 3-notch: 0.34N·m * | |
|--------------------------|--|--|
| Total Travel (TT) | 2-notch: approx. 90 degree (3-notch: approx.45 degree) | |
| Releasing Force (RF) | Manual reset: 0.34N·m Maximum * | |


* Rotation torque for knob type/key type selector switches.

Key-type selector switch (1a1b)

| | Total Travel Force (TTF) | Manual reset: 0.34N·m Maximum * Auto-reset 2-notch: 0.25N·m * 3-notch: 0.34N·m * |
|--|--------------------------|--|
| | Total Travel (TT) | 2-notch: approx. 90 degree (3-notch: approx.45 degree) |
| | Releasing Force (RF) | Manual reset: 0.34N·m Maximum * |

* Rotation torque for knob type/key type selector switches.

Terminal Arrangement




Terminal connection

| Туре | |
|---|---|
| Non-lighted (1a1b) | |
| Lighted without voltage reduction unit (1a1b) | |
| Lighted with voltage reduction unit (1a1b) | (|
| | (|

A22R/M22R Series 23

Terminal



Characteristics

Operating characteristics

• Pushbutton switch (1a1b)

| Total Travel Force (TTF) | 29.4N Maximum |
|--------------------------|---------------|
| Total Travel (TT) | 5.5mm Maximum |

• Knob-type selector switch (1a1b)

| Total Travel Force (TTF) | Manual reset: 0.34N·m Maximum * Auto-reset 2-notch: 0.25N·m * 3-notch: 0.34N·m * | |
|--------------------------|--|--|
| Total Travel (TT) | 2-notch: approx. 90 degree (3-notch: approx.45 degree) | |
| Releasing Force (RF) | Manual reset: 0.34N·m Maximum * | |


* Rotation torque for knob type/key type selector switches.

Key-type selector switch (1a1b)

| | Total Travel Force (TTF) | Manual reset: 0.34N·m Maximum * Auto-reset 2-notch: 0.25N·m * 3-notch: 0.34N·m * |
|--|--------------------------|--|
| | Total Travel (TT) | 2-notch: approx. 90 degree (3-notch: approx.45 degree) |
| | Releasing Force (RF) | Manual reset: 0.34N·m Maximum * |

* Rotation torque for knob type/key type selector switches.

Terminal Arrangement




Terminal connection

| Туре | |
|---|---|
| Non-lighted (1a1b) | |
| Lighted without voltage reduction unit (1a1b) | |
| Lighted with voltage reduction unit (1a1b) | (|
| | (|

A22R/M22R Series 23

Terminal



Precautions

Precautions

/ Warning

Do not wire and/or touch the switch terminal while power is supplied to the switch to avoid electric shock.



Correct Use

Mounting

- Always make sure that the power is turned OFF before mounting, removing, or wiring the Switch, or performing maintenance.
- Do not tighten the mounting ring more than necessary using tools such as pointed-nose pliers. Doing so will damage the mounting ring. The tightening torque is 0.98 to 1.96N·m.
 Recommended panel thickness: 1 to 5 mm.
- Wiring
- Terminal screws must be Phillips with a square washer.
- The tightening torque is 1.08 to 1.27N·m.
- Single wires, stranded wires and crimp terminals except round type can be connected to the Switch.
- Applicable Wire Size


Strand wire: 2mm² Maximum Solid wire: 1.6mm diameter Maximum Bare Crimp Terminals



Crimp Terminal with Insulating Sheath




- Secure appropriate insulation distance after wiring of the Switch.
- Perform wiring so that the lead wires will not be caught on other objects as this will cause stress on the Switch terminals. Wire the Switch so that there is slack in the lead wires and fix lead wires at intermediate points. If the panel to which the Switch is mounted needs to be opened and closed for maintenance purpose, perform wiring so that the opening and closing of the panel will not interfere with the wiring.




Operational Environment

- The IP65 model is designed with a degree of protection so that it will not sustain damage if it is subject to water from any direction to front of the panel.
- This Switch is indoor use only. Outdoor use of the Switch will cause operation failure of the Switch.
- Do not use the Switch in the water, oil, or in locations where water, oils, detergent, chemicals, or solvent is applied to the Switch always. Otherwise, switching failure will be happened.
- Do not use the Switch under the environmental condition where corrosive gas (ammonia, chlorine, dioxide sulfur...etc.) is generated. Otherwise, the Switch will corrode.
- Do not use the Switch in locations where dust, metal or plastic dust exists. Dust will accumulate o the Switch, and then the Switch wouldn't operate normally.
- Do not use the Switch under the environmental condition where excessive vibration or shock exists. Otherwise, incorrect switching would occur.
- Electrical Conditions
- The switching load capacity of the Switch greatly varies between AC and DC. Always be sure to apply the rated load. The control capacity will drastically drop if it is a DC load. This is because a DC load has no current zero-cross point, unlike an AC load. Therefore, if an arc is generated, it may continue for a comparatively long time. Furthermore, the current direction is always the same, which results in a contact relocation phenomena whereby the contacts easily stick to each other and do not separate when the surfaces of the contacts are uneven.
- Some types of load have a great difference between normal current and inrush current. Make sure that the inrush current is within the permissible value. The greater the inrush current in the closed circuit is, the greater the contact abrasion or shift will be. Consequently, contact weld, contact separation failures, or insulation failures may result. Furthermore, the Switch may be broken or damaged.
- If the load is inductive, counter-electromotive voltage will be generated. The higher the voltage is, the higher the generated energy will be, which increase the abrasion of the contacts and contact relocation phenomena. Be sure to use the Switch within the rated conditions.



Before using the Switch, be sure to test the Switch under actual conditions.
This product is a standard load type Switch. Using the Switch for opening and closing a microload circuit may cause contact failure. Use the Switch within the operating range as shown in below chart.



• When use the Switch for opening and closing a microload or large-load, use the Switch with an appropriate relay.

Precautions

• Switching

- Do not use the Switch for loads that exceed the rated switching capacity or other contact ratings. Doing so may result in contact weld, separation failure, or insulation failures. Furthermore, the Switch may be broken or damaged.
- Do not touch the charged switch terminals while power is supplied, otherwise an electric shock may be received.
- The life of the Switch varies greatly with switching conditions. Before using the Switch, be sure to test the Switch under actual conditions. Make sure that the number of switching operations is within the permissible range. If a deteriorated Switch is used continuously, insulation failures, contact weld, contact failures, switch damage, or

switch burnout may result.
Do not apply excessive or incorrect voltages to the Switch or incorrectly wire the terminals. Otherwise, the Switch may not function properly and have an educate effect on external.

- function properly and have an adverse effect on external circuitry. Furthermore, the Switch itself may become damaged or burnt.
- Do not use the Switch in locations where flammable or explosive gasses are present. Otherwise switching arcs or heat radiation may cause a fire or explosion.
- Do not drop or disassemble the Switch, otherwise it may not be capable of full performance. Furthermore, it may be broken or burnt.

• LED

- The LED current-limiting resistor is built-in, so internal resistance is not required.
- If commercially available LEDs are used, select the ones that meet the following conditions: Base: BA9S/13□

Overall length: 26mm Maximum Power consumption: 2.6 W Maximum

Storage

- When the Switch is left unused or stored for long periods, the ambient conditions can have a great effect on the condition of the Switch. In certain environments, leaving the Switch exposed may result I deterioration (i.e., oxidation, or the creation of an oxide film) of the contacts and terminals, causing the contact resistance to increase, and making it difficult to solder the lead wires. Therefore, store in a well-ventilated room, inside, for example, a non-hygroscopic
- case, in a location where no corrosive gasses are present.
 If the Switch is stored in a location where it will be exposed to direct light, colored resin in the colored plate may fade. Therefore, do not store the Switch I locations where it will be exposed to direct light.


A22R/M22R Series

25


Precautions

Mechanical Conditions
Operating the Switch using a

 Operating the Switch using a hard object (e.g., metal), or with a large or sudden force, may deform or damage the Switch, resulting in faulty or rough operation, or shortening of the Switch life.



 The pushbutton surface is composed of resin. Therefore, do not attempt to operate the pushbutton using a sharp object, such as a screwdriver or a pair of tweezers. Also, do not drop, throw, or knock the Switch. Doing so may damage or deform the pushbutton surface and result in faulty operation.



· Periodic maintenance is required to use the Switch stably.

Precautions

Precautions

/ Warning

Do not wire and/or touch the switch terminal while power is supplied to the switch to avoid electric shock.



Correct Use

Mounting

- Always make sure that the power is turned OFF before mounting, removing, or wiring the Switch, or performing maintenance.
- Do not tighten the mounting ring more than necessary using tools such as pointed-nose pliers. Doing so will damage the mounting ring. The tightening torque is 0.98 to 1.96N·m.
 Recommended panel thickness: 1 to 5 mm.
- Wiring
- Terminal screws must be Phillips with a square washer.
- The tightening torque is 1.08 to 1.27N·m.
- Single wires, stranded wires and crimp terminals except round type can be connected to the Switch.
- Applicable Wire Size


Strand wire: 2mm² Maximum Solid wire: 1.6mm diameter Maximum Bare Crimp Terminals



Crimp Terminal with Insulating Sheath




- Secure appropriate insulation distance after wiring of the Switch.
- Perform wiring so that the lead wires will not be caught on other objects as this will cause stress on the Switch terminals. Wire the Switch so that there is slack in the lead wires and fix lead wires at intermediate points. If the panel to which the Switch is mounted needs to be opened and closed for maintenance purpose, perform wiring so that the opening and closing of the panel will not interfere with the wiring.




Operational Environment

- The IP65 model is designed with a degree of protection so that it will not sustain damage if it is subject to water from any direction to front of the panel.
- This Switch is indoor use only. Outdoor use of the Switch will cause operation failure of the Switch.
- Do not use the Switch in the water, oil, or in locations where water, oils, detergent, chemicals, or solvent is applied to the Switch always. Otherwise, switching failure will be happened.
- Do not use the Switch under the environmental condition where corrosive gas (ammonia, chlorine, dioxide sulfur...etc.) is generated. Otherwise, the Switch will corrode.
- Do not use the Switch in locations where dust, metal or plastic dust exists. Dust will accumulate o the Switch, and then the Switch wouldn't operate normally.
- Do not use the Switch under the environmental condition where excessive vibration or shock exists. Otherwise, incorrect switching would occur.
- Electrical Conditions
- The switching load capacity of the Switch greatly varies between AC and DC. Always be sure to apply the rated load. The control capacity will drastically drop if it is a DC load. This is because a DC load has no current zero-cross point, unlike an AC load. Therefore, if an arc is generated, it may continue for a comparatively long time. Furthermore, the current direction is always the same, which results in a contact relocation phenomena whereby the contacts easily stick to each other and do not separate when the surfaces of the contacts are uneven.
- Some types of load have a great difference between normal current and inrush current. Make sure that the inrush current is within the permissible value. The greater the inrush current in the closed circuit is, the greater the contact abrasion or shift will be. Consequently, contact weld, contact separation failures, or insulation failures may result. Furthermore, the Switch may be broken or damaged.
- If the load is inductive, counter-electromotive voltage will be generated. The higher the voltage is, the higher the generated energy will be, which increase the abrasion of the contacts and contact relocation phenomena. Be sure to use the Switch within the rated conditions.



Before using the Switch, be sure to test the Switch under actual conditions.
This product is a standard load type Switch. Using the Switch for opening and closing a microload circuit may cause contact failure. Use the Switch within the operating range as shown in below chart.



• When use the Switch for opening and closing a microload or large-load, use the Switch with an appropriate relay.

Precautions

• Switching

- Do not use the Switch for loads that exceed the rated switching capacity or other contact ratings. Doing so may result in contact weld, separation failure, or insulation failures. Furthermore, the Switch may be broken or damaged.
- Do not touch the charged switch terminals while power is supplied, otherwise an electric shock may be received.
- The life of the Switch varies greatly with switching conditions. Before using the Switch, be sure to test the Switch under actual conditions. Make sure that the number of switching operations is within the permissible range. If a deteriorated Switch is used continuously, insulation failures, contact weld, contact failures, switch damage, or

switch burnout may result.
Do not apply excessive or incorrect voltages to the Switch or incorrectly wire the terminals. Otherwise, the Switch may not function properly and have an educate effect on external.

- function properly and have an adverse effect on external circuitry. Furthermore, the Switch itself may become damaged or burnt.
- Do not use the Switch in locations where flammable or explosive gasses are present. Otherwise switching arcs or heat radiation may cause a fire or explosion.
- Do not drop or disassemble the Switch, otherwise it may not be capable of full performance. Furthermore, it may be broken or burnt.

• LED

- The LED current-limiting resistor is built-in, so internal resistance is not required.
- If commercially available LEDs are used, select the ones that meet the following conditions: Base: BA9S/13□

Overall length: 26mm Maximum Power consumption: 2.6 W Maximum

Storage

- When the Switch is left unused or stored for long periods, the ambient conditions can have a great effect on the condition of the Switch. In certain environments, leaving the Switch exposed may result I deterioration (i.e., oxidation, or the creation of an oxide film) of the contacts and terminals, causing the contact resistance to increase, and making it difficult to solder the lead wires. Therefore, store in a well-ventilated room, inside, for example, a non-hygroscopic
- case, in a location where no corrosive gasses are present.
 If the Switch is stored in a location where it will be exposed to direct light, colored resin in the colored plate may fade. Therefore, do not store the Switch I locations where it will be exposed to direct light.


A22R/M22R Series

25


Precautions

Mechanical Conditions
Operating the Switch using a

 Operating the Switch using a hard object (e.g., metal), or with a large or sudden force, may deform or damage the Switch, resulting in faulty or rough operation, or shortening of the Switch life.





 The pushbutton surface is composed of resin. Therefore, do not attempt to operate the pushbutton using a sharp object, such as a screwdriver or a pair of tweezers. Also, do not drop, throw, or knock the Switch. Doing so may damage or deform the pushbutton surface and result in faulty operation.



· Periodic maintenance is required to use the Switch stably.


Mounting to the Panel





- · Recommended panel thickness is 1 to 5mm.
- In outer surface treatment such as coating is performed for the panel, the panel dimensions after outer surface treatment must meet the specified panel dimensions.
- 2 Matrix Installation
- (1) The following panel hole dimensions apply when Switch Unit and the Standard-size Legend Plate Frame and Lock Ring are mounted, and lead wires are connected directly to the Switch Block.


(2) The following panel hole dimensions apply when the Large-size Legend Plate Frame is mounted, and when crimp terminals are connected to the Switch Block terminals.




| Type of crimp terminal | Dimension A |
|--|---------------|
| Bare crimp terminals | 51 mm Minimum |
| Crimp terminals with insulating sheath | 60 mm Minimum |

Note: The above dimensions are the minimum dimensions for when the wires described under "Applicable Wire Size". If a different wires are used, the wiring dimensions may be different so determine an appropriate pitch before setup


- ③ Mounting the Operation Unit on the Panel
- Insert the Operation Unit (Pushbutton, etc.) from the front surface of the panel, insert the Lock Ring and the mounting nut from the terminal side, then tighten the nut. Before tightening, check that the rubber washer is present between the Pushbutton Unit and the panel.
- When using a Legend Plate Frame, put one rubber washer each between the Legend Plate Frame and the panel and between the Operation Unit and the Legend Plate Frame. (One rubber washer will be provided when one Legend Plate Frame is ordered.)
- Align the Lock Ring with the groove in the casing, then insert the Lock Ring so that its edge is located on the panel side.
- Tighten the mounting nut at a torque of 0.98 to 1.96N·m. • When using a Lock Ring, replace with the supplied Lock Ring,
- insert the projecting part into the lock slot, and then tighten the mounting nut.




④ Mounting the Switch on the Pushbutton Unit • Insert the Pushbutton Unit into the Switch Unit, aligning the arrow mark inscribed on the Case with the lever on the Switch Blocks, then move the lever in the direction indicated by the arrow in the following figure.




- ⑤ Removing the Switch
- Move the lever in the direction indicated by the arrow in the following figure, then pull the Pushbutton Unit or the Switch Blocks
- Since the lever has a hole with an inside diameter of 6.5mm, the lever can be moved in the specified direction by inserting a screwdriver into the hole and then moving the screwdriver.




terminal side.




Mounting to the Panel





- · Recommended panel thickness is 1 to 5mm.
- In outer surface treatment such as coating is performed for the panel, the panel dimensions after outer surface treatment must meet the specified panel dimensions.
- 2 Matrix Installation
- (1) The following panel hole dimensions apply when Switch Unit and the Standard-size Legend Plate Frame and Lock Ring are mounted, and lead wires are connected directly to the Switch Block.


(2) The following panel hole dimensions apply when the Large-size Legend Plate Frame is mounted, and when crimp terminals are connected to the Switch Block terminals.




| Type of crimp terminal | Dimension A |
|--|---------------|
| Bare crimp terminals | 51 mm Minimum |
| Crimp terminals with insulating sheath | 60 mm Minimum |

Note: The above dimensions are the minimum dimensions for when the wires described under "Applicable Wire Size". If a different wires are used, the wiring dimensions may be different so determine an appropriate pitch before setup


- ③ Mounting the Operation Unit on the Panel
- Insert the Operation Unit (Pushbutton, etc.) from the front surface of the panel, insert the Lock Ring and the mounting nut from the terminal side, then tighten the nut. Before tightening, check that the rubber washer is present between the Pushbutton Unit and the panel.
- When using a Legend Plate Frame, put one rubber washer each between the Legend Plate Frame and the panel and between the Operation Unit and the Legend Plate Frame. (One rubber washer will be provided when one Legend Plate Frame is ordered.)
- Align the Lock Ring with the groove in the casing, then insert the Lock Ring so that its edge is located on the panel side.
- Tighten the mounting nut at a torque of 0.98 to 1.96N·m. • When using a Lock Ring, replace with the supplied Lock Ring,
- insert the projecting part into the lock slot, and then tighten the mounting nut.




④ Mounting the Switch on the Pushbutton Unit • Insert the Pushbutton Unit into the Switch Unit, aligning the arrow mark inscribed on the Case with the lever on the Switch Blocks, then move the lever in the direction indicated by the arrow in the following figure.




- ⑤ Removing the Switch
- Move the lever in the direction indicated by the arrow in the following figure, then pull the Pushbutton Unit or the Switch Blocks
- Since the lever has a hole with an inside diameter of 6.5mm, the lever can be moved in the specified direction by inserting a screwdriver into the hole and then moving the screwdriver.




terminal side.



Mounting/Replacing the Color Cap




Assembling the Cap



Installing/Replacing the LED

| ① Installing/Replacing from the Panel Surface | ② Installing/Replacing on the Switch |
|--|---|
| Insert the Lamp Extractor(A22Z-3901) into the lamp, then rotate the Extractor while pressing it. | Grip the lamp with your fingers, then rotate the lamp while pressing it against the Switch. |
| | |

Mounting/Replacing the Switch Unit and Indicator Unit




A22R/M22R Series 29


Installation

2 Removing the Switch Base


• Insert a screwdriver between the Mounting Latch and the Switch Block, then push down the screwdriver in the direction indicated by the arrow in the following figure.



Mounting/Replacing the Color Cap




Assembling the Cap



Installing/Replacing the LED

| ① Installing/Replacing from the Panel Surface | ② Installing/Replacing on the Switch |
|--|---|
| • Insert the Lamp Extractor(A22Z-3901) into the lamp, then rotate the Extractor while pressing it. | Grip the lamp with your fingers, then rotate the lamp while pressing it against the Switch. |
| | |

Mounting/Replacing the Switch Unit and Indicator Unit




A22R/M22R Series 29

Installation

2 Removing the Switch Base


• Insert a screwdriver between the Mounting Latch and the Switch Block, then push down the screwdriver in the direction indicated by the arrow in the following figure.



Control Box


① Mounting the Switch

The Standard-size Legend Plate Frame can be mounted. Mount the Switch in the same way as for an ordinary panel.



2 Creating a Cable Port Hole


Place the tip of a screwdriver on the surface where the cable port hole is to be created with the cover attached and strike the screwdriver to punch a hole. Attempts to punch a hole on the other side of the case will damage the Box.



3 Securing the Connector Cable

① Insert the connector into the cable port in the Box and secure with the fixing nut inside the box.

- ^② Open a hole in the thin rubber section of the rubber ring.
- ③ Pass the tightening cap through the cable, insert the cable into the connector, and tighten the hexagonal nut to secure the cable.



Engraving

- Engrave the characters on the surface on the Cap. Make sure that the characters are aligned parallel to the imaginary lie connecting the two protruding portions to the left and right of the Cap.
- The characters must not be engraved deeper than 0.5mm. Apply an alcohol-based paint coating, such as melamine, alkyd, or acrylic resin paint coating, to the engraved characters.

Protruding portions of the Cap




Material: Acrylic

- Engrave the characters directly on the matted side of the Snap-in Legend Plate.
- The characters must be engraved no deeper than 0.5mm.
- Apply alcohol-based paint coating to the engraved characters.
- If the Snap-in Legend Plate is transparent, engrave the mirror-written characters on the back of the Snap-in Legend Plate and apply paint coating of a different color to the remaining part of the Snap-in Legend Plate.


Afflixing Character Film

Hold the Cap, remove the cardboard o the Film, and attach the Film to the Cap. Make sure that the protruding portions of the Cap engage the cutout portions of the Film and that the characters are aligned parallel to the imaginary line connecting the two protruding portions to the left and right of the Cap.



Precautions when use the Indicators

- Lock Ring (A22Z-3360) cannot be used. • When use the Legend Plate Frames
- (A22Z-332, A22Z-333) cut the projection




31

Installation

Mounting and Dismounting Snap-in Legend


- · Press and secure the Snap-in Legend Plate onto the Legend Plate Frame.
- The direction of the characters will vary with the mounting direction of the control panel if the Switch is a knob or key selector model.




• To easily remove the Snap-in Legend Plate from the Legend Plate Frame mounted to the panel. Insert a Tool with a thin tip into the space between the Snap-in Legend Plate and the Legend Plate Frame



- The Snap-in Legend Plate is easily removed by pressing the
- Snap-I Legend Plate from the back of the Legend Plate Frame. The Legend Plate Frame is made of acrylic resin, which is easily damaged by shock. Be sure to handle the Legend Plate Frame with care




• When use the Control Box (A22Z-B10⁻), cut the projection portions shown in the below fig.



Control Box


① Mounting the Switch

The Standard-size Legend Plate Frame can be mounted. Mount the Switch in the same way as for an ordinary panel.



2 Creating a Cable Port Hole


Place the tip of a screwdriver on the surface where the cable port hole is to be created with the cover attached and strike the screwdriver to punch a hole. Attempts to punch a hole on the other side of the case will damage the Box.



3 Securing the Connector Cable

① Insert the connector into the cable port in the Box and secure with the fixing nut inside the box.


- ^② Open a hole in the thin rubber section of the rubber ring.
- ③ Pass the tightening cap through the cable, insert the cable into the connector, and tighten the hexagonal nut to secure the cable.



Engraving

- Engrave the characters on the surface on the Cap. Make sure that the characters are aligned parallel to the imaginary lie connecting the two protruding portions to the left and right of the Cap.
- The characters must not be engraved deeper than 0.5mm. Apply an alcohol-based paint coating, such as melamine, alkyd, or acrylic resin paint coating, to the engraved characters.

Protruding portions of the Cap




Material: Acrylic

- Engrave the characters directly on the matted side of the Snap-in Legend Plate.
- The characters must be engraved no deeper than 0.5mm.
- Apply alcohol-based paint coating to the engraved characters.
- If the Snap-in Legend Plate is transparent, engrave the mirror-written characters on the back of the Snap-in Legend Plate and apply paint coating of a different color to the remaining part of the Snap-in Legend Plate.


Afflixing Character Film

Hold the Cap, remove the cardboard o the Film, and attach the Film to the Cap. Make sure that the protruding portions of the Cap engage the cutout portions of the Film and that the characters are aligned parallel to the imaginary line connecting the two protruding portions to the left and right of the Cap.



Precautions when use the Indicators

- Lock Ring (A22Z-3360) cannot be used. • When use the Legend Plate Frames
- (A22Z-332, A22Z-333) cut the projection portions shown in the below fig.




31

Installation

Mounting and Dismounting Snap-in Legend


- · Press and secure the Snap-in Legend Plate onto the Legend Plate Frame.
- The direction of the characters will vary with the mounting direction of the control panel if the Switch is a knob or key selector model.




• To easily remove the Snap-in Legend Plate from the Legend Plate Frame mounted to the panel. Insert a Tool with a thin tip into the space between the Snap-in Legend Plate and the Legend Plate Frame



- The Snap-in Legend Plate is easily removed by pressing the
- Snap-I Legend Plate from the back of the Legend Plate Frame. The Legend Plate Frame is made of acrylic resin, which is easily damaged by shock. Be sure to handle the Legend Plate Frame with care



• When use the Control Box (A22Z-B10⁻), cut the projection portions shown in the below fig.



Terms and Conditions of Sale

- 1. Offer; Acceptance. These terms and conditions (these "Terms") are deemed part of all quotes, agreements, purchase orders, acknowledgments, price lists, catalogs, manuals, brochures and other documents, whether electronic or in writing, relating to the sale of products or services (collectively, the "Products") by Omron Electronics LLC and its subsidiary companies ("<u>Omron</u>"). Omron objects to any terms or conditions proposed in Buyer's purchase order or other documents which are inconsistent with, or in addition to, these Terms.
- 2. Prices; Payment Terms. All prices stated are current, subject to change without notice by Omron. Omron reserves the right to increase or decrease prices on any unshipped portions of outstanding orders. Payments for Products are due net 30 days unless otherwise stated in the invoice
- Discounts. Cash discounts, if any, will apply only on the net amount of invoices sent to Buyer after deducting transportation charges, taxes and duties, and will be allowed only if (i) the invoice is paid according to Omron's payment terms and (ii) Buyer has no past due amounts.
- Interest. Omron, at its option, may charge Buyer 1-1/2% interest per month or the maximum legal rate, whichever is less, on any balance not paid within the 4. stated terms
- Orders. Omron will accept no order less than \$200 net billing.
- Governmental Approvals. Buyer shall be responsible for, and shall bear all costs involved in, obtaining any government approvals required for the impor-6 tation or sale of the Products
- 7. Taxes. All taxes, duties and other governmental charges (other than general real property and income taxes), including any interest or penalties thereon, ctly or indirectly on Omron or required to be collected directly or indirectly by Omron for the manufacture, production, sale, delivery, importation, consumption or use of the Products sold hereunder (including customs duties and sales, excise, use, turnover and license taxes) shall be charged to and remitted by Buyer to Omron.
 <u>Financial</u> If the financial position of Buyer at any time becomes unsatisfactory
- to Omron, Omron reserves the right to stop shipments or require satisfactory security or payment in advance. If Buyer fails to make payment or otherwise comply with these Terms or any related agreement. Omron may (without liability and in addition to other remedies) cancel any unshipped portion of Products sold hereunder and stop any Products in transit until Buyer pays all amounts, including amounts payable hereunder, whether or not then due, which are owing to it by Buyer. Buyer shall in any event remain liable for all unpaid accounts. 9. Cancellation: Etc. Orders are not subject to rescheduling or cancellation
- unless Buyer indemnifies Omron against all related costs or expenses. 10. <u>Force Majeure</u>. Omron shall not be liable for any delay or failure in delivery resulting from causes beyond its control, including earthquakes, fires, floods strikes or other labor disputes, shortage of labor or materials, accidents to machinery, acts of sabotage, riots, delay in or lack of transportation or the requirements of any government authority.
- Shipping: Delivery. Unless otherwise expressly agreed in writing by Omron: a. Shipments shall be by a carrier selected by Omron; Omron will not drop ship except in "break down" situations.
- b. Such carrier shall act as the agent of Buyer and delivery to such carrier shall constitute delivery to Buyer;
- c. All sales and shipments of Products shall be FOB shipping point (unless otherwise stated in writing by Omron), at which point title and risk of loss shall pass from Omron to Buyer; provided that Omron shall retain a security interest in the Products until the full purchase price is paid;
- d. Delivery and shipping dates are estimates only; and e. Omron will package Products as it deems proper for protection against normal handling and extra charges apply to special conditions. 12. <u>Claims</u>. Any claim by Buyer against Omron for shortage or damage to the
- Products occurring before delivery to the carrier must be presented in writing to Omron within 30 days of receipt of shipment and include the original transportation bill signed by the carrier noting that the carrier received the Products from Omron in the condition claimed.
- 13. Warranties. (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied. (b) <u>Limitations</u>. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABIL-

ITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or oth-erwise of any intellectual property right. (c) <u>Buyer Remedy</u>. Omron's sole obli-gation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product: provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamina-tion, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty. See http://www.omron247.com or contact your Omron representative for published information.

- Limitation on Liability; Etc. OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.
- Indemnities. Buyer shall indemnify and hold harmless Omron Companies and their employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim investigation, litigation or proceeding (whether or not Omron is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Products. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless Omron and defend or set tle any action brought against such Companies to the extent based on a claim that any Product made to Buyer specifications infringed intellectual property rights of another party. <u>Property: Confidentiality.</u> Any intellectual property in the Products is the exclu-
- sive property of Omron Companies and Buyer shall not attempt to duplicate it in any way without the written permission of Omron. Notwithstanding any charges to Buyer for engineering or tooling, all engineering and tooling shall remain the exclusive property of Omron. All information and materials supplied by Omron to Buyer relating to the Products are confidential and proprietary, and Buyer shall limit distribution thereof to its trusted employees and strictly
- prevent disclosure to any third party. <u>Export Controls.</u> Buyer shall comply with all applicable laws, regulations and licenses regarding (i) export of products or information; (iii) sale of products to "forbidden" or other proscribed persons; and (ii) disclosure to non-citizens of regulated technology or information. <u>Miscellaneous</u>. (a) <u>Waiver</u>. No failure or delay by Omron in exercising any right and no course of dealing between Buyer and Omron shall operate as a waiver
- of rights by Omron. (b) Assignment. Buyer may not assign its rights hereunder without Omron's written consent. (c) Law. These Terms are governed by the law of the jurisdiction of the home office of the Omron company from which Buyer is purchasing the Products (without regard to conflict of law principles). (d) Amendment. These Terms constitute the entire agreement between Buyer and Omron relating to the Products, and no provision may be changed or waived unless in writing signed by the parties. (e) <u>Severability</u>. If any provi-sion hereof is rendered ineffective or invalid, such provision shall not invalidate any other provision. (f) <u>Setoff</u>. Buyer shall have no right to set off any amounts against the amount owing in respect of this invoice. (g) <u>Definitions</u>. As used herein, "<u>including</u>" means "including without limitation"; and "<u>Omron Compa-</u> nies" (or similar words) mean Omron Corporation and any direct or indirect subsidiary or affiliate thereof.

Certain Precautions on Specifications and Use

- 1. Suitability of Use. Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system Buyer shall take application responsibility in all cases but the following is a non-exhaustive list of applications for which particular attention must be given: (i) Outdoor use, uses involving potential chemical contamination or electrical rference, or conditions or uses not described in this document.
- (ii) Use in consumer products or any use in significant quantities.

(iii) Energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations (iv) Systems, machines and equipment that could present a risk to life or prop-erty. Please know and observe all prohibitions of use applicable to this Prod-

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO

ADDRESS THE RISKS, AND THAT THE OMRON'S PRODUCT IS PROP-ERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

- Programmable Products. Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof
- Performance Data. Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitabil-ity and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability. Change in Specifications. Product specifications and accessories may be
- changed at any time based on improvements and other reasons. It is our prac-tice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifica-tions of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.
- Errors and Omissions. Information presented by Omron Companies has been checked and is believed to be accurate: however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.



OMRON INDUSTRIAL AUTOMATION • THE AMERICAS HEADQUARTERS • Schaumburg, IL USA • 847.843.7900 • 800.556.6766 • www.omron247.com

OMRON CANADA, INC. • HEAD OFFICE Toronto, ON, Canada • 416.286.6465 • 866.986.6766 • www.omron247.com OMRON ARGENTINA • SALES OFFICE Cono Sur • 54.11.4783.5300

OTHER OMRON LATIN AMERICA SALES

OMRON CHILE • SALES OFFICE Santiago • 56.9.9917.3920

México DF • 52.55.59.01.43.00 • 001.800.556.6766 • mela@omron.com **OMRON ELECTRONICS DE MEXICO • SALES OFFICE** Apodaca, N.L. • 52.81.11.56.99.20 • 001.800.556.6766 • mela@omron.com

OMRON ELETRÔNICA DO BRASIL LTDA • HEAD OFFICE São Paulo, SP, Brasil • 55.11.2101.6300 • www.omron.com.br

OMRON ELECTRONICS DE MEXICO • HEAD OFFICE

OMRON EUROPE B.V. • Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands. • Tel: +31 (0) 23 568 13 00 • Fax: +31 (0) 23 568 13 88 • www.industrial.omron.eu

54.11.4783.5300

Authorized Distributor:

Automation Systems

Programmable logic controllers (PLC) • Human machine interfaces (HMI) • Remote I/O
 Industrial PC's • Software

Motion & Drives

• Motion controllers • Servo systems • AC drives

Control Components

- Temperature controllers Power supplies Timers Counters Programmable relays
- Digital panel indicators Electromechanical relays Monitoring products Solid-state relays
- Limit switches Pushbutton switches Low voltage switch gear

Sensing & Safety

- Photoelectric sensors Inductive sensors Capacitive & pressure sensors
- Cable connectors Displacement & width-measuring sensors Vision systems
- Safety networks Safety sensors Safety units/relay units Safety door/guard lock switches

Cat. No. A190-E1-01 10/09 Note: Specifications are subject to change. © 2011 Omron Electronics LLC Printed in U.S.A.

Printed on recycled paper. 🏵

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Switch Actuators category:

Click to view products by Omron manufacturer:

Other Similar products are found below :

LW1B-M0 61-1330.0 61-2607.0/D 680-4000-00 704.411.018I 704.412.0 704.633.1 704.730.1 704.733.0 79452124 84-1221.7 862.8102 G6083 9PA24 120-1867-000 ADC-418G 12MA7 HW1M-L2222 200-.704-00 JS-10008 JS-10083 JS-10118 JS-10133 JS-116 JS-150 JS-555 JS-68 JS-6-B JS-91 JS-94 22-211.011 9001KXSDC KRR22NW3XX03 SAPT654133 2PA3 STKLBU STKLWH SW53AA2 302561 3E-10.4 3E-12.0 468-10243-001 51-030.002 51-030.005 JM-13 JS-10120 JS-138-B JS-143-B JS-49 JS-551