

ON Semiconductor

Is Now

onsemi™

To learn more about onsemi™, please visit our website at
www.onsemi.com

onsemi and **onsemi** and other names, marks, and brands are registered and/or common law trademarks of Semiconductor Components Industries, LLC dba "**onsemi**" or its affiliates and/or subsidiaries in the United States and/or other countries. **onsemi** owns the rights to a number of patents, trademarks, copyrights, trade secrets, and other intellectual property. A listing of **onsemi** product/patent coverage may be accessed at www.onsemi.com/site/pdf/Patent-Marking.pdf. **onsemi** reserves the right to make changes at any time to any products or information herein, without notice. The information herein is provided "as-is" and **onsemi** makes no warranty, representation or guarantee regarding the accuracy of the information, product features, availability, functionality, or suitability of its products for any particular purpose, nor does **onsemi** assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. Buyer is responsible for its products and applications using **onsemi** products, including compliance with all laws, regulations and safety requirements or standards, regardless of any support or applications information provided by **onsemi**. "Typical" parameters which may be provided in **onsemi** data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. **onsemi** does not convey any license under any of its intellectual property rights nor the rights of others. **onsemi** products are not designed, intended, or authorized for use as a critical component in life support systems or any FDA Class 3 medical devices or medical devices with a same or similar classification in a foreign jurisdiction or any devices intended for implantation in the human body. Should Buyer purchase or use **onsemi** products for any such unintended or unauthorized application, Buyer shall indemnify and hold **onsemi** and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that **onsemi** was negligent regarding the design or manufacture of the part. **onsemi** is an Equal Opportunity/Affirmative Action Employer. This literature is subject to all applicable copyright laws and is not for resale in any manner. Other names and brands may be claimed as the property of others.



ON Semiconductor®

STR-LV8548MC-GEVB

User Guide



Table of Contents

INSTALLATION	3
INCLUDED WITH EVALUATION KIT	3
STARTUP PROCEDURE.....	3
DC BRUSHED MOTORS	4
STEPPER MOTOR	5

Installation

Go to www.onsemi.com/strata to download the most recent version of Strata and follow the installation prompts.

Included with Evaluation Kit

1. PCB with mounted DC and stepper motors
2. AC wall adapter – 12V/1A
3. USB Mini-B cable
4. Small flathead screwdriver (for changing motors)

Startup Procedure

1. Connect included barrel jack
2. Connect your computer to the board using a USB Mini-B cable
3. Login with your credentials
4. Your board will be detected, UI will appear, and relevant collateral will be downloaded to your computer

Auxiliary Stepper Motor Connection

1. Disconnect included stepper motor
2. Connect new stepper to four pin screw terminal as seen below
3. Winding resistance should be high enough to ensure total holding current of less than 1A




A => OUT1
B => OUT2
C => OUT3
D => OUT4



OCP Indicators

Below are the three states that the OCP indicator can be in. Please know that once OCP is tripped, the reset button appears and must be clicked to resume operation of that motor.



DC Brushed Motors

Note: Only one DC motor is included in EVK

1. Overview


- a. **PWM Frequency** – Frequency for PWM signal at motor input
 - i. This parameter may not be changed while either motor is running
- b. **Input Voltage** – Input voltage to LV8548 that controls brushed motors
- c. **Input Current** – Input current to LV8548 that controls brushed motors
- d. **OCP** – Over current protection turns red when fault detected and reset button appears to right of indicator must be pressed to continue operation. OCP set at 1A.
 - i. Toggle switch below indicator disables OCP feature
- e. **Direction** – Clockwise or counter clockwise rotation
 - i. Changing the direction of running motor will cause a 10 ms brake between states
- f. **PWM mode** – Changes PWM control for driving DC motor
- g. **Duty Ratio** – Duty ratio for PWM signal at motor input
- h. **Start** – Starts the motor
- i. **Stop** – Brakes the motor (pulls both pins to GND)
- j. **Standby** – Stops the motor and leaves output pins floating

The screenshot displays the ON Semiconductor Strata Developer Studio interface for controlling DC brushed motors. The interface is divided into two main sections for Motor 1 and Motor 2. At the top, there are tabs for 'Brush' and 'Stepper'. Below these, a 'PWM frequency' slider is set to 1000 Hz. The 'INPUT VOLTAGE' is 12.1 V, 'INPUT CURRENT' is 0 mA, and 'OCP' is enabled. Each motor panel includes a 'Direction' selector, a 'PWM mode' selector (on ↔ off or on ↔ brake), a 'Duty ratio' slider (set to 75%), and 'start', 'stop', and 'standby' buttons.

Stepper Motor

The advanced view is broken up into 3 main sections:

1. Overview
 - a. **Input Voltage** – Input voltage to LV8548 that controls stepper motor
 - b. **Holding Current** – Holding current to LV8548 that controls stepper motor
 - c. **OCP** – Over current protection turns red when tripped and the reset button to right of indicator must be pressed to continue operation. OCP set at 1A
 - i. Toggle switch below indicator disables OCP feature for entire board
 - d. **Excitation** – Full or half step excitation method
 - e. **Direction** – Clockwise or counter clockwise rotation
 - f. **Step Angle** – Step angle of attached motor. Included motor (default) is 7.5°
 - g. **Motor Speed** – Motor speed in either steps per second or rotations per minute (rpm)
 - h. **Transfer Time** – Motor run duration in either seconds, steps, or degrees. 0 corresponds to ∞
 - i. **Start** – Starts the motor for the selected transfer time and motor speed
 - i. Note: All input telemetry stops while stepper motor is running
 - j. **Hold** – Stops the motor. Defaults to hold when transfer time is up. Provides holding torque to the stepper motor
 - i. **Warning:** Since current continues to flow when the motor stops, it is important to pay attention to heat generation. Press *Free* to stop holding current in motor
 - k. **Free** – Leaves stepper output pins floating. No holding torque is present



ON Semiconductor and the ON Semiconductor logo are trademarks of Semiconductor Components Industries, LLC dba ON Semiconductor or its subsidiaries in the United States and/or other countries. ON Semiconductor owns the rights to a number of patents, trademarks, copyrights, trade secrets, and other intellectual property. A listing of ON Semiconductor's product/patent coverage may be accessed at www.onsemi.com/site/pdf/Patent-Marking.pdf. ON Semiconductor is an Equal Opportunity/Affirmative Action Employer. This literature is subject to all applicable copyright laws and is not for resale in any manner.

The evaluation board/kit (research and development board/kit) (hereinafter the "board") is not a finished product and is as such not available for sale to consumers. The board is only intended for research, development, demonstration and evaluation purposes and should as such only be used in laboratory/development areas by persons with an engineering/technical training and familiar with the risks associated with handling electrical/mechanical components, systems and subsystems. This person assumes full responsibility/liability for proper and safe handling. Any other use, resale or redistribution for any other purpose is strictly prohibited.

The board is delivered "AS IS" and without warranty of any kind including, but not limited to, that the board is production-worthy, that the functions contained in the board will meet your requirements, or that the operation of the board will be uninterrupted or error free. ON Semiconductor expressly disclaims all warranties, express, implied or otherwise, including without limitation, warranties of fitness for a particular purpose and non-infringement of intellectual property rights.

ON Semiconductor reserves the right to make changes without further notice to any board.

You are responsible for determining whether the board will be suitable for your intended use or application or will achieve your intended results. Prior to using or distributing any systems that have been evaluated, designed or tested using the board, you agree to test and validate your design to confirm the functionality for your application. Any technical, applications or design information or advice, quality characterization, reliability data or other services provided by ON Semiconductor shall not constitute any representation or warranty by ON Semiconductor, and no additional obligations or liabilities shall arise from ON Semiconductor having provided such information or services.

The boards are not designed, intended, or authorized for use in life support systems, or any FDA Class 3 medical devices or medical devices with a similar or equivalent classification in a foreign jurisdiction, or any devices intended for implantation in the human body. Should you purchase or use the board for any such unintended or unauthorized application, you shall indemnify and hold ON Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that ON Semiconductor was negligent regarding the design or manufacture of the board.

This evaluation board/kit does not fall within the scope of the European Union directives regarding electromagnetic compatibility, restricted substances (RoHS), recycling (WEEE), FCC, CE or UL, and may not meet the technical requirements of these or other related directives.

FCC WARNING – This evaluation board/kit is intended for use for engineering development, demonstration, or evaluation purposes only and is not considered by ON Semiconductor to be a finished end product fit for general consumer use. It may generate, use, or radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment may cause interference with radio communications, in which case the user shall be responsible, at its expense, to take whatever measures may be required to correct this interference.

ON Semiconductor does not convey any license under its patent rights nor the rights of others.

LIMITATIONS OF LIABILITY: ON Semiconductor shall not be liable for any special, consequential, incidental, indirect or punitive damages, including, but not limited to the costs of requalification, delay, loss of profits or goodwill, arising out of or in connection with the board, even if ON Semiconductor is advised of the possibility of such damages. In no event shall ON Semiconductor's aggregate liability from any obligation arising out of or in connection with the board, under any theory of liability, exceed the purchase price paid for the board, if any.

PUBLICATION ORDERING INFORMATION

LITERATURE FULLFILLMENT:

Literature Distribution Center for ON Semiconductor 19521 E.
32nd Pkwy, Aurora, Colorado 80011 USA

Phone: 303-675-2175 or 800-344-3860 Toll Free USA/Canada
Fax: 303-675-2176 or 800-344-3867 Toll Free USA/Canada
Email: orderlit@onsemi.com

N. American Technical Support:

800-282-9855 Toll Free USA/Canada

Europe, Middle East and Africa Technical Support:

Phone: 421 33 790 2910

ON Semiconductor Website:

<http://www.onsemi.com/>

Order Literature:

<https://www.onsemi.com/orderlit>

For additional information, please contact your local Sales Representative

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Power Management IC Development Tools](#) *category:*

Click to view products by [ON Semiconductor](#) *manufacturer:*

Other Similar products are found below :

[EVAL-ADM1168LQEBZ](#) [EVB-EP5348UI](#) [MIC23451-AAAYFL EV](#) [MIC5281YMME EV](#) [DA9063-EVAL](#) [ADP122-3.3-EVALZ](#) [ADP130-0.8-EVALZ](#) [ADP130-1.2-EVALZ](#) [ADP130-1.5-EVALZ](#) [ADP130-1.8-EVALZ](#) [ADP1712-3.3-EVALZ](#) [ADP1714-3.3-EVALZ](#) [ADP1715-3.3-EVALZ](#) [ADP1716-2.5-EVALZ](#) [ADP1740-1.5-EVALZ](#) [ADP1752-1.5-EVALZ](#) [ADP1828LC-EVALZ](#) [ADP1870-0.3-EVALZ](#) [ADP1871-0.6-EVALZ](#) [ADP1873-0.6-EVALZ](#) [ADP1874-0.3-EVALZ](#) [ADP1882-1.0-EVALZ](#) [ADP199CB-EVALZ](#) [ADP2102-1.25-EVALZ](#) [ADP2102-1.875EVALZ](#) [ADP2102-1.8-EVALZ](#) [ADP2102-2-EVALZ](#) [ADP2102-3-EVALZ](#) [ADP2102-4-EVALZ](#) [ADP2106-1.8-EVALZ](#) [ADP2147CB-110EVALZ](#) [AS3606-DB](#) [BQ24010EVM](#) [BQ24075TEVM](#) [BQ24155EVM](#) [BQ24157EVM-697](#) [BQ24160EVM-742](#) [BQ24296MEVM-655](#) [BQ25010EVM](#) [BQ3055EVM](#) [NCV891330PD50GEVB](#) [ISLUSBI2CKIT1Z](#) [LM2744EVAL](#) [LM2854EVAL](#) [LM3658SD-AEV/NOPB](#) [LM3658SDEV/NOPB](#) [LM3691TL-1.8EV/NOPB](#) [LM4510SDEV/NOPB](#) [LM5033SD-EVAL](#) [LP38512TS-1.8EV](#)