


RS-232 (DB9) CABLE TESTER



DB9-RS232 Cable Tester



72-9200 is RS-232 (DB9) cable tester. 72-9200 can test the "Open" & "Short" of RS-232 cable. It is standard DB9 male to DB9 female cable tester. 72-9200 use 9 pcs blue LED to show the test result.

Remark:


1. 72-9200 needs power to work.

Power option :a: 5V USB power cable



b: battery box (you must use the size "AA" 3 pcs)

c: AC to DC Adapter (5V, 2A)

2. RS-232 cable must to have the shield. If RS-232 cable is without shield, the blue LED of tester is "NG"
3. If RS-232 cable has the "OPEN" or "SHORT" , the blue LED of tester is "NG"

**RS-232 / DB-9 / LED Pin assignment (full pin test)**

RS-232 Signal	Name	DB 9 Female	DB 9 Male	LED
FG (Frame Ground)*		Metal case*	Metal case*	
CD (Carrier Detect)		1	1	DCD
RD (Receive Data)		2	2	RXD
TD (Transmit Data)		3	3	TXD
DTR (Data Terminal Ready)		4	4	DTR
SG (Signal Ground)		5	5	GND
DSR (Data Set Ready)		6	6	SDR
RTS (Request To Send)		7	7	RTS
CTS (Clear To Send)		8	8	CTS
RI (Ring Indicator)		9	9	RI
Test step : DCD=>RXD=>TXD=>DTR=>GND=>DSR=>RTS=>CTS=>RI				



AC to DC Adapter

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Tenma](#) manufacturer:

Other Similar products are found below :

[76-096](#) [21-10156](#) [BC0019213](#) [76-355](#) [CBB018722](#) [76-1564](#) [A1170](#) [72-14500](#) [72-14530](#) [EU](#) [72-13668](#) [72-13686](#) [72-13736](#) [72-13742](#) [72-13798](#) [72-13818](#) [72-13822](#) [72-13824](#) [72-13836](#) [72-13858](#) [72-13950](#) [72-14090](#) [72-14096](#) [72-14112](#) [72-14228](#) [72-14300](#) [72-14302](#) [21-10164](#) [21-10154](#) [72-10405](#) [BC0024434](#) [CBB019217](#) [76-1448](#) [76-024](#) [72-13654](#) [72-13762](#) [72-13826](#) [72-13872](#) [72-13874](#) [72-13888](#) [72-13986](#) [72-14014](#) [72-14154](#) [72-14230](#) [72-14272](#) [21-10152](#) [72-9405](#) [72-7615](#) [72-9490](#) [76-1446](#) [76-1566](#)